

Instruction Manual

Connection Method:

1. Ensure the wireless function of your phone is turned off. Take the earbuds out of the charging case—after removal, the indicator light will flash red and blue alternately in quick succession (wait for 5 seconds after taking them out). They will then automatically enter TWS mode (dual-earbud mode). Once successfully in TWS mode, both earbuds will slowly flash red and blue alternately in sync.

2. Turn on the wireless function of the phone and connect to "G201". After successful connection, the earbuds' indicator light will turn off.

(If only one earbud has sound, first turn off your phone's wireless function, delete the paired device "G201", place the earbuds back into the charging case, and then proceed to Step 1.)

Touch Control Function:

1. Short press: Play, pause, answer calls, end calls; press and hold the touch area during incoming calls to reject.
2. Double-tap left/right earbud touch area: Previous track/next track.
3. Triple-tap left/right earbud touch area: Volume down/volume up.
4. Press and hold the touch area for 1.5 seconds: Activate Siri.
5. Press and hold the touch area for about 5 seconds: Power on/off.

Touch Control Area



Charging:

The red light turns on when the earbuds are charging and turns off when fully charged;


The red light flashes when the charging case is charging and stays steadily lit when fully charged.

The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 10 Watts in order to achieve the maximum charging speed.





The usage methods of intelligent tools:

1. Search for and download the "VoxNex" APP in your app store, or scan the QR code below to download.



2. Connect the earphones to your phone, then open the app to start using them.



FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.