

Instruction Manual

Connection Method:

1. Ensure the wireless function of your phone is turned off. Remove the earbuds from the charging case (wait for 5 seconds after removal), and they will automatically enter TWS mode (dual-earbud mode).
2. Turn on your phone's wireless function and connect to "G301".

(If only one earbud has sound, first turn off your phone's wireless function, delete the paired device "G301", place the earbuds back into the charging case, and then proceed to Step 1.)

Touch Control Function:

1. Short press: Play/Pause, Answer/End call; Long press the touch area during an incoming call to reject.
2. Double-tap left/right earbud touch area: Previous track/Next track.
3. Triple-tap left/right earbud touch area: Volume down/Volume up.
4. Long press (1.5 seconds) on earbud touch area: Activate Siri.
5. Long press (~5 seconds) on earbud touch area: Power on/off.



Touch Control Area

Charging:

The charging case's blue light flashes during charging and stays solid blue when fully charged.

The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 10 Watts in order to achieve the maximum charging speed.



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter. The device can be used in portable exposure conditions without restriction.

FCC ID: 2AXK8-G301