



kms One

USER MANUAL



2.4G WIRELESS RECHARGEABLE
KEYBOARD WITH COVER

Keyboard Specification


Working voltage	3.0V
Working current	<5mA
Keys number	95 keys
Keycap structure	scissors
Keyboard size	347*122*20mm
Keyboard weight	330g
Keyboard lifespan	3 millions keypresses
Wireless operating distance	10 meters
Storage temperature	-40 ~ 125 degree (in celsius)
Operating system	Windows XP/7/8/10/Vista

Mouse Specification

Working voltage	3.0V
Working current	<20mA
Sleeping current	<0.2mA
Mouse buttons	4
DPI levels	800/1200/1600dpi
Mouse size	113*59*26mm
Weight	66g
Mouse buttons lifespan	3 million clicks

<1>


Product explicative image



Functional Description

- Fn+F1=Music
- Fn+F2=Volume down
- Fn+F3=Volume up
- Fn+F4=Mute
- Fn+F5=Previous
- Fn+F6=Next
- Fn+F7=Play/Pause
- Fn+F8=Stop
- Fn+F9=Web browser
- Fn+F10=Email
- Fn+F11=My computer
- Fn+F12=My favourite

<2>



Package contents:

- 1 x Wireless Keyboard
- 1 x Wireless Mouse (USB receiver included)
- 1 x User Manual
- 1 x Micro USB Charging Cable.

<3>



Connection Guidance:

1. Take the receiver out of the mouse ;
2. Plug the receiver into the USB port of the computer;
3. Switch on the power of the mouse and keyboard;
4. The two devices should connect to your computer automatically.

Notice:

The mouse will enter Sleep Mode after idling for 5 minutes.
Press any key to activate it.

Please charge if they are slow responses

Trouble Shooting:

If the keyboard doesn't work properly, please try the following:

1. Unplug the receiver from the computer;
2. Switch off the power of the keyboard and turn it on after 3 seconds;
3. Hold down the "Esc" and "=" keys at the same time until the red LED light is on;
4. Plug the receiver back into the USB port of computer;
5. The keyboard should reconnect to the computer 1 second after the red LED light switches off.

If the mouse cannot work properly, please try the following:

1. Unplug the receiver from the computer;
2. Switch off the power of the mouse and turn it on after 3 seconds;
3. Plug the receiver back into the USB port of computer;
4. Switch on the power of the mouse;
5. The mouse should reconnect to the computer.

<5>

Wireless keyboard FCC ID:2AXNMKMSONE
Mouse FCC ID: 2AXNMKMSONE2
This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) this device may not cause harmful interference,
and (2) this device must accept any interference received,
including interference that may cause undesired operation.

<6>




<7>



kms One

MANUAL DE USUARIO



2.4G TECLADO INALÁMBRICO RECARGABLE

Especificaciones del Teclado

Voltaje	3.0V
Corriente	<5mA
Número de teclas	95 keys
Estructura de teclas	scissors
Tamaño del teclado	347*122*20mm
Peso del teclado	330g
Esperanza de funcionamiento	3 millions keypresses
Distancia operativa	10 meters
Temperatura de almacenamiento	-40 ~ 125 degree (in celsius)
Sistema Operativo	Windows XP/7/8/10/Vista

Especificaciones del Mouse

Voltaje	3.0V
Corriente	<20mA
Corriente de espera	<0.2mA
Número de botones	4
Niveles de DPI	800/1200/1600dpi
Tamaño del Mouse	113*59*26mm
Peso del Mouse	66g
Esperanza de funcionamiento	3 million clicks

<1>


Imagen explicativa del producto



Descripción de funciones:

- Fn+F1= Música
- Fn+F2= Bajar volumen
- Fn+F3= Subir volumen
- Fn+F4=Mute
- Fn+F5= Anterior
- Fn+F6= Siguiente
- Fn+F7= Play/Pausa
- Fn+F8= Detener
- Fn+F9= Navegador
- Fn+F10=Email
- Fn+F11= Mi computadora
- Fn+F12= Mis favoritos


<2>



Contenido de Caja:

- 1 x Teclado Inalámbrico
- 1 x Mouse Inalámbrico (Receptor USB incluido)
- 1 x Manual de Usuario
- 1 x Cable de carga Micro USB

<3>



Guía de Conexión:

1. Retire el receptor del mouse.
2. Conecte el receptor en el puerto USB de la computadora.
3. Encienda el mouse y el teclado.
4. Ambos dispositivos deberían conectarse automáticamente.

Nota:

El mouse entrara en modo sueño luego de estar inactivo po 5 minutos, pulse cualquier tecla para activarlo nuevamente.

Carguelo si experimenta movimientos lentos.

<4>

Solución de Problemas:

Si el teclado no está funcionando de manera correcta, pruebe lo siguiente:

1. Desconecte el receptor de la computadora.
2. apague el teclado y enciéndalo luego de 3 segundos.
3. Mantenga presionado la tecla "Esc" y "=" al mismo tiempo hasta que la luz LED ROJA se encienda.
4. Conecte el receptor nuevamente a la computadora.
5. El teclado debería conectarse a la computadora 1 segundo despues de que la luz roja de apague.

Si el Mouse no está funcionando de manera correcta, pruebe lo siguiente:

1. Desconecte el receptor de la computadora.
2. Apague el mouse y enciéndalo luego de 3 segundos.
3. Conecte el receptor nuevamente a la computadora.
4. Encienda el Mouse.
5. El Mouse debería reconectarse a la computadora.

<5>

Wireless keyboard FCC ID:2AXNMKMSONE
Mouse FCC ID: 2AXNMKMSONE2

Este dispositivo cumple con la Parte 15 de las Reglas FCC.
La operación está sujeta a las siguientes condiciones:
(1) este dispositivo no causa interferencia dañina, y
(2) este dispositivo debe aceptar cualquier interferencia recibida, incluso interferencia que pueda causar un funcionamiento indeseado.

<6>



<7>

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.