

X10使用说明书

尺寸:79X103mm
材料:128g铜版纸
工艺:四色印刷, 折页


Mifa

USER MANUAL

Customer Service


Email: service@mifa.tech
WhatsApp: (+86) 1392 3490 475
Web: www.mifa.tech

Packing List



1/13

Product Overview




2/13

First-time use

- Remove the plastic protective films on the earphones.
- Fully charge both Earphones and charging case when first-time use.
- Use the provided Type-C charging cable, or upright the charging case on a wireless charger to get charge.

How to wear?

1.Choose suitable ear tips.



2.Put on and twist to adjust to the most comfortable angle.




3/13

How to charge?

Type-C Cable charging

Place earphones into the charging case correctly, open the dustproof cover, connect to power supply with the USB-C charging cable, then the earphones and charging case will start charging.



Wireless Charging Supported

Upright the charging case on a wireless charger(not included) to get charge.
(* We recommend you to use wireless charger with Qi certificate.)




4/13

LED Battery Power Display


Battery indicator of Charging Case

The display will show the remaining power of case when you put earphones in, or just open the charging case lid. The number will flash when charging, and will show "100" when fully charged, and will turn off about 10 secs later.



Charging Status of Earphones

When being charged, earphones' LED will flash red light; When fully charged, earphones' LED red light will turn off.





5/13

How to power on/off ?

Automatically Power on/off

(Make sure the earphones and charging case have power.)

1.Take out earphones from the charging case, they will auto power on and enter pairing mode. (You could hear prompt sound "power on" then "pairing" if you wear the earphones.)



2.Put the earphones back into the charging case, the earphones will disconnect & power off automatically.

6/13

Manually Power on/off

Touch & hold earphones' touch control area for about 3 secs, earphones' LED light flashes red and green alternately, then turns off, which means the earphones turn on and ready to pair.



Ensure the earphones are not connected to any device, then touch & hold either earphone's (L/R) touch control area for about 5 secs, both earphones' light will flash red for 2 secs, then turn off, which means the earphones (L & R) turn off.



7/13


How to pair & connect dual earphones? —

- Take out both earphones from the charging case, they will auto turn on and be ready for connection.
- Then activate the Bluetooth setting on your phone, search and connect "Mifa X10".



Single Mode

- When on dual mode, put one earphone into the charging case.
- Only take one earphone out from the charging case and connect it.



8/13

Factory Restore Setting

When should I do reset?

When only one side play music.
When both earphones fail to pair with each other or occur connection related issues.

How to do the reset?




- Delete all "Mifa X10" from the Bluetooth menu on your phone and deactivate the Bluetooth setting.
- Place earphones into the charging case correctly, touch and hold both earphones' touch control area for about 10 secs, earphones' LED light flashes red 3 times, which means the earphones have been reset.
- Now take out the earphones from charging case and activate the Bluetooth setting on your device, search "Mifa X10", it will connect without problem.



9/13





Multi-function Operations

Incoming Call



10/13

Music Mode



(*You have to skip back on the connected device.)

11/13

Specification

- Bluetooth Version: V5.0
- Support: A2DP/HFP/HSP/AVRCP
- Transmission Range: 33 feet (without obstacle)
- Charging Port: Type-C
- Wireless Charging Supported: Yes
- Music Time: 7H
- Phone Call Time: 5H
- Charging Time: about 2H
- Battery of each earphone: 40mAh
- Battery of Charging Case: 500mAh

Safety Precautions

- Please do not dismantle the earphones or charging case.
- Please Keep the earphones and charging case out of extreme heat or humidity. And prevent them from being stricken, dropped, warped, soaked, etc.
- Please stop using the device if it causes any discomfort or pain.
- Please do not overcharge the device for a long time, otherwise it will decrease the battery's lifespan.
- Use DC 5V-1A chargers/adapters certified by a regulated manufacturer. Recharging and discharging the headphones repeatedly will lead to decrease in battery performance over time, which is normal for all rechargeable electronic products.

12/13

FQA

Q1: Why does the music cut in and out sometimes?

- A1: 1-Please make sure there is no obstacle between the earphones and your device.
2-Please make sure there is no Microwave oven/Wifi transmitter around you, which are more likely to produce electromagnetic interference and result in signal interruption.

Q2: What should I do if the earphones stop charging?

- A2: 1-We advise you to charge the earphones by using the supplied original charging cable.
2-Please make sure the charging pins and charging points are clean & dry before charging.
3-Please make sure the headphones' battery was run out if sometimes it can't be charged properly.

Q3: How to contact Mifa customer service?

- A3: Email: service@mifa.tech
WhatsApp: (+86) 1392 3490 475
Web: www.mifa.tech

If there is any issue with your Mifa X10, please don't hesitate to contact us, we will reply within 24 hours and solve your problem 100%.

13/13

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
--Increase the separation between the equipment and receiver.
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.
FCC ID: 2AX0X-X10