


Open-Ear Bluetooth Headphones



95mm

Instructions for usage and warranty
Operating instructions and Warranty description

Schematic diagram



Parts list

1: Headphone x1 2: Charging cable x1 3: Instruction manual x1

Instruction

Bluetooth Paring
When used for the first time, after the headset is turned on normally, it will enter the Bluetooth pairing state. At this time, " X1 " can be searched in the Bluetooth settings of the mobile phone. After clicking the connection button, the indicator light will turn off, and the music will start playing. The blue light will flash once every 5 second.

Change paired devices and reconnect
Disconnect the Bluetooth of the currently paired device, the headset indicator light flashes red and blue alternately, other devices can search for "X1" , Click connect . For connected devices, please ensure that the front end (such as mobile phone Bluetooth) is turned on normally.

Charging
Normal connection, the phone will display the earphone battery, such as the battery display red, that is, the meter show the need to charge, plug in the charging line to charge. about 2 hours to fill, charging status indicator is red light, full charge often blue light .

Note
Please use a USB power adapter with an output of 5V less than 1A.
 The rechargeable battery of this product must be properly disposed of for recycling. Please do not place the battery in a fire to avoid explosion.

Power On/Off

Function	Operation	Indicator light
Power On	Press '  ' for 3-5s	The blue light on for 1s
Power Off		The red light on for 1s

Operating instruction

Function	Earphone status	Operation
Increase volume	Play music	Click '  '
Reduce volume		Click '  '
Next song		Press '  ' for 2s
Previous song		Press '  ' for 2s
Pause	Pause	Click '  '
Resume	Phone calls in	
Answer the call	Phone calls in	
Hang up	Press '  ' for 2s	
Decline the call		
Volume control	Calling	Click '  ' / '  '

Indicator

Search for a match	Red and blue lights flash alternately
Charging	Normally on red light
Finished charging	Normally on blue light
Bluetooth music player	Blue light flashes once every 5 sec.

AI intelligent voice control

(Phone needs to support voice wake-up function)

Function	Earphone status	Operation
Voice control	Bluetooth is connected	Double click '  '

Note: In the Bluetooth connection status, Double click '  '. After hearing the prompt, you can voice control the phone, saving time to operate the phone, fast and smart.

Game/Music Mode Switching

Function	Earphone status	Operation
Mode switching	Bluetooth is connected	4-click '  '

Note: In Bluetooth connection mode , 4-click '  ' to switch between Game/Music Mode. (Default music mode upon first startup)

Troubleshooting

Unable to boot
Determine whether the headset is fully charged, whether the button is misoperated, and then charge and activate.

Unable to connect to Bluetooth
Whether the headphone indicator is in the alternately flashing stage of red and blue, such as the headphone is in the breathing state of blue light, Indicates that the headset has been connected to other devices and needs to disconnect the current connected device.

Can't back to even
Make sure the front end (e.g., Bluetooth) is open properly.

Headphone volume is low
Whether the phone increases the volume, the phone needs to increase or decrease the volume. Wearing a way Whether it is right.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Statement

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition, compliance with exposure requirements.

Product parameter

Model: X1	Version: 5.4
weight: ≈28g	Battery: 200mAh
Input: 5V/150mA	Charging time: ≈2h
Call parameters: -42dB	
Waterproof grade: IPX5	
Distance: Bluetooth 10 meter	
Operating time : ≈9h@60% Volume	
Profile: A2DP, AVRCP, HFP	

Care and cleaning

- The product cannot be soaked in water, otherwise it will short-circuit and burn out.
- If not used for a long time, please fully charge it at least once a month.
- Do not disassemble any part of the product without permission. If you find that the earphone is defective, please stop using it.
- Keep the product away from fire, heat, freezing, and chemicals. Do not immerse the earphone in water, and do not wipe it with chemicals such as aromatherapy water.
- Store in a cool, dry place. Do not expose the product to direct sunlight for a long time.
- Please use a USB power adapter with an output of 5V less than 1A.



Product warranty card

This card is a product warranty certificate, please keep it properly

Product name:	Product model:
Purchase date:	Clients name:

Contact:

Product maintenance records

Date	Bad phenomenon	Solution

70mm