

Konnnect

User's Guide

Contents

1. Safety Information, *P3*
 - 1.1 Warning, *P3*
 - 1.2 Precautions, *P3-4*
 - 1.3 Handling Cautions, *P4*
2. Introduction, *P5*
 - 2.1 Package Contents, *P5*
 - 2.2 Product Features, *P6*
 - 2.3 Setup Connection, *P8*
 - 2.4 Display when Power Up, *P8*
3. Settings, *P7*
 - 3.1 WiFi, *P7*
 - 3.2 Bluetooth, *P9*
 - 3.3 Ethernet, *P9*
 - 3.4 Data usage, *P10*
 - 3.5 Wireless & networks, *P10*
 - 3.6 users, *P11*
 - 3.7 Sound, *P11*
 - 3.8 Display, *P12*
 - 3.9 Storage, *P14*
 - 3.10 Apps, *P14*
 - 3.11 Google services, *P15*
 - 3.12 Notification, *P15*
 - 3.13 Location, *P16*
 - 3.14 Security, *P16*

- 3.15 Language & input, *P17*
- 3.16 Reset, *P17*
- 3.17 Sleep, *P18*
- 3.18 Add an account, *P18*
- 3.19 Date & Time, *P19*
- 3.20 Choose wallpaper from, *P19*
- 3.21 Screen saver, *P20*
- 3.22 About device, *P20*
- 3.23 Camera mode, *P21*
- 3.24 HDMI, *P21*
- 3.25 Printing, *P22*

- 4. Apps Install & Uninstall, *P22*
- 5. Firmware Update, *P22*
- 6. Trouble Shooting/FAQ, *P23*
- 7. Repairs, *P23*
- 8. Specification, *P24*

1. Safety Information

Read and understand all instructions before using this product. If damage is caused by failure to follow the instructions, the warranty does not apply.

1.1 Warning

To reduce the risk of electric shock, DO NOT remove the cover (or back).

DO NOT attempt to repair the product, this could lead to the risk of injury, damage to the product .

To reduce the risk of fire or electric shock, keep this product away from exposed direct sunlight, naked flames or heat, large amounts of moisture, dust, and sand.

FCC Note (for U.S.A)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on.

The user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.
- This class B digital product meets all requirements of the Canadian Interference - Causing Equipment Regulations.

Radiation Exposure Statement

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

1.2 Precautions

Important Safety Instructions

Read these operating instructions carefully before using the unit. Follow all the safety instructions listed below.

Keep these operating instructions handy for future reference.

1.2.1 Read these instructions.

1.2.2 Keep these instructions.

1.2.3 Heed all warnings.

1.2.4 Follow all instructions.

1.2.5 DO NOT use this apparatus near water.

1.2.6 DO NOT clean with any chemical detergent. Clean only with a dry cloth.

- 1.2.7 DO NOT block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 1.2.8 DO NOT install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- 1.2.9 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where it exits the apparatus.
- 1.2.10 Only use attachments/accessories specified by the manufacturer.
- 1.2.11 Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 1.2.12 Unplug this apparatus during lightning storms or when unused for long period of time.
- 1.2.13 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

1.3 Handling Cautions

- 1.3.1 DO NOT expose this apparatus to dripping or splashing. Do not put objects filled with liquids, such as vases on the apparatus.
- 1.3.2 To turn this apparatus off completely, you must pull the power plug out of the wall socket. Consequently, the power plug must be easily and readily accessible at all times.
- 1.3.3 DO NOT plug multiple electric devices into the same wall socket. Overloading a socket can cause it to overheat, resulting in a fire.
- 1.3.4 Before connecting other components to this player, be sure to turn them off.
- 1.3.5 If the product makes an abnormal noise or produces a burning smell or smoke, turn off the power switch immediately and disconnect the power plug from the wall outlet. Then, contact the nearest customer service center for technical assistance. Do not use the product. Using the product as it is may cause a fire or an electric shock.

2. Introduction

2.1 Package Contents

Kraydel Hub Quad + Dual Core Box – KONNECT

User's Guide

HDMI Cable

Fiber Optical Cable, RJ45 Network Cable

IR Remote Controller (IR RC)

Power Adapter, Input: AC100 ~ 240V, 50/60Hz, Output: 12V-3A

The Kraydel Hub Quad and Dual Core Box must be used together with the KONNECT cable connect, and they can't work alone.

2.2 Product Features

Rockchip RK3399 Octa-core CPU


- ARM Dual-core Cortex-A72 and quad-core Cortex-A53
- ARM Mali-T860MP4 GPU support OpenGL ES1.1/2.0/3.0, OpenCL1.2, DirectX11.1 etc.
- 2GB LPDDR4 memory(Optional 1G、4G)
- 8GB EMMC Flash(Optional 16-64G)
- Android OS 7.1
- Built-in IEEE 802.11 B/G/N AC dual band 2.4G/5G+BT4.0
- WAN RJ45 10/100/1000M Ethernet interface
- One HDMI output, One HDMI In
- SDK available, fully controlled displaying
- Support 2.4G & 5G wireless Router
- Support 3G & 4G
- Support weather, calendar, and desktop clock gadgets
- Support music player, picture player and more family entertainment
- Support TF card and Google Chrome browser and virtual private network access
- App Installer for application installation from USB/TF card

2.3 Setup Connection


Place KONNECT on a flat platform near the TV, and make sure nothing blocks the remote control signal.

2.4 Display when Power Up

2.4.1 After power up, the TV will first show a green robot during loading. When loading is finished, it will go to Home screen.




2.4.2 Home Screen display.



3. Settings


Using Navigation (4 directions), OK, EXIT, and Menu keys of Remote Controller to select the options, the option selected will be highlighted and confirmed by pressing OK key. Same operation for text input if needed.

Select  icon then press OK key.




3.1 WiFi

3.1.1 It will automatically scan ambient WiFi networks when select “ON”. Connect an available WiFi network. If connect a secured WiFi network, corresponding password will be input firstly. Or fail to connect and need reset password. Once build up the connection with a certain WiFi network successfully, KONNECT will connect this WiFi network automatically when restart.
Note: If factory reset, the password of WiFi network have to be reset.




3.1.2 Tethering & portable hotspot


If you want to share WIFI with your friends, you can set the wi-fi hotspot here, set the wi-fi password, and turn on the hotspot switch for transmission.



3.2 Bluetooth




3.3 Ethernet




3.4 Data usage

Show data usage information.




3.5 Wireless & networks



3.6 users

You can add user or configuration here



3.7 Sound

3.7.1 Volumes


Increase or decrease sound volumes

3.7.2 Touch Sounds

If enable Touch sound, sound will be heard while move remote controller.

3.7.3 Sound Input Devices


3.7.4 Sound Output Devices



3.8 Display


3.8.1 Display size

make the items on your screen smaller or larger. Some apps on your screen may change position.




3.8.2 Font size

Change the font size of OSD., Make the text on screen smaller or larger




3.8.3 Cast screen




3.8.4 Screenshot

Here you can set the screen shot time and select the image location




3.9 Storage

Shows the storage used of the OS and SD card.



3.10 Apps

List all apps installed.




You can choose an application and force to shut down the app, uninstall the app, clear user data, move to SD card and clear cache data.


3.11 Google services




3.12 Notification




3.13 Location



3.14 Security



3.15 Language & input




Change OSD language and input method.

The default input method is android standard keyboard.

If you are using our IR remote control, enter into “Default” option and switch to remote controller input method.

3.16 Reset




Factory data rest:

You can reset all the settings and apps to factory default.


Note: You might want to backup important data before resetting the box. Once you choose to rest to factory default, all data/apps will be deleted.

3.17 Sleep


Find the display button and find Sleep. You can select the Sleep time of the product. There are 8 options for sleep time. The shortest is 'Never' and the longest is 30 minutes.



3.18 Add an account




3.19 Date & time




3.20 Choose wallpaper from

Users can choose wallpaper photos from albums and historical wallpapers according to their preferences.




3.21 Screen saver

Interface Settings: can set the clock, color, theme, page photos.




3.22 About device.




3.23 Camera mode

set the USB camera to back/front mode




3.24 HDMI

User can set the screen, display resolution, zoom in/out screen, rotate screen, dual screen display in this part.



3.25 Printing

If you have a printer installed, you can print in this part.



4. Apps Install & Uninstall

On KONNECT, you can install apps from Android Market over the Internet or other sources, such as other online sources, the internal storage and the USB storage device and SD card that you have mounted onto KONNECT.

You also can manage apps on KONNECT and SD card, install/uninstall apps, stop running apps, or select other options.

5. Firmware Update

You can download newest firmware from Geniatech Official website:
www.geniatech.com

6. Trouble Shooting/FAQ

6.1 No Picture

Refer to the TV user manual for how to select the correct video input channel.

6.2 USB Content cannot be read

- . The format of USB storage device is not supported
- . The supported memory size is 32G maximum.
- . Make sure that this player supports these files.

6.3 Remote Controller cannot respond quickly to the pressing of keys

Make sure that batteries have enough power.

6.4 The firmware updating is not complete after a long time

If you update the firmware over the online service, it may take a long time to download the firmware update files from the server. To save your time, update the firmware through the SD card.

7. Repairs

If you contact us to repair your player, an administration fee may be charged if either:

An engineer is called out to your home at your request and there is no defect in the product.

You bring the unit to a repair center and there is no defect in the product.

We will provide you with the amount of the administration fee before we make a home visit or begin any work on your player.

We recommend you read this manual thoroughly, search for a solution on line at www.geniatech.com, or contact Geniatech Customer Care before seeking to repair your player.

8. Specification

CPU	ARM Dual-core Cortex-A72 and quad-core Cortex-A53, up to 1.8GHz
GPU	Mali-T860MP4 GPU (ARM Frame Buffer Compression)
RAM	2G LPDDR4
ROM	8G eMMC
OS	Android 7.1
USB	1*USB2.0+1*USB3.0
HDMI	1*HDMI IN+1*HDMI OUT
DC Input	5.0V-2A
MicroSD Slot	Max: 32G
Video Output	HDMI+Earphone
IR Blaster	IR Blaster x1
RS232	Support
POE	Support optional
LAN	RJ45 10/100/1000M Ethernet interface
WiFi	IEEE 802.11 AC 2.4G & 5.8G(optional)
BT	Optional
WCDMA	Band II/ IV/V
LTE	Band2/4/5/12/13/14/66/71
Audio Decoder	Built-in Audio Codec with 24-bit resolution
	One I2S interface (2 channels) for Audio input/output
	IEC 60958 (SPDIF) digital audio output
	7.1 CH down-mix
	MPEG I Layer 1, 2, 3 (2-CH) and MPEG II Layer 1, 2 (Multi-Channel) LPCM, ADPCM, ALAC, FLAC, AAC, WAV, AIFF, VSELP, and OGG Vorbis LPCM/ADPCM/MP3/AAC audio recording DTS Broadcast capable (Licensee Only) Dolby Digital Consumer Encoder capable (Licensee Only)
Video/Picture Decoder	Real-time video decoder of MPEG-1, MPEG-2, MPEG-4, H.263, H.264, H.265, VC-1,
	VP9, VP8, MVC
	Error detection and concealment support for all video formats
	H.265/HEVC, Main/Main10 profile @ level 5.1 High-tier; up to 4Kx2K @ 60fps
	H.264/AVC, Base/Main/High/High10 profile @ level 5.1; up to 4Kx2K @ 30fps MPEG-4, ISO/IEC 14496-2, SP@L0-3, ASP@L0-5, up to 1080P @ 60fps MPEG-2, ISO/IEC 13818-2, SP@ML, MP@HL, up to 1080P @ 60fps MPEG-1, ISO/IEC 11172-2, up to 1080P @ 60fps

VC-1, SP@ML, MP@HL, AP@L0-3, up to 1080P @ 60fps
MVC is supported based on H.264 or H.265, up to 1080P @ 60fps

Size	195x146x29mm
Net Weight	392g
Power Adapter	AC100 ~ 240V 50/60Hz
IR Remote	
Controller	Optional
Optional Remote	2.4G wireless Remote Controller with Nano receiver
Controller	USB wire/wireless Mouse & Keyboard