

### True Wireless Sport Earbuds

Model: OEB-E11D

Hereby, ORAIMO TECHNOLOGY LIMITED.

Declares that this True Wireless Earbuds is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU.

**Please read this Guide carefully  
before using the product**

For more information, please visit:


[www.oraimo.com](http://www.oraimo.com)

 @oraimo\_accessories

 @oraimoclub

 @oraimomate


#### Package Contents



#### Product Overview



#### Product Overview



#### Basic Product Specifications

##### Earbuds

Range: 10m / 33ft

Music play time: Up to 5 hours on single charge, case provides additional 15 hrs

Battery capacity: 35mAh (each earbud)

Charging time: Approx. 1.5 hours

\*oraimo Lab test results

##### Charging Case

Battery capacity: 330mAh

Charging time: Approx. 2 hours

\*If the charging case is fully charged, it can recharge the earbuds about 3 times.

#### Using Your Earbuds



#### Turn On & Pairing



\* Earbuds will turn on and enter pairing mode automatically when open the charging case.

| Earbud Status Indicator                                                             |                                | Status                |
|-------------------------------------------------------------------------------------|--------------------------------|-----------------------|
|  | Flashing white on both earbuds | Bluetooth Pairing     |
|  | Lights off                     | Connected to a device |

💡 Make sure the distance of the earbuds and your device is less than 1 metre / 3.3 feet at the first time of connection.

💡 When turned on, the earbuds will automatically connect to the last connected device if available. If not, the earbuds will enter pairing mode.

💡 Under any abnormal condition, return the earbuds to the charging case and then take out again.

### Turn Off

- The earbuds will automatically turn off after 5 minutes if no device is connected.
- When the earbuds are in the charging case and the lid is closed, it will automatically turn off after being fully charged.
- If the distance of the earbuds and your device is more than 10 metres, it will automatically turn off after 5 minutes.

### Charging Your Earbuds & Case

#### Charging The Earbuds



Earbuds will be charged automatically once they are returned to the charging case with the lid closed.

#### Charging The Case



| Case Status Indicator |                                      |
|-----------------------|--------------------------------------|
|                       | Steady red (Low level battery)       |
|                       | Steady orange (Medium level battery) |
|                       | Steady green (Full battery)          |
| Status                |                                      |
|                       | Charging                             |
|                       | Fully Charged                        |

Use the included Type-C charging cable to charge the case.

### Case Power Level

| Case Status Indicator |                                      |
|-----------------------|--------------------------------------|
|                       | Steady red (Low level battery)       |
|                       | Steady orange (Medium level battery) |
|                       | Steady green (Full battery)          |
| Status                |                                      |
|                       | Charging                             |
|                       | Fully Charged                        |

### Controls

| Controls |                                                 |                   |
|----------|-------------------------------------------------|-------------------|
|          | Tap on one earbud twice                         | Play/Pause        |
|          | Tap and hold on the left earbud for one second  | Previous track    |
|          | Tap and hold on the right earbud for one second | Next track        |
|          | Tap on one earbud twice                         | Answer/End a call |
|          | Tap and hold on one earbud for one second       | Reject call       |

### FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

**FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

| Call Control                                                                             |                                           |             |
|------------------------------------------------------------------------------------------|-------------------------------------------|-------------|
| <br>X 2 | Tap on one earbud twice                   | Answer call |
| <br>1"  | Tap and hold on one earbud for one second | Reject call |

| Others                                                                                     |                                                                                                                               |                                    |
|--------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|------------------------------------|
| <br>X 3   | Tap one earbud for three times                                                                                                | Activate Voice Assistant           |
| <br>X 3 | Tap one earbud for three times<br>*Under the TWS Pairing status or no Bluetooth Connected status or single-ear playing status | Clear pairing list of the earbuds  |
| <br>3"  | Tap and hold on one earbud for three seconds                                                                                  | Game Mode switch*with voice prompt |



## WELCOME GUIDE

\*For safety issue, the product remains low capacity during shipping. Please fully charge the product before initial use!

**AIRBUDS 3**  
OEB-E11D  
True Wireless Earbuds