


Meondrop


MM3A Multimedia Speaker

5-in-1 Multi-function Active 3-inch HiFi Speaker




User Manual


Package list




Primary Speaker (Right Channel) *1



Secondary Speaker (Left Channel) *1




Speaker Interconnect Cable *1



Type-C to Type-A USB Cable*1



Power Cable *1



3.5mm Cable *1



Desktop Foam Pads *2




Manual *1



Guidance Card *1

Should you find any accessories missing or damaged, please promptly contact the seller where you made the purchase.

Interfaces and buttons instruction



Back Panel Interfaces and Button Layout

• Multi-functional Knob:

Rotate: Adjust volume: Facing the knob, clockwise increases volume, counterclockwise decreases volume.

Short press: Cycle through input sources (In the following order: Bluetooth → USB → AUX → TOSLINK → SPDIF).

Long press (approx. 2s): Power on/off.

• Bluetooth Pairing:

Long press (approx. 3s): Blue indicator flashes rapidly to enter Bluetooth pairing mode.

• **USB:** USB-C digital audio input for connecting digital audio output devices supporting UAC 2.0, such as smartphones, computers, and tablets. When connecting to a computer, use the included Type-C to Type-A cable.

• **AUX:** 3.5mm AUX analog audio input for connecting players, DAC/Amps, or other devices with headphone output or Line Out. Volume can still be adjusted via the multi-functional knob when using AUX input.

• **TOSLINK:** Optical digital audio input for connecting devices with optical audio output, such as TVs and gaming consoles.

• **SPDIF:** Coaxial digital audio input for connecting audio devices supporting coaxial audio output.

• **Speaker output:** DIN 4-pin analog audio output. Use the included primary-secondary cable to connect to the secondary speaker.

• **Power Socket:** Connect the included power cable to supply power to the speaker.

Connection

To complete the connection and basic setup of your speakers, please follow these steps:

1. Position the Speakers:

Place the primary speaker (right channel) on your right side and the secondary speaker (left channel) on your left side, ensuring that both speakers face the listener. For optimal stereo imaging, maintain a distance of at least 5 cm between the speakers and the back wall.

You can use the included foam pads or find an optional desktop stand to isolate vibrations and enhance your listening experience.

2. Connect the Speakers:

Use the provided 2m 4-core cable to connect the primary and secondary speakers. Connect the DIN 4P interface of the primary speaker to the corresponding interface of the secondary speaker.

Insert the IEC C13 socket (3-pin) of the power cable into the power interface of the primary speaker, and plug the other end into a power outlet.

3. Select the Input Connection:

To turn on the speaker, press and hold the multi-functional knob for 2 seconds. To switch the input connection mode, press the knob briefly:

• Bluetooth Connection (Blue Indicator):

To initiate a Bluetooth connection, briefly press the Bluetooth button, then long press the Bluetooth pairing button until the blue indicator flashes quickly. Next, enable Bluetooth on your device and select "MOONDROP MM3A" to connect to the speaker.

• USB Connection (White Indicator):

Use the provided Type-C to Type-A cable to connect the speaker to your playback device.

Once connected via USB-C, you can utilize the online interactive DSP function through the WEB UI for balanced PEQ adjustment.

• AUX Connection (Green Indicator):

Connect the speaker to your playback device using the included 3.5mm cable.

• TOPSLINK connection (Red indicator):

Use a qualified optical cable to connect the speaker to your playback device.

• SPDIF connection (Yellow indicator):

Connect the speaker to your playback device using a qualified RCA cable.

4.Unlock more features via MOONDROP APP:

Enhance your experience with the MOONDROP App through a Bluetooth connection. With the app, you can:

- Remotely switch between input sources.

- Select the LHDC Bluetooth format, achieving a transmission rate of up to 990 kbps.

- Toggle between music and game modes.
- Choose from five preset sound effect modes: monitoring, music, games, movies, and customization.
- Utilize the online interactive DSP function for more professional PEQ adjustments.

Important Precautions and Safety Information

Safety Priority: Please read and adhere to the following safety precautions to ensure your safety and the longevity of the product.

Safety Warnings

- Do not allow any liquid to splash or flow into the interior of the speaker, as this may cause a short circuit or permanent damage.
- Avoid using this product in extremely high or low temperatures, or in humid environments.
- Do not touch the surface of the speaker diaphragm. Due to the physical properties of the diaphragm material, it is susceptible to deformation and damage.
- Use only the included power cable. Using an incompatible power cable may pose a safety risk.
- When cleaning, please disconnect the power supply and wipe the speaker with a dry, soft cloth. Avoid chemical solvents or wet cloths.

Suggestions for Use and Maintenance

- Avoid playing at maximum volume for extended periods to prevent damage due to overload.
- Regularly check the interface and cable to ensure a secure connection and proper contact.
- When moving the speaker, handle it gently to prevent collisions or falls.

Troubleshooting

- **Silent:** Check if the power supply is connected, if the volume is set to the lowest level, if the correct input source is selected, and if the audio cable is securely connected.
- **Bluetooth Connection Failure:** Ensure the speaker is in Bluetooth pairing mode (the blue light should be flashing) and verify that the Bluetooth on your mobile device is turned on and that no other devices are connected.
- **No Indicator Light:** Check the power connection and confirm that the socket is functioning properly.

Certification and Environmental Protection

This product has received the following certifications: **3C (China Compulsory Product Certification)**, **CE (European Conformity Certification)**, **FCC (Federal Communications Commission Certification)**, **RoHS (Hazardous Substances Restriction Directive)**, **UKCA (British Conformity Assessment)**, and **KR (Korean Certification)**. It meets safety, environmental protection, and electromagnetic compatibility standards in the relevant regions.

Specifications

Category	Item	Specification
System Specifications	Product Name	MOONDROP MM3A
	Model	MD-SP-007
	Color	White
	Frequency Response	60Hz-20000Hz (-3dB)
	Max SPL	100dBA (200Hz-20kHz)
	THD	THD+N<1%@86dB (1000Hz)
	Bass Extension	Down to 50Hz (-6dB)
	Tweeter	0.65-inch (16mm) silk dome tweeter
	Analog Input Sensitivity	300mVrms

Category	Item	Specification
Driver Configuration	Mid-woofer	3-inch (76mm) aluminum diaphragm
	Passive Radiator	Dual bass passive radiators × 2 (internally concealed)
	Frequency-crossover Technology	4th-order digital crossover @2500Hz
Amplifier & Power	Amp Chip	ACM8625S×2
	Output Power	33W/ch @4Ω (1% THD)
	Power Supply	Built-in 20V 44W switching power supply
	Power Connector	IEC C13 socket (3-pin), 100–240V universal voltage
Input & Connectivity	Wireless Input	Bluetooth 6.0
	Wired Digital Input	USB Type-C (UAC2.0), Optical, Coaxial
	Wired Analog Input	3.5mm AUX
	Speaker Link	DIN 4P interface (primary–secondary speaker connection)
Function & Control	DSP Feature	Software-adjustable PEQ, 5 preset sound modes
	Physical Control	Rotary & Press encoder (power/input/volume)
		Independent Bluetooth pairing button
	App Control	MOONDROP App (source/DSP/sound mode/speaker settings)
Physical Design	Enclosure	Large-radius rectangular plastic housing, 10° tilt design
	Mounting	Freestanding or with optional desktop stand

Security Instructions

Please read this important security instructions before using the equipment.

This information contains general safety information applicable to this device and may include content not applicable to this device. Please follow the warnings and cautions to avoid injury to yourself or others or damage to your equipment.

Warning

***Failure to comply with safety warnings and regulations would result in serious injury or death**

***Do not use damaged power cord or plug or loose power socket**

• Unsafe connections can cause electric leakage or fire.

***Do not use wet hands or other wet body parts to touch the device, power cord, plug or power socket, otherwise it may cause electric shock**

• When unplugging the power cord, do not use too much force, otherwise it may cause electric shock or fire.

***Do not bend or damage the power cord, otherwise it may cause electric leakage or fire**

***Do not operate the device with wet hands while it is charging, otherwise it may cause electric shock**

***Do not directly connect the positive and negative terminals of the charger together, otherwise it may cause a fire or cause serious injury**

***Do not use the device outdoors during a thunderstorm, otherwise it may cause electric shock or equipment failure**

***Use batteries, chargers, accessories and supplies approved by the manufacturer**

• Using universal batteries or chargers may shorten the life of the battery or cause the device to malfunction. They may also cause a fire or cause the battery to explode.

• Only use chargers and data cables specially designed for equipment and approved by MOONDROP. Incompatible chargers and data cables may cause danger or damage the device.

• When customers use accessories or supplies not approved by MOONDROP, MOONDROP is not responsible for the customers' safety.

***Do not put the device in the back pocket or hang it on the waist**

• Excessive force may damage the device, might cause explode or fire.

• If you hit or fall, you may be injured.

***Do not drop the device or subject it to strong impact**

• Otherwise, it may damage the device or battery, cause the device to fail to work normally, or shorten the device life.

• It may also cause overheating, burning or other dangers.

***Handle and dispose of equipment and chargers carefully**

***Do not throw battery or device into fire**

***Do not place batteries or devices in or on heating devices (such as microwave ovens, ovens, or radiators). The device may explode if overheated**

***When disposing of used battery or device, please comply with local regulations**

- **Do not squeeze or pierce the device**
- **Do not subject the device to external high voltage, otherwise it may cause internal short circuit and overheating**
- **Protect equipment, batteries and chargers from damage**
 - Avoid exposing the device and battery to extremely cold or extremely hot temperatures.
 - Extreme temperature can damage the device, reduce the charging capacity of the device, and shorten the service life of the device and battery.
 - Do not use the data cable with the skin peeled off or damaged, and the charger with damaged or not working properly.
- **Do not store device near or in water heaters, microwave ovens, hot cooking equipment, or high-pressure containers**
 - The battery may leak.
 - The equipment may overheat and cause a fire.
- **Do not use or store the device in areas where dust or aeolian materials are concentrated**
 - Dust or foreign objects may cause device damaged, fire or electric shock.
 - Prevent the charger socket and the smaller end of the charger from contacting conductive materials such as liquid, dust, metal powder, or pencil lead.
- **Do not touch with sharp tools. Charger socket; do not bump the charger socket**
 - Conductive materials may short-circuit or corrode the contacts, which may cause explosion or fire.
 - When using a wireless charger, do not place metal objects, magnets, and magnetic stripe cards between the device and the wireless charger. The device may not charge properly or may overheat.
- **Do not bite or suck the device or battery**
 - Otherwise, it may damage the equipment or cause an explosion or fire.
 - Children or animals can suffocate by swallowing small parts.
 - When children use this device, please make sure they use it correctly.
- **Do not poke the device or its accessories into your eyes, ears or mouth, otherwise it may cause suffocation or serious injury**
- **Do not use damaged or leaking batteries. For safe disposal of batteries, please contact the nearest authorized service center**
 - The device and some accessories (sold separately) contain magnets. The American Heart Association and the British Medicines and Health Products Administration also warned that magnets will affect implantable pacemakers, heart rhythm converters, defibrillators, insulin pumps or other electronic medical devices (collectively referred to as "medical devices") within 15 cm. operating. If you are a user of any of these medical devices, please do not use this device and some accessories (sold separately) before consulting a doctor.

Note

- **Failure to comply with safety precautions and regulations can lead to personal injury or property damage**
- **Do not use the device near other electronic devices**
 - Most electronic devices use radio frequency signals. Your device may interfere with other electronic devices.
 - Equipment with speakers is particularly susceptible to interference.
- **Do not use your device in places that may be interfered by radio frequency such as hospitals, airplanes or cars**
 - If possible, use the device beyond 37cm of the pacemaker to avoid interference with the pacemaker.
 - In order to minimize the interference of the device to the pacemaker, please use the device on the side of opposite to the pacemaker.
 - If you use medical equipment, please contact the medical equipment manufacturer before using this device to determine whether it will be affected by the radio frequency emitted by this device.
 - During air flight, the use of electronic equipment will interfere with the airplane's electronic navigator. Follow the airline's regulations and the instructions of the "aircraft crew. If the equipment is allowed, please always use the flight mode."
 - The electronic equipment of the car may malfunction due to radio interference from the equipment. For details, please contact the manufacturer.
- **Do not place the device in a place with dense smoke or fog**
 - Otherwise, the surface of the device may be damaged or the device may malfunction.
 - If you use hearing aids and cochlear implants, please contact the manufacturer for information about radio interference.
 - The radio frequencies emitted by this device may interfere with certain hearing aids and cochlear implants. Before using this equipment, please contact the manufacturer to determine whether the equipment will be affected by the radio frequencies emitted by this equipment.
- **Do not use the device near radio frequency devices or instruments (such as audio systems or radio antenna towers)**
- **Radio frequency may cause device malfunction**
- **Turn off the device in a potentially explosive environment**
 - Always operate in accordance with regulations, instructions and signs in an explosive environment.
 - Do not use the equipment in gas stations or near flammable materials, chemical agents and explosive areas.
 - Do not store or carry flammable liquids, gases or explosive materials in boxes containing device or accessories.
- **If any part of the device is damaged, smokes, or smells of burning things, please stop using the device immediately. The equipment can not be reused until being repaired by the MOONDROP Service Center**
 - Broken glass may hurt your hands and face.
 - If the device emits smoke or the smell of burning things, it may cause the battery to explode or burn.
- **Please observe all safety warnings and regulations regarding the use of equipment while driving.**
- **Driving safely is your primary responsibility while driving. If prohibited by law, please do not use the device while driving. For the safety of you and others, please follow the safety warnings and relevant regulations and remember the following tips:**
 - Place the equipment in an easy-to-access location. No need to look away from the road to get the wireless device.
 - In order to avoid danger, pause the call in traffic jams or bad weather conditions (rain, sleet, snow, ice). Rain and sleet, snow, ice and heavy traffic can cause danger.
 - Do not record voice memos. Recording a language memo while driving prevents you from focusing on the primary responsibility of driving safely.
 - According to the traffic situation, decide whether to answer the call reasonably. Answer calls when not moving forward or in traffic jams. Try to call after parking.
 - Do not engage in nervous or excited conversations to avoid distraction. Please let the caller know that you are driving.
- **Properly maintain and use equipment**
 - Keep the equipment dry.
 - Moisture and liquid can damage equipment parts or circuits.
 - Do not turn on the device when it is wet. If the device is turned on, turn it off (if the device cannot be turned off, please maintain the status quo). Then dry the equipment with a towel and contact the local MOONDROP service center.
 - This equipment is equipped with a built-in liquid indicator. Water damage to the equipment will invalidate the manufacturer's warranty.
- **The device should be stored on a flat ground**
- **If the device falls, it will be damaged**
 - The device can be used where the atmosphere temperature is between 0°C and 35°C. You can store the device where the ambient temperature is between -20 °C and 50 °C. Using or storing the device outside the recommended temperature range may cause damage to the device or shorten battery life.
 - Do not store the device in extremely hot areas, such as in a car in summer, otherwise, the equipment may be damaged or the battery may explode.
 - Do not expose the device to direct sunlight for a long time, such as on the dashboard of a car. Do not store the device with metal objects such as coins, keys and necklaces.

- The device may be scratched or malfunction.
- If the battery contacts come in contact with metal objects, it may cause a fire.
- **Do not store the device near magnetic fields**
 - When exposed to a magnetic field, the device may malfunction or the battery may discharge.
 - Magnetic stripe cards (including credit cards, phone cards, bank books and boarding cards) may be damaged by magnetic fields. Avoid contact with the device when it is overheated.
- **Otherwise it may cause low temperature burns, redness and skin pigmentation**
 - After using the device for a long time, pay attention to the heating of the device and avoid contact with the skin for too long.
 - Do not sit on the device, or keep in direct contact with your skin for a long time while the device is charging or connected to the power source.
 - High temperature resistance varies from person to person. Please pay special attention when using it by children, the elderly.
- **Protect hearing and ears when using earplugs**
 - Excessive exposure to strong sounds can cause hearing loss.
 - Always turn down the volume before using earplugs, and use only the lowest volume required to listen to conversations or music.
- **Precautions for using the device during walking or moving**
 - Always pay attention to your surroundings to avoid harming yourself or others.
- **Do not paint or paste paper on the equipment**
 - If you are allergic to the paint or metal parts of the device, it may cause itching, eczema or swelling of the skin. When the above situation occurs, please stop using the device and consult a doctor.
- **Install the device cautiously**
 - Do not place equipment and accessories in or near the airbag deployment area. If the equipment is improperly placed, the airbag inflates rapidly, which can cause serious injury.
- **Do not drop the device or cause collision**
 - The device may be damaged or malfunction.
 - If the device is bent or deformed, it may damage the equipment or cause parts malfunction.
- **Ensure the longest service life of the battery and charger**
 - If the battery is not used for a long time, the battery may malfunction.
 - The equipment will discharge if left unused for a long time, and must be recharged before use.
 - When the equipment is not in use, disconnect the power supply.
 - The battery can only be used for the designated purpose.
 - Follow all the instructions in this manual to ensure the longest service life of the device and battery. The manufacturer will not provide warranty for damage or poor performance caused by failure to follow the warnings and instructions.
 - The equipment may wear out over time. Although some parts and repairs are guaranteed during the validity period, damage or deformation caused by the use of unapproved accessories is not covered by the warranty.
- **Do not disassemble, modify or repair the equipment**
 - Any changes or modifications to the equipment will cause the manufacturer to not guarantee the equipment. For repairing, please contact your local MOONDROP authorized dealer.
 - Do not disassemble or pierce the equipment, as this may cause an explosion or fire.
 - Do not disassemble or reuse the battery.
- **When cleaning the equipment, please follow the following advices**
 - Use a soft and dry cloth to wipe the device, use a brush or other tools to remove the earwax or dirt on the earpiece.
 - Clean the battery contacts with a dry cloth.
 - Do not use chemicals or cleaning agents. Otherwise, the surface of the equipment may be discolored or corroded, and it may also cause electric shock or fire.
 - Prevent the equipment from contact with dust, sweat, ink, oil, and chemical products (such as cosmetics, antibacterial sprays, hand sanitizers, detergents and insecticides). Otherwise, the internal and external parts of the device may be damaged, or the performance may deteriorate. If the device comes into contact with any of the above-mentioned substances, please wipe it with a soft, lint-free cloth.
- **Do not use the device for any purpose other than the designated purpose**
 - The device may malfunction.
 - Avoid disturbing others when using the device in public places.
- **Only qualified personnel are allowed to repair the device**
 - If the equipment is repaired by unqualified personnel, the equipment may be damaged and the warranty will not be provided.
- **Do not distribute copyrighted content**
 - Do not distribute copyrighted material without the permission of the content owner. This behavior violated copyright law. The manufacturer is not responsible for any legal problems caused by any illegal actions by users against copyrighted content.

Disclaimer

All content and services available through this device belong to third parties and are protected by copyright, patents, trademarks and other intellectual property laws. Such content and services are only for personal non-commercial use. Without the permission of the content owner or service provider, you may not be able to use any content or service. In addition to the above restrictions, unless you have the explicit permission of the application content or service provider, you may not be able to modify, copy, republish, upload, post, transmit, translate, or repost, any content or service displayed through this device. sell, create new derivative works, develop or distribute in any way.

Third-party content and services are provided. For any purpose, MOONDROP Company does not provide any express or implied guarantees for the content or services provided. MOONDROP Co. expressly declares that it does not assume any implicit guarantees, Or through regulations, common law, or other means (including but not limited to marketability or applicability for specific purposes) recognized terms or conditions. In any case (including negligence), any content or service provided through this device, Even if it has been notified in advance that there is a possibility of such damage, whether it is in contract or tort, any direct, indirect, accidental, special or corresponding loss or damage compensation costs, attorney fees, various expenses or any resulting For other losses or damages, or connecting any information contained, or the results caused by you or any third party using any content or service, MOONDROP Co. does not guarantees for its accuracy, validity, timeliness, legality or completeness."

Third-party services may be stopped or interrupted at any time, and MOONDROP Co. is not responsible or guarantees for any content or the time period during which the service is available. The content and services are transmitted by third parties through networks and transmission equipment outside the control of MOONDROP. In addition to the generality of the exemption clause, MOONDROP also expressly stated that it does not assume any responsibility or obligation for any interruption or delay of any content or service applicable to this device.

MOONDROP Co has neither responsibility nor obligation for customer service involving content and services. Any service requirements related to content or services should be directly borne by the content and service providers.

ISED Warning statements

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.

2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC Warning statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Content of hazardous substances in products

Name	Hazardous substances and elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent (Cr (VI))	Polybrominated biphenyls (PBB)	Poly Australian Diphenyl Ether (PBDE)
Circuit components	X	O	O	O	O	O
Metal parts	O	O	O	O	O	O
Plastic parts	O	O	O	O	O	O
Speaker	O	O	O	O	O	O
Battery	X	O	O	O	O	O
Annex	X	O	O	O	O	O

This form is compiled in accordance with SJ/T 11364.
 O: Indicates that the amount of the hazardous substance in all homogeneous materials of the part is below the limit requirement specified in GB/T 26572-2011. X: Indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds the limit requirement specified in GB/T 26572 2011, and there is currently no mature alternative in the industry. Please handle such parts or substances properly to avoid impact on the environment and human.



This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and any part of your body.

This equipment complies with ISED RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

Pour se conformer aux exigences de conformité CNR 102 RF exposition, une distance de séparation d'au moins 20 cm doit être maintenue entre l'antenne de cet appareil et toutes les personnes.

After-sales Policy

☆If the product has a non-man caused failure from the date of shipment, it can be returned within in 7 days, replaced within 15 days and repaired free of charge within 12 months. If the damage is caused due to improper use, paid repair service will be provided depending on the condition.

☆If this device is damaged and meets the warranty conditions, please contact the seller to return it under the guidance of the seller by completing the device after-sales list, and attaching it to this device, package, and purchase receipt.

☆This device is a precise electronic product, please avoid putting it in damp, dust and high/low temperature as well as avoid pulling, collision, and squeezing, to prevent unnecessary damage, which will invalidate the warranty.

☆Cable breakage, shell deformation, water damage, dust, corrosion or pins broke, tuning material, and unit damage, are out of warranty.

☆If warranty service cannot be provided due to product iteration and upgrades, the following after-sales procedures shall apply:

1. Customers with products still under warranty will qualify for a free replacement with an equivalent or lower-priced product.
2. For products beyond the warranty period, customers may exchange for an equivalent or lower-priced product upon payment of applicable service fees.

3. The specific warranty period will be determined based on the original purchase date.

☆If the product has expired the warranty period, and due to product replacement, our company may not be able to provide repair service.

☆We will not be able to provide repair service if the device shell or core parts are seriously deformed due to external force.

☆The after-sales service period is generally 7-20 days (excluding transportation time), depending on the repair department.

☆About warranty period after repair/replacement:

☆If the cause of the product issue is confirmed as poor build quality by MOONDROP after-service center, the warranty period will be prolonged to 60 days from the completion date of repair/replace if it was less or equal to 60 days; otherwise, it will stay as the original warranty period.

Warranty Card

☆For after-sales service, please refer to [After-sales Terms].

Fault description:

.....

Purchase date:

Receiving Address:

.....

Customer Name:

Contact phone:

