

DL-TWS-001 User Manual	Package list (The pictures are for reference only, please refer to the actual products.) Charging case *1 Earbuds *2(pair) Charging cable *1 Earbuds **2(pair) Manual	Introduction	Manual Turn on Turn on the earbuds is automatically turn on after coming with Power On prompt. Turn off 1. In the case, it will turn off after putting the earbuds back into the charging case. 2. Over time turn-off: it will turn off if there is no paired device within 3 minutes. 3. Low-battery turn-off: it will turn off if the battery is low. You'll hear the prompt of Power Off.	Manual Restore factory setting Be sure the earbuds is unconnected and is searching Bluetooth, simultaneously long press the right/left earbuds for 10s to clean paired information and restore the factory setting.	Manual Charging Put the earbuds in the charging case to feed power to the earbuds. The earbuds state of charging: When charging, the white indicator is always on until the prompt of Connected appears out. The case state of charging: When charging, the orange indicator is always on. 1. Fully charging: LED indicator goes out. Tip: The charging case state is given priority when charging both earbuds and the case.	Connection Bluetooth pairing Entering the Bluetooth interface to find DL-TWS-001, click the prompt of Pairing. There is warning of "You Du Du" under pairing mode. You'll hear the prompt of Connected. Disconnection 1. Over-distance disconnection: The earbuds will be automatically disconnected if beyond the effective working distance, you'll hear the prompt of Disconnect. 2. Manually disconnection: Under the connected state (non-working state), simultaneously long press the Touch of	Connection Right and Left for 3s, disconnect the current device. Or manually turn off the Bluetooth device to disconnect. The earbuds will enter into the pairing mode prompt disconnected, DL-TWS-001 allows pairing with other devices. <td data-bbox="2562 718 2803 740"> Connection the last paired device when taken it out from the charging case. Please put the earbuds back in the charging port if there is one earbud quit and disconnecting, and try to reconnect the prompt of Transparency mode is High. <td data-bbox="2803 718 3041 740"> Function Operation Press the earbuds. Click the left/right earbud 3 times to start, and click to exit. *Note of Android: Interference between the "Headset voice" and "Voice assistant" will occur when wearing the "Headset voice". Music The prompt of noise-cancelling is 5h. The prompt of regular mode is 5h. The prompt of Transparency mode is 5h. Call Answer: Click the left/right earbud. Decline: Long press left/right earbud for 1.5s. Hang up: Click the left/right earbud. Third-party call: Click the left/right earbud, keep the original call and answer the new call. Switch the call: Double-click the left/right earbud. </td> <td data-bbox="3041 718 3283 740"> Function Noise-cancelling mode In the turn-on state, Long-press Right/left for 1s to switch the mode. The prompt of noise-cancelling is 5h. The prompt of regular mode is 5h. The prompt of Transparency mode is 5h. Low-latency Mode In the turn-on state, click the right/left earbud for 4 times to switch mode. The prompt of game: Game Mode. The prompt of game: Music Mode. </td> <td data-bbox="3283 718 3500 740"> product Specifications Product Model: DL-TWS-001 Distribution Version: 1.3 Codes: AAC / SBC Audio Distribution Profile: A2DP/ACR/HFP/HSP/HSP/5BC/AAC Bluetooth Range: >10 meters (Open environment) Battery Life: 40(phone)+20(Case)/hours </td> </td>	Connection the last paired device when taken it out from the charging case. Please put the earbuds back in the charging port if there is one earbud quit and disconnecting, and try to reconnect the prompt of Transparency mode is High. <td data-bbox="2803 718 3041 740"> Function Operation Press the earbuds. Click the left/right earbud 3 times to start, and click to exit. *Note of Android: Interference between the "Headset voice" and "Voice assistant" will occur when wearing the "Headset voice". Music The prompt of noise-cancelling is 5h. The prompt of regular mode is 5h. The prompt of Transparency mode is 5h. Call Answer: Click the left/right earbud. Decline: Long press left/right earbud for 1.5s. Hang up: Click the left/right earbud. Third-party call: Click the left/right earbud, keep the original call and answer the new call. Switch the call: Double-click the left/right earbud. </td> <td data-bbox="3041 718 3283 740"> Function Noise-cancelling mode In the turn-on state, Long-press Right/left for 1s to switch the mode. The prompt of noise-cancelling is 5h. The prompt of regular mode is 5h. The prompt of Transparency mode is 5h. Low-latency Mode In the turn-on state, click the right/left earbud for 4 times to switch mode. The prompt of game: Game Mode. The prompt of game: Music Mode. </td> <td data-bbox="3283 718 3500 740"> product Specifications Product Model: DL-TWS-001 Distribution Version: 1.3 Codes: AAC / SBC Audio Distribution Profile: A2DP/ACR/HFP/HSP/HSP/5BC/AAC Bluetooth Range: >10 meters (Open environment) Battery Life: 40(phone)+20(Case)/hours </td>	Function Operation Press the earbuds. Click the left/right earbud 3 times to start, and click to exit. *Note of Android: Interference between the "Headset voice" and "Voice assistant" will occur when wearing the "Headset voice". Music The prompt of noise-cancelling is 5h. The prompt of regular mode is 5h. The prompt of Transparency mode is 5h. Call Answer: Click the left/right earbud. Decline: Long press left/right earbud for 1.5s. Hang up: Click the left/right earbud. Third-party call: Click the left/right earbud, keep the original call and answer the new call. Switch the call: Double-click the left/right earbud.	Function Noise-cancelling mode In the turn-on state, Long-press Right/left for 1s to switch the mode. The prompt of noise-cancelling is 5h. The prompt of regular mode is 5h. The prompt of Transparency mode is 5h. Low-latency Mode In the turn-on state, click the right/left earbud for 4 times to switch mode. The prompt of game: Game Mode. The prompt of game: Music Mode.	product Specifications Product Model: DL-TWS-001 Distribution Version: 1.3 Codes: AAC / SBC Audio Distribution Profile: A2DP/ACR/HFP/HSP/HSP/5BC/AAC Bluetooth Range: >10 meters (Open environment) Battery Life: 40(phone)+20(Case)/hours
--	---	--	--	---	---	---	--	---	--	---	---

[illegible][illegible][illegible]