

BTX10 - Portable Wireless Travel Speaker
User Manual - Black and White Printing

4.65 in

4.65 in

SPECIFICATIONS

Bluetooth® Version : 5.3
Working Distance : 30FT (10M)
Battery Capacity : 300 mAh
Playtime at 70% Volume : About 2 Hours
Charging Time : About 2 Hours
Speaker Size : 52 mm
Power Rating : 3W
Product Size : 125*40*85mm
Charging Port : USB Type-C

WARNING

This product is for indoor use only. This device is not a toy and should be kept away from children. The product must not be dropped or subjected to intentional impact. Do not use the device in humid environments or in extremely hot / cold temperatures. Do not use chemicals or abrasive detergents to clean the product. Please return for repairs if the product is defective. The warranty is invalid if the product has metal rust, water damage, or other natural oxidation.

WARRANTY

This product has a 1 year warranty against defects in manufacturing under regular consumer use. For instructions about how to obtain warranty service for your product, please contact Customer Service: info@primebrandsgroup.com.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. This product is compatible with all wireless audio devices, Bluetooth® and non-Bluetooth®.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



©2025 Prime Brands Group. All rights reserved.
All trade names are registered trademarks of the respective manufactures listed. Made in China.
Prime Brands Group • Brooklyn, NY 11232 • SHOPSOAR.COM

SOAR PORTABLE WIRELESS TRAVEL SPEAKER


USER MANUAL Wireless Bluetooth Speaker
Model: BTX10

Thank you for choosing the SOAR Portable Wireless Travel Speaker. The ultimate companion for fans who want to represent their team everywhere! This compact, powerful speaker is designed for both style and performance. Whether you're at the beach, the gym, on a hike, or just relaxing at home, this speaker delivers rich, high-quality sound to keep you pumped up.

Includes: Portable Wireless Travel Speaker,
USB-C Charging Cable, and User Manual

PRODUCT KEY

1. Secure Travel Loop
2. LED Indicator Light
3. Power Button
4. Volume Down / Previous Track Button
5. Play / Pause Button
6. Volume Up / Next Track Button
7. USB-C Power Input
8. Call Control Button
9. Microphone



OPERATION

Fully charge your Portable Wireless Travel Speaker before use. Plug the provided USB-C charging cable into the charging port (7) on your speaker, and connect the other end to a suitable 5V power outlet. The LED charging indicator light (2) will turn off when charging is complete.

To power on, press and hold the Power Button (3). The LED Indicator Light (2) will blink to signal your speaker is in pairing mode. From your audio device's Bluetooth® menu, search for the pairing name "BTX10". When selected, the speaker will say "Device is connected." and the LED Indicator Light (2) will remain on, showing a successful connection.

Tap the Play / Pause Button (5) to play or pause your music or video.
To sync two speakers for dual-channel sound, turn on both devices. Then press and hold the Play/Pause Button (5) on one speaker to start automatic pairing.

Tap the Volume Down / Previous Track Button (4) to decrease the volume.
Press and hold Volume Down / Previous Track Button (4) to skip to the previous track.
Tap the Volume Up / Next Track Button (6) to increase the volume.
Press and hold the Volume Up / Next Track Button (6) to skip to the next track.

To handle calls: Press the Call Control Button (8) to answer or end an incoming call. Double-tap the Call Control Button (8) to redial the last incoming number.

Back

Front