

SHRP-HP01 - Soundhaven : Wireless Headphones

User Manual - Black and white printing



Keep it away from children. This product is not a toy. Do not throw this product to avoid any damage. Do not disassemble, repair or reform this product. Do not clean this product with any chemical solvents. For charging, please use a charger with DC 5V input. Keep or use this product at normal temperature. Do not throw it away or expose it to temperature above 60°C / 140°F or fire to avoid any danger. Clean only with dry cloth. Dispose the device properly at the end of its life cycle. The warranty is invalid if the product has metal rust, water damage, or other natural oxidation.

Dispose of batteries responsibly and be aware of the environmental effects of battery disposal. Do not expose the batteries (installed) to excessive heat, such as fire or the like

To prevent possible hearing damage, do not listen at high volume levels for long periods. For your own safety, please be aware of your surroundings when using these headphones.

This product has a 1 year warranty against defects in manufacturing under regular consumer use. For instructions about how to obtain warranty service for your product, please contact Customer Service: info@primebrandsgroup.com.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. This product is compatible with all wireless audio devices, Bluetooth®.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

⚠️ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov



©2026 Prime Brands Group. All rights reserved. All trade names are registered trademarks of the respective manufactures listed. Made in China.
Prime Brands Group • Brooklyn, NY 11232 • **SHOPSOAR.COM**

Sharper Image® name and logo (Including the 77 logo) are trademarks or registered trademarks. Distributed by ©2026 Prime Brands Group, INC. Brooklyn, NY 11232. All rights reserved. For Technical Support, Please visit www.shopsoar.com. Colors and styles may vary. Before use, read all warnings found in the included instruction manual or refer to our website www.primebrandsagroup.com for more information.

SOUNDHAVEN 2




USER MANUAL

Thank you for choosing the Sharper Image SoundHaven 2 Headphones. Engineered with advanced noise cancellation, powerful battery life, and premium comfort, they're designed to elevate every listening experience. This guide will help you get started quickly and make the most of every feature. Enjoy exceptional sound wherever you go.

Includes:
SoundHaven 2 Wireless Headphones, USB-A to USB-C Charging Cable, Hard Shell Travel Case, User Manual

1. LED Indicator
2. Volume Up
3. Power Button
(Multi-function)
4. Volume Down
5. Charging Port
6. Noise Control
LED Indicator
7. Noise Control
Button
8. Microphone



- Driver size: 40 mm
- Impedance: 32 Ω
- Frequency response: 20 Hz – 20 kHz
- Listening modes: ANC On, ANC Off, Transparency
- Low Latency Mode: Yes

Microphone System

- 4-microphone hybrid ANC system
- 2 inward-facing feedback microphones
- 1 outward-facing feed forward microphone
- 1 hybrid call microphone

- Bluetooth® version: 6.0
- Wireless range: up to 15 m
- Chipset: JL7018
- Voice assistant support: Siri & Google Assistant

- Battery: 500 mAh lithium-polymer
- Playtime with ANC On: up to 32 hours
- Playtime with ANC Off: up to 55 hours
- Fast charge: 10 minutes = 3 hours (ANC On) / 4 hours (ANC Off)
- Charging Input: 5V (USB-C)

Power On: Press and hold the Power Button (Multi-function) (3) to turn on the headphones. You will hear a voice prompt: "Power ON."

Pairing Mode: The headphones automatically enter pairing mode when powered on for the first time. The LED indicator (1) will blink, and you'll hear "Pairing." On your device, select "SHRP-HP01" from the Bluetooth menu. Once connected, the LED will turn solid and you'll hear "Connected." The headphones will automatically pair with the last connected device the next time they are powered on. To pair with a new device, press and hold the Power Button to turn off the headphones. Then, press and hold the Power Button for 5 seconds to turn on and re-enter pairing mode.

Battery Voice Prompts: Battery Full: 100%–80%, Battery Medium: 70%–30%, Low Battery: less than 20%

BUTTON	FUNCTION
	Press to increase volume. Press and hold to skip track.
	Press once to Play, Pause, or Answer / End a phone call. Press twice to activate Siri or other voice control software. Press and hold 2 seconds to reject incoming calls. Press and hold to power on or off.
	Press to decrease volume. Press and hold to play previous track

Press the Noise Control Button (7) to toggle through the three listening modes. ANC On actively blocks out external sounds for an immersive experience. Transparency Mode lets ambient sounds in, keeping you aware of your surroundings. ANC Off disables both noise cancellation and transparency, providing standard listening. A single press of the button cycles through these three modes.

For real-time audio applications, such as gaming or video, the Low Latency Mode reduces audio delay for smoother playback. To toggle Low Latency Mode on or off, double-press the Noise Control Button (7) while the headphones are connected.

The SoundHaven 2 supports connecting to two devices simultaneously, such as a smartphone and a laptop. After the first device is connected, turn off Bluetooth on that device—the headphones will automatically enter pairing mode. On your second device, go to Bluetooth settings and connect to the headphones. Finally, re-enable Bluetooth on the first device and reconnect to the headphones. Both devices are now connected and can be used interchangeably.

To charge your SoundHaven 2, insert the included USB-C charging cable (or a compatible USB-C cable) into the USB-C Charging Port (5). Connect the other end to a USB 5V/1A power source, such as a laptop, wall charger, or car charger.

The LED Indicator Light (1) will turn on when the battery is low and remain on while charging. It will turn off once the battery is fully charged. To help preserve battery life, unplug the headphones when charging is complete.

Before performing a factory reset, make sure to forget “SHRP-HP01” from your device’s Bluetooth settings. With the headphones powered off, press and hold the Power Button (3) for 5 seconds until the LED flashes blue and red. Then, press and hold the + (2) and – (4) buttons simultaneously for 10 seconds until the red LED flashes three times. The headphones will power off automatically and have been restored to factory settings.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.