

SHRP-ANC - Airwaves Wireless Headphones
User Manual - Black and white printing

6 in

4 in

4 in

with dry cloth. Dispose the device properly at the end of its life cycle. The warranty is invalid if the product has metal rust, water damage, or other natural oxidation.

WARRANTY

This product has a 1 year warranty against defects in manufacturing under regular consumer use. For instructions about how to obtain warranty service for your product, please contact Customer Service: info@primebrandsgroup.com.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. This product is compatible with all wireless audio devices, Bluetooth® and non-Bluetooth®.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

PB GROUP ©2026 Prime Brands Group. All rights reserved. All trade names are registered trademarks of the respective manufactures listed. Made in China.
Prime Brands Group • Brooklyn, NY 11232 • **SHOPSOAR.COM**

Sharper Image® name and logo (Including the 77 logo) are trademarks or registered trademarks. Distributed by ©2026 Prime Brands Group, INC. Brooklyn, NY 11232. All rights reserved. For Technical Support, Please visit www.shopsoar.com. Colors and styles may vary. Before use, read all warnings found in the included instruction manual or refer to our website www.primebrandsgroup.com for more information.

SHARPER IMAGE®

LANTERN SPEAKER

SHRP-LAN

USER MANUAL

Thank you for choosing the Sharper Image Lantern Speaker. This portable device brings together cozy, warm LED lighting and crisp Bluetooth audio, letting you create the perfect ambiance wherever you go. Whether you're relaxing at home or enjoying the outdoors, your new lantern speaker is ready to brighten your space and fill it with sound.

Includes:
Lantern Speaker, USB-C to USB Charging Cable, & User Manual

PRODUCT KEY

1. Volume Increase Button

2. Power Button

3. Volume Down / LED Light Button

4. USB-C Power Input



SPECS

Bluetooth version : JL V5.3

Horn specifications : 45mm 4Ω 3W

Battery capacity : 500mAh

Play time : about 6H at 50% volume.

Charging time : about 2H

Lighting effect : warm color with 3 brightness

PAIRING

To connect your Lantern Speaker to a Bluetooth enabled device, first power on the speaker by pressing and holding the Power Button (2) until the indicator light turns on. On your phone, tablet, or other audio player, navigate to the Bluetooth settings and search for available devices. Select "SHRP-LAN" from the list to pair. Once paired, the speaker will automatically connect to that device in the future when powered on and within range.

CHARGING

Before using your Lantern Speaker for the first time, charge it fully to ensure optimal performance. Connect the included USB-C charging cable to the speaker's USB-C port (4) and plug the other end into a 5V 2A USB power source. While charging, the indicator light will show the charging status. Once fully charged, unplug the cable to preserve the battery's longevity.

FUNCTION AND OPERATION

BUTTON	FUNCTION
+	Press to increase the volume.
○	Press to power the speaker on or off.
☀	Press to decrease volume. Press twice to cycle through the three LED brightness levels. Press and hold to turn the LED light on or off.

WARNING

Keep it away from children: this product is not a toy. Do not throw this product to avoid any damage. Do not disassemble,repair or reform this product. Do not clean this product with any chemical solvents. For charging,please use a charger with DC 5V input. Keep or use this product at normal temperature. Do not throw it away or expose it to temperature above 60°C / 140°F or fire to avoid any danger. Clean only