

VIBE BLUETOOTH SPEAKER
USER'S MANUAL



MODEL: Vibe
VERSION: V-01

1

Introduction:

Thank you for choosing Vibe Bluetooth speaker. This product supports smartphones, tablets, laptops and other Bluetooth enabled devices.

This product is tested to be IPX7 waterproof and dust-proof. It can work under 0.15-1 meter underwater for 30 minutes, and it is not affected by water splashes or rain in a limited time.

Please note the Bluetooth speaker is not waterproof when the silicone cover is opened. Please ensure that the silicone cover is closed under wet and splashing conditions.



2

Description:

- ① Pulsing Light
- ② Microphone
- ③ TWS Mode Button
- ④ Light Mode Button
- ⑤ Power ON/OFF Button
- ⑥ Volume Down-/ Previous Track Button
- ⑦ Volume UP+/ Next Track Button
- ⑧ AUX IN Port
- ⑨ Reset Button
- ⑩ Type-C Charging Port
- ⑪ Type-C Charging Cable
- ⑫ 3.5mm AUX IN Cable

Specification:

Bluetooth Version: 5.0
Bluetooth Receiving Range: 10M
1.75in 10W mid-bass
Product Size: 82.5*82.5*130mm
Battery Capacity: 3.7V/3350mAh
Input: 5V/2A

Bluetooth:

Pair: The device name Vibe will be displayed when it is searched and connected for the first time. After the speaker is turned on, it will automatically search for the last connected device. When the Bluetooth is connected, you will be prompted.Or it will enter pairing

3

mode when the last connected device is not found in 10 seconds. The white LED light flashes quickly in the disconnected state, and the speaker will automatically turn off when the Bluetooth is not connected for 10 minutes;

Reconnect: when the connection distance is exceeded, the speaker will reconnect automatically when back in the connection distance within 10 minutes, and automatically turn off after 10minutes.

Disconnect: when connected, long press TWS button to clear the paired Bluetooth, you will be prompted with "disconnected", then the speaker will start to research devices.

Note: Clear the paired Bluetooth will not affect the TWS connection.

Button:

Power ON/OFF Button: Turn Off State: Long press 2s turn on the device, the startup voice prompts, LED ambient light is on, the white LED light flashes quickly to enter the Bluetooth standby state.

Turn On State: Long press 2s turn off the device, the voice prompts and LED ambient light is off.

Incoming Call Status: Press the ON/OFF Button to answer the call.

Call Status: Press the power button to hang up the call;

Music Status: Press the power button to pause/play.

“+”: Press volume“+” button to turn up the volume, long press to switch to the next track.

“-”: Press volume “-” buttonto turn down the volume, long press to switch to the next track.

Light Mode Button: Press the light button to switch to the light mode, long press to turn on/off the light.

4

TWS: After the Bluetooth is connected, press the TWS button to turn on the TWS interconnection function to connect with the same other product. When two identical Bluetooth products are interconnected, stereo music will be played at the same time, one is L channel, the other is R channel;

Note: The other speaker that is to be connected with TWS can only be paired when its Bluetooth is not connected.

TWS Turn Off State: Press TWS button, the indicating white light is on, the voice prompts the devices connected successfully.

TWS Turn On State: Press TWS button, the indicating white light is off, the voice prompts the devices disconnected.

Power-on State: 1. Long Press to clear the paired Bluetooth;
2. Press twice to announce the current battery level.

AUX: Connect the speaker with 3.5mm AUX IN cable, the mode will be automatically switched to AUX. You can only adjust the volume and turn the speaker on/off under AUX mode.

Reset Button: When the speaker was crashed, please use a pointed object to push it in the reset button to restart the speaker

Charging:

Support Type-C 5V/1A charging, the charging time is 2.5H, the red light in the charging state is long on, and the red light is off when it is fully charged. You will be prompted when battery is low to 20%, please charge your speaker when you hear the low battery prompt.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable

5

protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

What's in the Box:

- 1) Speaker
- 2) Type-C Charging Cable
- 3) 3.5mm AUX IN Cable
- 4) User's Manual

6