






LOW-PROFILE BLUETOOTH FM TRANSMITTER  USER MANUAL MODEL: VM-201 VERSION: V01-24-8																																					
	Features -Hands-free calling with built-in microphone -Bluetooth connection to mobile device (A2DP) -Comes with USB-A charging port -Supports Bluetooth, Aux in, Micro SD card and flash drive -Display FM station -Car battery voltage display	Overview Microphone Display FM Setting Previous Flash Drive USB Function Switch Answer/Volume +/- Next Micro SD Card Aux In Audio cable																																			
			Controls <table><thead><tr><th>Buttons</th><th>Action</th><th>Behaviors</th></tr></thead><tbody><tr><td rowspan="2">“CH”</td><td>Press</td><td>Enter FM Station Setting</td></tr><tr><td>Press for 3 seconds</td><td>Change playlist</td></tr><tr><td rowspan="2">“M”</td><td>Long press</td><td>Enter EQ Mode</td></tr><tr><td>Press</td><td>Change source</td></tr><tr><td rowspan="5">“📶”</td><td>Rotation</td><td>Setting FM frequency; Adjust volume during playback</td></tr><tr><td>Press</td><td>Answer/End the call; Pause/Play Music</td></tr><tr><td>Press Twice</td><td>Call Back</td></tr><tr><td>Press for 3 seconds</td><td>Reject the call</td></tr><tr><td>Press for 5 seconds</td><td>Screen off/on</td></tr><tr><td>“⏮”</td><td>Press</td><td>Previous Track; Frequency adjustment 0.1MHz</td></tr><tr><td>“⏭”</td><td>Press</td><td>Next Track; Frequency adjustment 0.1MHz</td></tr></tbody></table>	Buttons	Action	Behaviors	“CH”	Press	Enter FM Station Setting	Press for 3 seconds	Change playlist	“M”	Long press	Enter EQ Mode	Press	Change source	“📶”	Rotation	Setting FM frequency; Adjust volume during playback	Press	Answer/End the call; Pause/Play Music	Press Twice	Call Back	Press for 3 seconds	Reject the call	Press for 5 seconds	Screen off/on	“⏮”	Press	Previous Track; Frequency adjustment 0.1MHz	“⏭”	Press	Next Track; Frequency adjustment 0.1MHz	Operation 1. Insert device into 12/24V DC port. Display shows FM station, Bluetooth indicator flash.  2. Turn on vehicle radio. Select unused FM station (FM 88.1 to 107.9). (Note: If sound quality is poor try another unused FM station.) 	Press - “📶” to enter FM station setting - “⏮” / “⏭” +/- by 0.1MHz - “M” for confirmation  	SELECT SOURCE (BLUETOOTH, AUX INPUT, FLASH DRIVE, MICRO SD CARD) Pair Device First-time setup: - Power On - Bluetooth indicator flashes in “Pairing Mode” - Connected to “VM-201” on smartphone - Voice confirmation of successful connection 	CONTROLS “⏮” / “⏭” Go back/ Skip song “📶” Pause / Play “M” =Change source MP3/WMA/WAV/FLAC Supported When playing songs from Micro SD card or USB flash drive, long press “⏮” / “⏭” to change folder. Note: It will automatically enter Micro SD card or Flash drive mode when connecting, and automatically return to Bluetooth mode after it is removed. Important: Use source device for AUX input track controls.
Buttons	Action	Behaviors																																			
“CH”	Press	Enter FM Station Setting																																			
	Press for 3 seconds	Change playlist																																			
“M”	Long press	Enter EQ Mode																																			
	Press	Change source																																			
“📶”	Rotation	Setting FM frequency; Adjust volume during playback																																			
	Press	Answer/End the call; Pause/Play Music																																			
	Press Twice	Call Back																																			
	Press for 3 seconds	Reject the call																																			
	Press for 5 seconds	Screen off/on																																			
“⏮”	Press	Previous Track; Frequency adjustment 0.1MHz																																			
“⏭”	Press	Next Track; Frequency adjustment 0.1MHz																																			

						</	

型号：VM-201

材质：120g双铜纸

印刷：四色双面印刷

成品尺寸：72*105MM

展开尺寸：576*105MM

折页方法：风琴折