


DOG TRAINING COLLAR



USER MANUAL
MODEL: TT11



CONTENT

I. Important Safety Information	01
II. Package Content	02
III. Product Overview	03
IV. Quick Start Guide	04
V. Setting Up	07
VI. Training Modes	09
VII. Fitting the Receiver	13
VIII. Pairing Up	14
IX. LCD Display & Indicator Definitions	17
X. Training Tip	18
XI. Frequently Asked Questions	19
XII. Trouble Shooting	21
XIII. FCC Statement	21





ÍNDICE

I. Información De Seguridad Importante	23
II. Contenido Del Paquete	24
III. Descripción Del Producto	25
IV. Guía De Inicio Rápido	26
V. Configuración	30
VI. Modos de Entrenamiento	32
VII. Ajuste Del Receptor	35
VIII. Emparejamiento	36
IX. Definiciones De Pantalla LCD e Indicadores	40
X. Consejo de entrenamiento	41
XI. Preguntas Frecuentes	42
XII. Solución de Problemas	43



I. Important Safety Information:

WARNING

Not for use with aggressive dogs. Do not use this product if your dog is aggressive or prone to aggressive behavior. Aggressive dogs can cause severe injury and even death to their owner and others. If you are unsure whether this product is appropriate for your dog, please consult your veterinarian or a certified trainer.


- ◆ For use with dogs over 6 months of age and over 8 lbs.
- ◆ **DO NOT** use when the dog or the collar is wet.
- ◆ **DO NOT** press and hold shock or vibrate for more than 10 seconds to avoid physical or psychological damage to your dog.
- ◆ Your dog **SHOULD NOT WHINE OR PANIC** when receiving stimulation. If this happens, the stimulation level is too high and you need to go back to the previous level and repeat the process.
- ◆ **DO NOT** charge the device near any flammable substances.
- ◆ For dog use **ONLY**. Not for use on children.
- ◆ This is not a toy, and should only be operated by a responsible adult.

CAUTION


Before your first training, please carefully read and follow the instructions in this manual. The cautions below will help keep your dog safe and comfortable. Millions of dogs are comfortable wearing collars, while some are sensitive to the pressure from the contacts.

- ◆ It is vitally important that you and your dog remain safe while learning during on-leash training. Your dog should be on a strong leash (do not attach the leash to the receiver). The leash should be long enough for your dog to attempt to chase an object but short enough to prevent reaching roads or other hazards. You must also be physically strong enough to restrain your dog when he tries to chase.
- ◆ Risk of skin damage. Proper Receiver fitment is important. A Receiver worn for too long or made too tight on the dog's neck may cause skin damage. Ranging from redness to pressure ulcers; this condition is commonly known as bed sores.
- ◆ **DO NOT** leave the Receiver on the dog for more than 12 hours per day.
- ◆ When possible re-position the Receiver on the dog's neck every 1 to 2 hours.
- ◆ Check the fit to prevent excessive pressure; follow the instructions in this manual.
- ◆ Never connect an extra leash to the Receiver; it will cause excessive pressure on the contacts.
- ◆ Clean the dog's neck area and the Metal Prongs of the Receiver weekly with a damp cloth.
- ◆ Examine the contact area daily for signs of a rash or a sore.
- ◆ If a rash or sore is found, discontinue the use of the Receiver until the skin has healed. If the condition persists beyond 48 hours, see your veterinarian.
- ◆ Receiver Collar meets IP67 waterproof rating, it can be submerged in water up to 1 meter for up to 30 minutes. If submerged and wet, please do not use it.

II. Package Content



Remote Transmitter




Receiver Collar



Test Bulb



Metal Prongs



USB Type-C Cable



Conductive
Silicone Caps




User Manual



Wrist Strap

III. Product Overview


Remote Transmitter



Note:

- (1) When the Remote Transmitter toggles to the lock state, the Remote Transmitter will only display the battery level.
- (2) The Remote Transmitter will go into sleep mode if no operation in one minute.


Display Screen




Note: The Remote Transmitter will go into sleep mode if no operation in one minute.

Receiver


Power ON/OFF Button(Pairing Button)



Indicator Light




IV. Quick Start Guide




Charge the Receiver and the Remote Transmitter for 2-3 hours with the USB Type-C Cable from the package box.

Note: The charger, power bank, and other charging devices shown in the above picture are not included in the box.




Make your dog sit down and fit the Receiver to your dog by leaving one finger space between the collar and your dog's neck. Center the Metal Prongs underneath your dog's neck, touching the skin.

3




Turn on the Receiver by pressing and holding the Power Button for 2 seconds with a vibration to indicate that the Receiver is turned on. The green LED Indicator light now continues to blink regularly.

4



Turn on the Remote Transmitter by pressing and holding the ON/OFF (Channel) Button for 2 seconds.


5



Warning Tone Command: Press the Warning Tone Button, and the green Indicator Light on the Remote Transmitter rapidly lights up. The Receiver will deliver a warning tone, and the green Indicator light on the Receiver comes up simultaneously.

To adjust the Warning Tone level, press the Adjustment Knob to select the Warning Tone Mode first, then turn the Adjustment Knob left and right to raise/lower to the desired level, and finally press  button to confirm the modification.

6



Vibration Command: Press the Vibration Button, and the green Indicator Light on the Remote Transmitter rapidly lights up. The Receiver will deliver vibration, and the green Indicator light on the Receiver comes up simultaneously.

To adjust the Vibration level, press the Adjustment Knob to select the Vibration Mode first, then turn the Adjustment Knob left and right to raise/lower to the desired level, and finally press  button to confirm the modification.