



Shock Command: Press the Shock Button, and the red indicator Light on the Remote Transmitter rapidly lights up. The Receiver will deliver a shock and the green Indicator light on the Receiver comes up simultaneously. To adjust the Shock level, press the Adjustment Knob to select the Shock Mode first, then turn the Adjustment Knob left and right to raise/lower to the desired level, and finally press button to confirm the modification.



Flashlight Mode: Press the Flashlight Button, and the Flashlight on the Receiver will be on, while the "L1" icon is shown on the Remote Transmitter. Press the Flashlight Button again, and the Flashlight Mode will be off. Once the Flashlight is on, it will cut off automatically after 30 minutes if there is no operation on the Remote Transmitter. To adjust the type of the Flashlight, press the Adjustment Knob to select the Flashlight Mode first, then turn the Adjustment Knob left and right to raise/lower to the desired type of light, and finally press button to confirm the modification.




Test the Receiver with the Test Bulb:

1. Turn the Receiver on.
2. Hold the Test Bulb to the Metal Prongs on the Receiver. Make sure the metal wire in the Test Bulb has direct contact with both of the tops of the Metal Prongs.
3. Press the Shock Button on the Remote Transmitter.
4. The Red Test Light will flash if the Receiver works normally. At higher shock levels, the Test Bulb will flash brighter.

Note:

- (1) While you test the Receiver with your fingers, please put your two fingers on the top of the Metal Prongs separately to form a closed loop circle.
- (2) Please always start from the lowest Shock level to avoid accident hurt.



This product can train up to 2 dogs. You can either train 2 dogs independently by pressing the Channel Button to or , or train two dogs simultaneously by pressing the Channel Button to . This Receiver is paired to the Channel by the factory default setting, if you have an extra receiver to pair up, please follow the instructions in the section Pairing Up on page 14.

How the System Works

The Remote Training Collar is easy to use with an advanced digital display that tells you the exact stimulation level you are using.

The Remote Training Collar assists you in controlling your dog without a leash. At the push of a button, your Remote Transmitter sends a signal activating your dog's Receiver. He receives a safe but annoying stimulation.


He'll quickly learn the association between his behavior and your correction, and soon you'll have a better-behaved dog. The Remote Training Collar has been proven safe, comfortable, and effective for both small and large dog breeds.

If using the Remote Training Collar consistently and correctly, any basic obedience commands can be taught and will help correct any misbehavior that your dog exhibits.

V. Setting Up

1. Charge the Product

Charge both the Receiver and Remote Transmitter with the USB Type-C Charging Cable in the package box until their Indicator becomes solid green which will take around 2-3 hours.




Note:


- (1)The charger, power bank, and other charging devices shown in the above picture are not included in the box.
- (2)Use the charging cable in the package when charging. Other charging cables may not be suitable for this Dog Training Collar, which may cause electric damage.
- (3)The Dog Training Collar ONLY supports a 5V-rated power source. If charged with an improper charger:
Receiver Collar—deliver a rapid warning tone and stop charging automatically.
Remote Transmitter—stop charging automatically with the Indicator rapidly blinking in red.

2. Turn On/Off the Product



Turn on the Remote Transmitter by pressing and holding the ON/OFF (Channel) Button for 2 seconds.





Turn off the Remote Transmitter by pressing and holding the ON/OFF (Channel) Button for 2 seconds.



Turn on the Receiver by pressing and holding the Power Button for 3 seconds with a vibration to indicate that the Receiver is turned on, as the green LED Indicator light blinks regularly.



Turn off the Receiver by pressing and holding the Power Button for 3 seconds with a long beeping to indicate that the Receiver has turned off, as the green LED Indicator light stops blinking.




VI. Training Modes


1. Warning Tone Mode

Press the Warning Tone Button and the Receiver Collar will deliver a warning tone. It will cut off automatically if you press and hold the Warning Tone Button for 10 seconds. There is a total of 8 levels of Warning Tone for training.

To adjust the warning tone level, press the Adjustment Knob to select the Warning Tone Mode first, then turn the Adjustment Knob left and right to raise/lower to the desired level, and finally press the  button to confirm the modification.




Press




2.Vibration Mode

Press the Vibration Button and the Receiver will deliver a vibration. It will cut off automatically if you press and hold the Vibration Button for 10 seconds. There is a total of 16 levels of Vibration.

To adjust the vibration level, press the Adjustment Knob to select the Vibration Mode first, then turn the Adjustment Knob left and right to raise/lower to the desired level, and finally press  button to confirm the modification.




Press




3.Shock Mode


Press the Shock Button and the Receiver will deliver a static shock. It will cut off automatically if you press and hold the Shock Button for 10 seconds. There is a total of 99 levels of Shock.

To adjust the shock level, press the Adjustment Knob to select the Shock Mode first, then turn the Adjustment Knob left and right to raise/lower to the desired level, and finally press  button to confirm the modification.



Press





When testing the Shock function for the first time, place the Test Bulb on the Metal Prongs. The Test Bulb lights up to indicate that the Shock function is working, and it will become brighter at higher shock levels.


4. Flashlight Mode

There are seven types of flashlight modes.


Icon on the Remote Transmitter	Flashlight Color	Press the Flashlight Button, the Receiver will illuminate the corresponding Flashlight color based on the icon shown on the Remote Transmitter.
L1	Blue, Green, Red   	
L2	White 	
L3	Green 	
L4	Red 	
L5	Blue 	
L6	Yellow 	
L7	Purple 	

Press the Flashlight Button again, and the Flashlight Mode will be off. Once the Flashlight is on, it will cut off automatically after 30 minutes if there is no operation on the Remote Transmitter.

To adjust the different types of the Flashlight, press the Adjustment Knob to select the Flashlight Mode first, then turn the Adjustment Knob left and right to raise/lower to the desired type of light, and finally press  button to confirm the modification.




Press



Note: When the dog training collar is in Flashlight mode, pressing any of the buttons for the other three training modes will temporarily turn off the Flashlight. Once the operation is complete, the receiver will automatically return to light mode and resume lighting up.

5. Switching Channels

Use the Channel Button on the left side of the Remote Transmitter to select the Receiver you wish to control if you have paired two Receivers.



Note:

The Remote Transmitter will enter sleep mode if no operation in one minute to save battery power.

VII. Fitting the Receiver


IMPORTANT:

The proper fit and placement of your Receiver are important for effective training. The Metal Prongs with Conductive Silicone Caps must have direct contact with your dog's skin on the underside of his neck. To ensure a proper fit, please follow these steps:


1. Make sure that the Receiver is turned off.
2. Let your dog stand on four feet or lay down fully (A).
3. Place the Receiver on your dog's neck close to the ears. Center the Metal Prongs underneath your dog's neck, touching the skin (B).

Note: It is sometimes necessary to trim the hair around the Metal Prongs to make sure that contact is consistent.

4. The Receiver should fit snugly, yet loose enough to allow one finger to fit between the strap and your dog's neck (C).
5. Allow your dog to wear the Receiver for several minutes then recheck the fit. Check the fit again as your dog becomes more comfortable with the Receiver.



6. To attach the collar to the Receiver, please follow the following steps as instructed to thread the strap.



CAUTION:

- **DO NOT** leave the Receiver on your dog's neck for continuous 12 hours.
- **Never** attach a leash to the collar.