


size:210x148mm

WALL ART WIRELESS SPEAKER

Instruction Manual

Item Number:MU03032



Contents:

- Wall art speaker x 1
- USBA-Type C charging cable x 1
- Instruction Manual x 1

Product Specification:

Bluetooth Speaker(15.75in. x 15.75in. x 1.38in.)
(40cm x 40cm x 3.5cm)

Weight: 4.4lbs(1.99kg)

Material: ABS Polyester & MDF


Battery: 1200mAh

Play Time: 4-5 Hours (at 70% Max Volume)

Charging Time: 3-4 Hours

Input: 5V $\approx$ 500mA


Speaker Output: 5W (Max)

Part Name:

1. “-” Volume Down
2. “⏻” Power key
3. “+” Volume Up

Hanging the Wall Art Speaker:

- There is a hook at the upper back section of the Wall Art Speaker. The hook can be used to suspend the Wall Art Speaker on a wall or vertical surface.
- Please ensure that the hanger used is securely attached to the wall and can sustain the weight of 4.4lbs (1.99kg) to avoid potential droppage and breakage of the speaker.



How To Use:

- **Power on:** long press the power switch for 2s, the speaker will have a power on prompt tone, and the blue indicator will flash.
- **Bluetooth connection:** After the power is turned on, the speaker will automatically enter the Bluetooth search pairing state, and the blue indicator will flash.

Search the name of the Bluetooth speaker on the multimedia device: "ART BT SPEAKER", and click Pairing. After the pairing is successful, the Bluetooth speaker will give a successful connection tone and the blue indicator light will stay on. At this point, audio can be played on the Bluetooth speaker.

When the Bluetooth speaker is not connected to the device within 5 minutes after the power is turned on, the power will turn off automatically. To use it again, you need to restart the speaker. The speaker has a back link function. The device that is successfully connected will automatically connect when Bluetooth is turned on again.

Front

- **Bluetooth music playing:** After the Bluetooth connection is successful, the device plays music directly. Short press during playback "⏸" to Pause, briefly press "⏮" to play the previous song, briefly press "⏭" to play the next song, long press "⏮" to decrease the volume and long press "⏭" to increase the volume. Press "⏸" while paused to resume playing. Always press the "⏸" key for more than 3 seconds to shut down.

Charging: You can charge in standby or off state. Plug the TYPE-C end of the USB power cable provided into the TYPE-C socket of the speaker, and connect the other to the USB port or USB charger of a computer to start charging. The charging LED turns red and the charging indicator turns off after a full charge.

** WARNING:**

- Charge and operate only as indicated in this manual, as improper use may result in damage to the product or injury.
- To avoid risk of shock or injury, do not dismantle the device or insert any objects into the speaker.
- To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so.
- Do not pull the speaker charging cable. Damage may result to the cable.
- Keep out of reach of children. This is not a toy.
- Avoid exposure to moisture, liquids, heat, flame and high voltage equipment.
- Retain these instructions as they contain important information.
- Do not short circuit the input terminals of the speaker.
- Do not drop, place heavy weight or allow heavy impact to the speaker.
- PCB of battery should not be crushed and twisted.
- Battery body should not be bended.
- Do not disassemble and Do not dispose of in fire.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

Tips: Please do not turn the volume knob to the maximum level to prevent hearing damage and to prolong the service life of the system.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

-"**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

-"**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications."

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AYB6-MU03032

Dongguan Imlong Electronics CO., Ltd
Feb,2023
This product complies with EPA TSCA Title VI requirement for Formaldehyde emission

Distributed By: 1616 Holdings, Inc

701 Market Street, Suite 200

Philadelphia, PA 19106

Made in China



[Back](#)