


TRANSPARENT
WIRELESS SPEAKER

Instruction Manual

Item Number: MU03041




Contents:

- 1(One) x Wireless Bluetooth® Speaker 11.8in. x 8.46in. x 5.12in. (30cm x 21.5cm x 13cm)
- 1(One) x USB A-USB C Cable 47.3in.(120cm)
- 1(One) x Instruction Manual

Product Specification:

Frequency: 20Hz -20kHz
Speaker Input: 5V==2A
Speaker Output: 7W + 3W
Power Source: 47.3in. (120cm) USB A- USB C
Bluetooth Range: Up to 32 feet (10m)
USB Cable rating 2.0A Max
FCC ID: 2AYB6-MU03041



How To Use:

Connect the included cable with power supply.The red LED will be lit on.

- **Power on:** Press the power key “” 2 second when it is off.
- **Pairing:** Activate the Bluetooth® function on your phone within range and select “TRANSPARENT BT SPEAKER” from the list shown.
- **Play/Pause:** When it is playing, press the center key “” to pause, then press again to play.
- **Volume up:** Hold down “” to increase the volume.
- **Volume down:** Hold down “” to decrease the volume.
- **Previous song:** Press the “” once to play the previous song.
- **Next song:** Press the “” once to play the next song.
- **Power off:** When the speaker is on standby or operating, press and hold the speaker key “” 3 seconds to shut down the speaker.
- **Bluetooth mode / FM mode:** Double click “” to switch
- **FM mode:** Short press “” to search and store radio stations

Front

 WARNING:

- Charge and operate only as indicated in this manual, as improper use may result in damage to the product or injury.
- To avoid risk of shock or injury, do not dismantle the device or insert any objects into the speaker.
- To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so.
- Do not pull the speaker charging cable. Damage may result to the cable.
- Keep out of reach of children. This is not a toy.
- Avoid exposure to moisture, liquids, heat, flame and high voltage equipment.
- Retain these instructions as they contain important information.
- Do not short circuit the input terminals of the speaker.
- Do not drop, place heavy weight or allow heavy impact to the speaker.
- PCB of battery should not be crushed and twisted.
- Battery body should not be bended.
- Do not disassemble and Do not dispose of in fire.

Tips: Please do not turn the volume knob to the maximum level to prevent hearing damage and to prolong the service life of the system.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.
The device should be installed and operated with minimum distance 20cm between the radiator your body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

-“**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.”

-“**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.”

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.”

 Bluetooth®

The Bluetooth®word mark and logos are owned by the Bluetooth®SIG.
All other trademarks appearing herein are the property of their respective owners.
¹Depends upon third party device compatibility.

Distributed By: 1616 Holdings, Inc
701 Market Street, Suite 200,
Philadelphia,PA 19106
Made in China



Back