
CFカード表示ランプ
CFカード挿入口
タッチペン
VOL
キャプチャー
インデックス
キャプチャーボタン
電源ボタン
音量UPボタン
音量DOWNボタン
インデックスボタン


ネジカバー
ネジカバー
LOCK
UNLOCK
RELEASE
DC IN
ネジカバー
ネジカバー


36.1
24.1
ケース(裏)
ケース(表)
27.6
10.8
タッチパネル・LCD画面
RFユニット
スピーカー(R)
CF保護カード
13.3
電源表示ランプ
ワイヤレス表示ランプ
充電表示ランプ
スピーカー(L)
電源
ワイヤレス
充電
118.1
8.1
Locationfree
SONY
ヘッドホン端子
イーサコネクタ
206.2
Lバッテリ
15°
Sバッテリ
外部電源端子(DC入力)


LOCK
UNLOCK
RELEASE
SONY
LOCATIONFREE TV
D05-XXXX001
DC:12V 1.5A
Li-ion
Contains FCC ID:AK8IRF303J
Contains IC:409B-IRF303J
Complies Canada ICES-003/NMB-003
This class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)this device may not cause harmful interference,and(2)this device must accept any interference received,
including interference that may cause undesired operation.
ソニー株式会社 Sony Corporation MADE IN JAPAN 2-547-218-01
認証機器名 LF-X5M
製造番号 XXXXXXX
DC IN
FCC ID label


RFユニット
120°
スタンド
ゴム足
ゴム足

モニター外観図