105*148 MM 128克铜版纸 单色 印刷 12p 钉成册

JVC

SP-PA15BT
Portable Wireless Speaker

Instruction Manual

Website: www.jvc.com/usa

1



Notice:
* Please read [Instruction Manual] carefully and keep it for your records.

Package include:
- SP-PA15BT (Bluetooth Speaker) × 1pcs
- Strap × 1pcs
- USB-C to USB-A Cable (31.5 inch / 800 mm) x 1pcs
- AUX Cable (23.6 inch / 600 mm) x 1pcs
- Instruction Manual x 1pcs
- Warranty Card x 1pcs

Specifications:
- Bluetooth Version 5.3
- Output: Max. 120W/4Ω
- 3 inch x 2 Woofers x 2, 1.5 inch x 2 Tweeters and 3.75 inch x 2 Passive Speakers
- Battery Capacity: 7.4V / 5,400mAh
- Multi-Link up to 100pcs of SP-PA15BT
- SIRI Control
- Hands Free Calling
- USB Audio
- AUX Input
- IPX6 Waterproof
- Equalizer (2 modes)
- RGB LED Illumination (4 modes include Off)
- Bluetooth Working Distance: 33 ft / 10m
- Operation Temperature: 68~104°F / -10~40°C
- Size: 14.8 x 7.1 x 6.2 inch / 377 x 180 x 157 mm
- Power Bank Function (5V/1A)
- Notification Beep
- Auto Off (10min.)

2

Safety Instructions:
- Never disassemble SP-PA15BT in an attempt to make any repair as this could result in electrical shock, burns, or product failure.
- Use extra caution in high temperatures.
- Do not expose SP-PA15BT to direct heat or flame.
- SP-PA15BT is not covered under Warranty when the product has metal rust, surface spoiling and any other natural oxidation.
- Damage, shock, and/or injury can occur if these warnings are not heeded.
- SP-PA15BT may become warm while charging.
- Make sure to always completely turn off both the SP-PA15BT and power outlet before unplugging.
- Make sure SP-PA15BT has plenty of ventilation.
- Do not press the buttons too hard as it could damage SP-PA15BT.
- Only use dry cloth to keep SP-PA15BT clean from dust.
- Do not use chemicals on SP-PA15BT.
- Never try to repair SP-PA15BT yourself, take it to a Certified Technician. Trying to remove panels or repairing it yourself could lead to electric shock. When it is not in use, make sure it is correctly turned off and stored in a cool dry place.
- Do not insert foreign objects into SP-PA15BT.
- Avoid dropping SP-PA15BT, as harsh impacts could damage it.

3



No.	Button / Slot
1	−
2	+
3	LED Illumination
4	Microphone Hole
5	Power with LED
6	Multi-Link with LED

No.	Button / Slot
7	Play
8	M (Mode)
9	AUX (AUX Slot)
10	RESET (Reset Slot)
11	INPUT (USB-C Slot)
12	USB (USB-A Slot)

* Rating label is placed on the exterior of the bottom.

4

Function	Button / Slot	Operation
Power On / Off	❾ Power	Long Press (2 sec.)
Volume Up	❽ +	Short Press
Volume Down	❼ −	Short Press
Play / Pause (Bluetooth, USB Audio)	❾ Play	Short Press
Mute On (AUX)	❾ Play	Short Press
Mute Off (AUX)	❾ Play, ❽ + , ❼ −	Short Press
Next Song (Bluetooth, USB Audio)	❽ +	Long Press
Previous Song (Bluetooth, USB Audio)	❼ −	Long Press
Mode Change (Bluetooth Audio / USB / AUX)	❽ M	Short Press
SIRI (Bluetooth)	❾ Play	Long Press (2 sec.)
Bluetooth Disconnect	❽ Multi-Link	Long Press (2 sec.)
Bluetooth Connect (After Disconnect)	❽ Multi-Link	Long Long Press (over 3 sec.)
Multi Link or TWS Connect / Disconnect (Bluetooth)	❽ Multi-Link	Short Press
Receive / End Phone Call (Bluetooth)	❾ Play	Short Press
Reject Phone Call (Bluetooth)	❾ Play	Long Press (2 sec.)
Switch Phone Call up Device to Phone	❾ Play	Long Press (2 sec.) while talking
LED Illumination Control (4 modes)	❺ LED	Short Press
Equalizer Control (2 modes)	❽ M	Long Press (2 sec.)
USB Audio	❷ USB-A Slot	Connect USB Flash Drive
AUX	❾ AUX Slot	Connect through AUX Cable
Charge Battery (Standard / Fast Charge)	❶ USB-C Slot	Connect via USB Cable with Charge (Standard 5V/2A or Quick 9V/2A Charger)
Power Bank (5V/1A)	❷ USB-A Slot	Connect through USB Cable
Re-Boot (Recovery)	❿ Reset Slot	Short Press by Rounded Pin
Reset	❾ Play	Long Long Press (over 10 sec.)

Note:
* Above operation can be processed on Bluetooth devices synchronously.

5

Power On/Off and Pairing:
- Place SP-PA15BT within 33 feet for the Bluetooth-enabled device.
- Long-Press "Power" Button ❾ for 2sec. "Blue LED Indicator" ❺ will Flash rapidly to indicate that SP-PA15BT is in Bluetooth Pairing Mode.

Bluetooth Pairing :
- On your Bluetooth enabled Device (Smartphone, Tablet, Media Player) navigate to the Bluetooth setting menu, Turn On the Bluetooth feature, and search for "JVC SP-PA15BT", Type Password "0000" or "1234" if requested.
- You will hear the Notification Beep, and the "Blue LED indicator" ❺ is instantly ON when connected.
You can start playing the music on your Devices now.
- SP-PA15BT will be automatically reconnected to the last Paired Bluetooth Device when Powered On again.

SIRI:
- Long-Press "Play" Button ❾ will Activate SIRI.
- Long-Press "Play" Button ❾ again will Deactivate SIRI.
- Google Assistant and other Voice Assistants are not Compatible.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. And any use of such marks by JVCKENWOOD Corporation (JVC) is under licensi. Other trademarks and trade namer are those of their respective owners.

Hands Free Call:
- Under Bluetooth connection state, you can receive call by Short-Press "Play" Button ❾ while Incoming call and End the call by Short-Press "Play" Button ❾ again.
- You can switch talking to your mobile phone by Long-Press "Play" Button ❾ during the call.
- You can reject the call by Long-Press "Play" Button ❾ while Incoming call.

6

Multi-Link:
- Multi-Link up to 100pcs of SP-PA15BT
- Please see below Chart for detail Operation and LED Indicator.

Steps	Speaker	Operation	Speaker	LED Indicator	
				Power LED	Multi-Link LED
1	Master Speaker	• Short-Press "Multi-Link" Button to make it ready for Multi-Link connection with Slave Speakers.	Master Speaker	• Illuminated constantly	• Illuminated constantly
2	Slave Speaker	• Power On and make it in Bluetooth is Disconnected state. • Short-Press "Multi-Link" Button to search Master Speaker. It will automatically start to get connected by Multi-Link.	Slave Speaker	• Blinking	• Illuminated constantly if Slave Speaker connected successfully. • Illumination off if Slave Speaker fails to connect in one minute.
3	Master Speaker	• Short-Press "Multi-Link" Button to exit the Multi-Link state.	Master Speaker	• Illuminated constantly when connect with Bluetooth enable Device. • Blinking while connect with Bluetooth enable Device.	• Illumination off
			Slave Speaker	• Blinking	• Blinking slowly while Searching state. If no Illumination off after 5min, Fail to connect with Master Speaker
4	Slave Speaker	• Short-Press "Multi-Link" Button to exit the Multi-Link state.	Master Speaker	• Illuminated constantly	• Illuminated constantly
			Slave Speaker	• Blinking	• Illumination off

* Please do not Bluetooth Pair each SP-PA15BT and Device separately. It will not connect as Multi-Link

7

Mode Change:
- While slotted in USB Drive and AUX Cable, it will change Mode by Short-Press "M" Button ❽ as below.
- It will skip the Mode, if USB Drive or AUX Cable or both of them are removed.

USB Audio Format
WAV
MP3
WMA
FLAC

USB Audio and Mode Change:
- USB Audio Mode will be activated while USB Drive is slotted in to the USB-A Slot ❷ and select USB Audio Mode by Short-Press "M" Button ❽.
- SP-PA15BT will change mode to USB Audio automatically when you slot in USB Drive.
- The playable Audio Formats are the table as above.
- USB Drive Condition: Up to 128GB

Auxiliary (AUX) Input and Mode Change:
- AUX Input Mode will be activated while AUX Cable is slotted in to the AUX Slot ❾ and select AUX Input Mode by Short-Press "M" Button ❽.
- SP-PA15BT will change mode to AUX Input Mode automatically when you slot in AUX Cable.
- While in AUX Input Mode, Short-Press "Play" Button ❾ to operate Mute On.
- When Mute On, it will be Mute Off by Short-Press below any 3 Buttons "Play" Button ❾ "+" Button ❽, "−" Button ❼.

LED Illumination:
- You can change 4 modes of LED Illumination (include Off) by Short-Press "LED Illumination" Button ❸.

Equalizer:
- You can change 2 modes of Equalizer by Long-Press "M" Button ❽.

8

Power Control (Auto Power Off):
- Bluetooth Mode: SP-PA15BT will Power Off automatically if not connected within 10 minutes while being Powered On.
- USB Audio Mode: While SP-PA15BT is Powering On and the USB Audio is in the Paused state by Short-Press "Play" Button ❾, SP-PA15BT will Power Off after 10 minutes.
- AUX Input Mode: While SP-PA15BT is Powering On and the AUX Input Audio is in the Mute On state by Short-Press "Play" Button ❾, SP-PA15BT will Power Off after 10 minutes.

Power Bank Function:
- Connect other device to the 5V/1A USB (USB-A Slot) ❷ via. Charging cable, while the SP-PA15BT is Power On.

Charging:
- Low Battery Notification Beep will occur when the battery is lower than 20%. and Red LED Indicator ❺ will blink.
- Connect to the USB-C Charging Port ❶ located under the Rear Silicone Cover
- Connect the USB-A (larger end of the Cable) to your Computer's USB Port or an AC adaptor (Not included) 5V/2A as Regular Charging or 9V/3A as Fast Charging.
- LED Indicator ❺ will Turn On Red while charging Battery.
- Red LED Indicator will Turn Off when fully charged.
- To protect the battery, please do not use the SP-PA15BT while it is charging.

Re-Boot (Recovery) and Reset:
- Re-Boot: Please Short-Press inside of the Reset Slot ❿ by Rounded Pin.
- Reset: Long-Press "Play" Button ❾ for over 10 sec



9

WARNING FOR BATTERY:
Please do not handle the battery in the following manners.
It can lead to an explosion or leakage of flammable liquids and gases.
- Dispose in fire, discard, crush or cut
- Leave in extremely high temperature environment
- Leave in extremely low pressure environment

For USA and CANADA:
This device complies with part 15 of FCC Rules and Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Le présent appareil est conforme à la parde 15 des règles de la FCC et aux normes des CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules as this equipment has very low levels of RF energy.

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles les radioélectriques (RF) de la FCC lignes directrices d'exposition et d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'ISDE puisque cet appareil a une niveau tres bas d'energie RF.

CAN ICES-3 (B) / NMB-3 (B).
This Class B digital apparatus complies with Canadian ICES-003.
(Cet appareil numérique de la Classe B conforme à la norme NMB-003 du Canada)

10

For USA :
FCC CAUTION
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note :
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed t o provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

11

For Customer Use:
Enter the Model No. and Serial No. (on the rating label of unit) below.
Retain this information for future reference.
Model No.
Serial No.

Supplier's Declaration of Conformity
Model Number : SP-PA15BT
Trade Name : JVC
Responsible party - JVCKENWOOD USA Corporation
Address: 1440 Corporate Drive, Irving, TX 75038
Telephone Number: (876)640-8070
This device complies with part 15 of the FCC Rules, Operation is subject to the following two conditions
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID : 2AYBO-SPPA15BT IC : 28ZB-SPPA15BT



PRODUCT REGISTRATION FOR THE CUSTOMER IN CANADA
EN : https://myjvckenwood.ca
FR : https://myjvckenwood.ca/fr

MADE IN CHINA

12

13

Support

JVC IS HERE TO HELP!

TOLL FREE: 1(800)252-5722

Website : www.jvc.com/usa