

JVC


SP-PA7BT
Portable Wireless Speaker

Instruction Manual



Website: www.jvc.com/usa

1



Notice:
* Please read Instruction Manual carefully and keep it for your records.

Package includes:
• SP-PA7BT (Bluetooth Speaker) x 1pcs
• Strap x 1pcs
• USB-C to USB-A Cable (31.5 inch / 800 mm) x 1pcs
• AUX Cable (23.6 inch / 600 mm) x 1pcs
• Instruction Manual x 1pcs
• Warranty Card x 1pcs


Specifications:
• Bluetooth Version 5.0
• Output: Max. 20W/40C
• 3 inch x 2 Full-Range Speakers and 3.5 inch x 2 Passive Speakers
• Battery Capacity: 2.5 Wh / 3,000mAh
• True Wireless Stereo by 2pcs of SP-PA7BT
• SIRI Control
• Hands Free Calling
• USB Audio
• AUX Input
• IPX5 Waterproof
• RGB LED Illumination (4 modes include Off)
• Bluetooth Working Distance: 33 ft / 10m
• Operation Temperature: 68~104°F / -10~40°C
• Size: 11.6 x 4.7 x 3.8 inch / 295 x 120 x 122 mm

2

Safety Instructions:

- Never disassemble SP-PA7BT in an attempt to make any repair as this could result in electrical shock, burns, or product failure.
- Use extra caution in high temperatures.
- Do not expose SP-PA7BT to direct heat or flame.
- SP-PA7BT is not covered under Warranty when the product has metal rust, surface spoiling and any other natural oxidation.
- Damage, shock, and/or injury can occur if these warnings are not heeded.
- SP-PA7BT may become warm while charging.
- Make sure to always completely turn off both the SP-PA7BT and power outlet before unplugging.
- Make sure SP-PA7BT has plenty of ventilation.
- Do not press the buttons too hard as it could damage SP-PA7BT.
- Only use dry cloth to keep SP-PA7BT clean from dust.
- Do not use chemicals on SP-PA7BT.
- Never try to repair SP-PA7BT yourself, take it to a Certified Technician. Trying to remove panels or repairing it yourself could lead to electric shock. When it is not in use, make sure it is correctly turned off and stored in a cool dry place.
- Do not insert foreign objects into SP-PA7BT.
- Avoid dropping SP-PA7BT, as harsh impacts could damage it.

3



No.	Button / Slot	No.	Button / Slot
1	Power	9	Microphone Hole
2	+	10	USB-A Slot
3	-	11	AUX (AUX Slot)
4	Play	12	DC 5V USB-C Slot
5	Play/Pause	13	Reset (Reset Slot)
6	Mute On	14	Battery Indicator
7	Mute Off	15	LED Illumination

* Rating label is placed on the exterior of the bottom.

4

Function	Button / Slot	Operation
Power On / Off	Power	Long Press (2 sec.)
Volume Up	+	Short Press
Volume Down	-	Short Press
Play / Pause (Bluetooth, USB Audio)	Play	Short Press
Mute On (AUX)	Play	Short Press
Mute Off (AUX)	Play	Short Press
Next Song (Bluetooth, USB Audio)	Next	Long Press
Previous Song (Bluetooth, USB Audio)	Previous	Long Press
Mode Change (Bluetooth Audio / USB / AUX)	Mode	Short Press
SIRI (Bluetooth)	Play	Long Press (2 sec.)
Bluetooth Disconnect	Link	Long Press (2 sec.)
Bluetooth Connect (After Disconnect)	Link	Long Press (2 sec.)
TWS Connect / Disconnect (Bluetooth)	Link	Short Press
Receive / End Phone Call (Bluetooth)	Play	Short Press
Repeat Phone Call (Bluetooth)	Play	Long Press (2 sec.)
Switch Phone Calling Device to Phone	Play	Long Press (2 sec.)
LED Illumination (Control LED mode)	Link	Short Press
USB Audio	USB-A Slot	Connect USB Audio Device
AUX	AUX Slot	Connect through AUX Cable
Charge Battery	USB-C Slot with LED	Connect through USB Cable with Charge (5V/1A - 5V/2A Charger)
Reset (Reset)	Reset Slot	Short Press by Rounded Pin

Note:
* Above operation can be processed on Bluetooth devices synchronously

5

Power On/Off and Pairing:

- Place SP-PA7BT within 33 feet for the Bluetooth-enabled device
- Long-Press "Power" Button (1) for 2sec. "Blue LED indicator" (2) will flash rapidly to indicate that SP-PA7BT is in Bluetooth Pairing Mode

Bluetooth Pairing:

- On your Bluetooth-enabled Device (Smartphone, Tablet, Media Player) navigate to the Bluetooth setting menu, Turn On the Bluetooth feature, and search for "JVC SP-PA7BT" type Password "0000" or "1234" if requested.
- You will hear the Notification Beep and the "Blue LED indicator" (2) is instantly On when connected.
- You can start playing the music on your Devices now.
- SP-PA7BT will be automatically reconnected to the last Paired Bluetooth Device when Powered On again.

TWS (True Wireless Stereo) Connection / Disconnection:
(Without Bluetooth Paired SP-PA7BT and Device)

- Place 2pcs of SP-PA7BT together, then Power On both 2 units
- Please make sure that the Bluetooth of both SP-PA7BTs "Blue LED indicator" (2) are flashing rapidly as "Ready to pair" state when starting TWS connecting.
- Long-Press "M" Button (3) on One of SP-PA7BT, it will connect 2 units as True Wireless Stereo with the Notification Beep.
- To Disconnect TWS, Long-Press "M" Button (3) again, it will disconnect.

(With Bluetooth Paired 1 of SP-PA7BT and Device)

- Operation is same as above except below.
- Please Long-Press "Link" Button (4) by Bluetooth Paired SP-PA7BT when you connect TWS. However, it might take more time to connect than "Without Bluetooth Paired SP-PA7BT and Device".

* Please do not Bluetooth Pair each SP-PA7BT and Device separately. It will not connect TWS for all above conditions.

SIRI:

- Long-Press "Play" Button (5) will Activate SIRI.
- Long-Press "Play" Button (5) again will Deactivate SIRI.
- Google Assistant and other Voice Assistants are not Compatible.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG Inc. And any use of such marks by JVC/KENWOOD Corporation (JVC) is under license. Other trademarks and trade names are those of their respective owners.

Support

JVC IS HERE TO HELP!

TOLL FREE: 1(800)252-5722

Website : www.jvc.com/usa

6

Hands Free Call:

- Under Bluetooth connection state, you can receive call by Short-Press "Play" Button (4) while incoming call and find the call by Short-Press "Play" Button (4) again.
- You can switch talking to your mobile phone by Long-Press "Play" Button (4) during the call.
- You can reject the call by Long-Press "Play" Button (4) while incoming call.

Mode Change:

- While slotted in USB Drive and AUX Cable, it will change Mode by Short-Press "M" Button (6) as below.
- It will slip the Mode, if USB Drive or AUX Cable or both of them are removed.

Bluetooth Audio

AUX Input ← USB Audio

USB Audio Format
WAV
MP3
WMA
FLAC

USB Audio and Mode Change:

- USB Audio Mode will be activated while USB Drive is slotted in the USB-A Slot (1) and select USB Audio Mode by Short-Press "M" Button (6).
- SP-PA7BT will change mode to USB Audio automatically when you slot in USB Drive.
- The playable Audio Formats are the table as above.
- USB Drive Condition: Up to 64GB

Auxiliary (AUX) Input and Mode Change:

- AUX Input Mode will be activated while AUX Cable is slotted in the AUX Slot (11) and select AUX Input Mode by Short-Press "M" Button (6).
- SP-PA7BT will change mode to AUX Input Mode automatically when you slot in AUX Cable.
- While in AUX Input Mode, Short-Press "Play" Button (4) to operate Music On.
- When Mute On, it will be Mute Off by Short-Press below any 3 Buttons "Play" Button (4), "+" Button (2), "-" Button (3).

7

Power Control (Auto Power Off):

- Bluetooth Mode: SP-PA7BT will Power Off automatically if not connected within 10 minutes while being Powered On.
- USB Audio Mode: While SP-PA7BT is Powered On and the USB Audio is in the Paused state by Short-Press "Play" Button (4), SP-PA7BT will Power Off after 10 minutes.
- AUX Input Mode: While SP-PA7BT is Powered On and the AUX Input Audio is in the Mute On state by Short-Press "Play" Button (4), SP-PA7BT will Power Off after 10 minutes.

LED Illumination:


- You can change 4 modes of LED Illumination (include Off) by Short-Press "LED Illumination" Button (7).

Charging:

- Low Battery Notification Beep will occur when the battery is over than 20%.
- Connect to the USB-C Charging Port (12) located under the Rear Silicone Cover.
- Connect the USB-A (loop end of the Cable) to your Computer's USB Port or an AC adaptor 5V/1A ~ 5V/2A (Not included).
- The Battery LED Indicator (13) will Turn On White while charging Battery.
- Once the speaker is full charged the 4 LED Indicators will keep steady lighting if it's powered on, otherwise, the LED indicators will be off.
- To protect the battery, please do not use the SP-PA7BT while it is charging.

Re-Boot (Recovery):

- Reset Short-Press inside of the Reset Slot (14) by Rounded Pin.



8

WARNING FOR BATTERY:

Please do not handle the battery in the following manners:

- It can lead to an explosion or leakage of flammable liquids and gases.
- Dispose in fire, discard, crush or cut.
- Leave in extremely high temperature environment
- Leave in extremely low pressure environment

For USA and CANADA:

This device complies with part 15 of FCC Rules and Innovation, Science and Economic Development Canada's licence-exempt RSSG. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme à la partie 15 des règles de la FCC et aux normes des CRTC. L'exploitation est autorisée sous les conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and ISED-102 of the ISED radio frequency (RF) Exposure rules as this equipment has very low levels of RF energy.

Cet équipement est conforme aux limites d'exposition aux rayonnements électromagnétiques pour un environnement non contrôlé et respecte les règles des radioélectriques (RF) de la FCC. L'exploitation est autorisée sous les conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CAN ICES-3 (B) / NMB-3 (B)
This Class B digital apparatus complies with Canadian ICES-3(B).
(Cet appareil numérique de la Classe B conforme à la norme NMB-003 du Canada)

9

For USA:
FCC CAUTION
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different than the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

10

For Customer Use:
Enter the Model No. and Serial No. (on the rating label of unit) below.
For Your Reference, Please call 1-800-252-5722 for more information.

Model No. _____
Serial No. _____

Supplier's Declaration of Conformity
Model Number: SP-PA7BT
Trade Name: JVC
Responsible party: JVC/KENWOOD USA Corporation
Address: 1440 Corporate Drive, Irving, TX 75039
Telephone Number: (972) 640-8899
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC ID : ZAYB0-SPPA7BT IC : 2828-SPPA7BT

FC

ATTENTION:
This product may be operated in powered by a rechargeable battery. But it is recommended to use a 1-amp 2-A1187 for replacement on non-rechargeable battery.

PRODUCT REGISTRATION FOR THE CUSTOMER IN CANADA
EN : <https://myjvc.kenwood.ca>
FR : <https://myjvc.kenwood.ca/fr>

MADE IN CHINA

11

Support

JVC IS HERE TO HELP!

TOLL FREE: 1(800)252-5722

Website : www.jvc.com/usa

12