

Xiaolei

Matter Smart Roller Shutter Switch



MK4

Product Features

- [Works with Major Matter Ecosystems]

MK4 is a Matter-certified smart switch that works seamlessly with Apple Home, Amazon Alexa, Google Home, SmartThings, and other Matter platforms. Manage devices from different brands in one APP.

- [Ultra-Compact Design]

Compact and versatile, MK4 fits easily into EU and US standard wall boxes. Ideal for both new installations and existing switch upgrades.

- [Precise Percentage Control]

After travel calibration, the roller shutter position can be adjusted by percentage for precise and flexible opening control.

- [Scheduled Roller Shutter Control]

Set opening and closing times to automate roller shutter operation based on your daily routine.

- [Safety Certifications]

MK4 is FCC, CE, RED, RoHS and Erp certified, ensuring reliable operation, electromagnetic compatibility, electrical safety, and environmental compliance.

- [APP Control]


Use Matter-compatible apps or the L-Home app for pairing, switching, cloud scenes, and automations. Use the NFC Lighting app for quick on-site parameter configuration.

Specifications


Model	MK4
Wireless Protocol	Matter over WiFi
Channels	2
Operating Voltage	100-240V~, 50/60Hz
Output Current	Max. 1.5A
Relay Inrush Current	70A@10ms
Operating Temperature	-10°C~40°C
Compatible Input Devices	Momentary Switch, Rocker Switch
Compatible Loads / Devices	Curtains, Blinds
Dimensions	L39.5×W33×H18(mm)
Package Size	L43×W58×H24(mm)
Weight	25.5g±5g

Dimensions

Unit: mm



Product Overview



Button and LED Indicator Status		
Button Action	Indicator Status	Device Status
-	Solid Blue	Normal
	Fast Flashing Blue	Ready to Pair
	Slow Flashing Blue	Firmware Update in Progress
Press and Hold for 15s, Press 3 Times within 3s	Fast Flashing Red	Ready for Factory Reset
	Slow Flashing Red	Factory Reset in Progress
Press 3 times within 1s	2 Slow Green Flashes	Switch to Momentary Switch Mode (Default)
	3 Slow Green Flashes	Switch to Rocker Switch Mode

1

Matter APP & Hub Setup

This device supports Matter and works with major smart home platforms. Download a compatible app and make sure your Matter hub is powered on and online before setup.



Apple Home



Google Home



Amazon Alexa





SmartThings

2

Wiring

- For electrical safety, install a 1.5A miniature circuit breaker (MCB) or residual current circuit breaker (RCCB) upstream of MK4.
- Disconnect the main power supply before wiring. Installation and maintenance must be performed by a qualified electrician. Never wire or touch the terminals while the device is powered.
- Follow the wiring diagram carefully. Wire size: 0.5–2.5mm² (24–14AWG). Strip length: 6–7mm. Do not exceed the rated load.
- Do not connect the S1 or S2 terminals to neutral or ground. Doing so may damage the device or create a safety hazard.
- The device supports both momentary and rocker switches. The default setting is Momentary Switch Mode.



- 1.To properly use the motor function of our MK4 device, ensure a live neutral wire is available near the installation location in your household circuit.
- 2.To avoid motor burnout from prolonged operation, the single running duration shall not exceed 2 minutes.


3 Add To Matter Platform

Open a Matter-compatible app, such as Apple Home or Google Home. Tap "Add Device," then scan the Matter QR code on the device and follow the on-screen instructions.



4 Installation

For in-wall installation, use a wall box at least 50mm deep.



EU Wall Box



US Wall Box

Use With NFC Lighting or L-Home APP

Scan the QR code below to download the NFC configuration tool. Configure Power-On State, Switch Control Type, Itinerary Calibration and other parameters before pairing. You can also use the L-Home APP. Scan the QR code on the right for the Digital Manual and more details.



NFC Lighting APP



L-Home APP



Digital Manual

Factory Reset

Method 1: Press and hold the function button for 15 seconds. Release it when the indicator flashes red rapidly. Within 3 s, press the function button 3 times. The indicator will flash red slowly while the device resets. The reset is complete when the indicator flashes blue rapidly.

Method 2: Make sure the device is powered on and online. Open the L-Home app and go to the device settings. Tap "Delete Device." When "Deleted Successfully" appears, the factory reset is complete.

Method 3: Make sure the device is powered on. Open the NFC Lighting app and tap "Read/Write Matter Device." Follow the on-screen instructions to find and connect the device, then tap "Factory Reset" on the parameter page.

FAQs

This product is designed to comply with the Matter standard. As Matter is still evolving, some features, performance, and network stability may be limited by the current version.

Product performance is subject to the current Matter version. We will continue to update and optimize the product as Matter evolves.

Q1: Does this device support Matter?

A: Yes. It works with major smart home platforms including Apple Home, Google Home, Amazon Alexa, and SmartThings.

Q2: Why doesn't the switch work as expected?

A: The external switch type may not match the current control mode.

Solutions:

- ① Quickly press the device button 3 times. Repeat up to twice if needed to switch to the appropriate control mode.
- ② Set "Switch Control Type" in the NFC Lighting or L-Home app to match the external switch.

Q3: Can the device be used without an external physical switch?

A: Yes. It can be controlled directly through L-Home or a Matter platform.

Q4: What should I do if 5GHz WiFi is not supported during pairing?

A: This device supports 2.4GHz WiFi only, not 5GHz. If your router uses a combined 2.4GHz/5GHz network, disable this feature in the router settings, connect your phone to the 2.4GHz WiFi network, and try pairing again.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Attention

- Product installation and commissioning should be done by a qualified professional.
- LTECH products are and not lightningproof non-waterproof (special models excepted). Please avoid the sun and rain. When installed outdoors, please ensure they are mounted in a water proofenclosure or in an area equipped with lightning protection devices.
- Good heat dissipation will prolong the working life of products. Please ensure good ventilation.
- Please check if the working voltage used complies with the parameter requirements of products.
- The diameter of wire used must be able to load the roller shutter you connect and ensure the firmwiring.
- Before you power on products, please make sure all the wiring is correct in case of incorrect connection that causes damage to roller shutter.
- If a fault occurs, please do not attempt to fix products by yourself. If you have any question, please contact our company or authorized distributors.
- This manual is subject to changes without further notice. Product functions depend on the goods. Please feel free to contact our company or our official distributors if you have any question.

Warranty Coverage

- Warranty periods from the date of manufacture: 2 years.
- Free repair or replacement services for quality problems are provided within warranty periods.

Warranty exclusions below:

Following conditions are not within the guarantee range of free repairing or replacement services:

- Beyond warranty periods.
- Any artificial damage caused by high voltage, overload, or improper operations.
- Products with severe physical damage.
- Damage caused by natural disasters and force majeure.
- Warranty labels and barcodes have been damaged.
- No any contract or invoice signed by LTECH.

1.Repair or replacement provided is the only remedy for customers. LTECH is not liable for any incidental or consequential damage unless it is within the law.

2.LTECH has the right to amend or adjust the terms of this warranty. The warranty that issues in writting shall prevail.

Xiaolei

Manufacturer: Zhuhai LTECH Technology Co., Ltd.

Address: 1st Building, No. 183, Shui'an 1st Road, Xiangzhou District, 519060
Zhuhai City, PEOPLE'S REPUBLIC OF CHINA

Website: www/tech-led.com

Email: lt@tech-led.com

Made in China