



Rienok

Wireless Earbuds

User Manual

Model: Rienok EB1

Manual directory

English 01 ~ 14

Deutsche 15 ~ 30


Français 31 ~ 44

Italiano 45 ~ 58


Packing Details



• Charging Base*1



• Type-C charging cable * 1




• User Manual * 1



• Wireless Earbuds*1




• Warranty card * 1



• Eartips * 3 pairs

- 01 - EN

Structure Description




Wearing



1. Take the earbuds out of the charging case, the "Rienok", "L", "R" logos should face yourself, then put them on and adjust them to a comfortable position.

2. The correct way of wearing is shown in the picture.



- 03 - EN

Specifications

Model:	Rienok EB1
Bluetooth version:	V5.0
Operating range:	Greater than 10 meters (Effective distance without obstacles)
Charging time of earbuds:	approx. 1.5 hours
Charging time of charging base:	approx. 2 hours
Playback time:	approx. 5 hours (75% volume)
Talk time:	approx. 4 hours (75% volume)
Wireless protocol:	A2DP, AVRCP, HFP, HSP, SBC
Earbuds battery:	45mAh rechargeable lithium battery
Charging base battery:	350mAh rechargeable lithium battery
Charging voltage:	DC 5V
Charging interface:	Type-C


Attention!

1. When using the earbuds for the first time, please remove the insulating piece on the magnetic charging contact and put the earbuds in the charging case and fully charge it before use.
2. If there's sweat or water on the earbuds, please dry them off before putting them in the charging case to charge.
3. When the earbuds are not in use, please charge them at least once every six months.


Turn On



● Mode1(Auto) Auto Power On




- 05 - EN



1. Take out the earbuds from the charging case, the earbuds will automatically turn on (blue light blinks)
2. When the earbuds are not in the charging base, or the charging base is out of power , long press the MFB touch button 2S, the earbuds will turn on (blue light blinks)

Pairing

White and blue lights on the right ear flash alternately




1. Take the earbuds out of the charging base, the white and blue lights on the earbud will flash alternately and enter the pairing state.
2. Turn on your device, turn on Bluetooth, find "**Rienok EB1**" and click to connect, the device displays the Bluetooth is connected and the light on the earbuds will be off.

Note:


When the earbuds are used a second time, it will automatically reconnect to the last connected device. If you want to connect it to a new device, disconnect the connected device, and pair it with the new device.

Pairing

- Model (Auto) Auto shutdown



- 08 - EN



1. Put the earbuds back into the charging base, the headset will be automatically shut down and charged.
2. When the earbuds is not in the charging base, press and hold the multi-function button for 7S, the headset will turn off.

Music Mode

Play/Pause:

- Click or touch the MFB button once.

Volume up and down:

- Volume up: Long press the right ear MFB button, volume "+"
- Volume down: Long press the left ear MFB button, volume "-"

Back / Next song:


- Back: Double press the left ear MFB button, back to the previous song
- Next song: Double press the right ear MFB button, next song

Incoming call:

- Answer/hang up: Click or touch the MFB function button once
- Reject: Long press the MFB function button for 1 second to reject the incoming call
- Voice wake up: three clicks of the MFB button, voice wake up

Reset/Clear Pairing

Put the earbuds back into the charging case, while long press the left and right earbud for 5 seconds, the blue and white light is on for 2 seconds and then off to clear the pairing record of the earbuds and the device.



Press and hold for 5S

Charging:



Earbuds Charging:

When the battery of the earbuds is low, the voice message "The battery is low". Please put the earbuds back into the charging case to charge when you hear the prompt tone. (the light on the earbuds will flash white while charging).

Charging in the charging case:

1. When the battery power of the charging case is only the first light, and the blue light keeps flashing, please charge the charging case in time.
2. Use the 5V output adapter to charge the earbuds charging case.
3. If the 4 battery indicator lights are on, the battery is fully charged.

FAQ

Common Problem	Solution
1. Cannot turn on the earbuds	1. The earbuds or charging case are dead - Charge the headset or charging case and try again.
2. Mobile phone cannot find the pairing name of the headset	1. The earbud has been connected to other devices, disconnect the connected device and try again. 2. Turn on the Bluetooth device, refresh and reconnect 3. Reconnect after restoring factory settings.
3. How to restore factory settings	Put the earphones back into the charging compartment and press both earphones for 5 seconds at the same time, until the earphones are blue and white The light will remain on for 2 seconds, then turn off to clear the pairing records of the headset and device.

4. Headset falls off when wearing it	1. Choose the appropriate eartips; 2. Check if the wearing method is correct (Refer to wearing method)
5. Other problems	If none of the above can solve the problem, please contact our after-sales service.

After-sales Service

Thank you for purchasing our products, if you have any questions or dissatisfaction, please feel free to contact us, we will promptly reply and solve your problem.

Website: <http://www.rienok.com>

E-mail: support-uk@rienok.com
support-us@rienok.com
support-ca@rienok.com

FCC STATEMENT

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Lieferumfang



• Ladebox * 1



• Bluetooth
Kopfhörer * 1



• Typ-C-Ladekabel * 1



• Anleitung * 1



• Garantiekarte * 1
- 15 - DE



S x1



M x1



L x1

• Kopfhörer
Aufsätze
*3 Paar

Darstellungen




Betriebsanzeige



Typ-C-Ladeanschluss



- MFB Touchtaste
- Bluetooth-Anzeige
- Mikrofon




- Magnetischer Ladekontakt

Trageweise



1. Nehmen Sie den Kopfhörer aus der Ladehülle, setzen Sie ihn auf und stellen Sie ihn auf eine bequeme Position ein.

2. Die korrekte Trageweise ist auf dem Bild dargestellt.



Technische Daten


Produkt Modell:	Rienok EB1
Bluetooth Version:	V5.0
Betriebsbereich:	Größer als 10m (effektive Entfernung ohne Hindernisse)
Ladezeit des Kopfhörers:	Ca. 1.5 Stunden
Ladezeit der Aufladebox:	Ca. 2 Stunden
Wiedergabedauer:	Ca. 5 Stunden (75% Lautstärke)
Sprechzeit:	Ca. 4 Stunden (75% Lautstärke)
Bluetooth Modus:	A2DP,AVRCP,HFP,HSP,SBC
Kopfhörer-Akku:	45 mAh wiederaufladbare Lithium-Batterie
Aufladebox-Akku:	350 mAh wiederaufladbare Lithium-Batterie
Ladespannung:	DC 5V
Ladeschnittstelle:	Typ-C


Achtung!

1. Wenn Sie die Kopfhörer zum ersten Mal verwenden, entfernen Sie bitte das Isolierstück und legen Sie das Headset vor der Verwendung vollständig aufgeladen in der Ladebox.
2. Wenn der Kopfhörer Schweiß oder Wasser abbekommen hat, trocknen Sie es bitte ab, bevor Sie es zum Aufladen in die Ladebox legen.
3. Wenn der Kopfhörer nicht in Gebrauch ist, laden Sie es bitte mindestens einmal alle sechs Monate auf.

Einschalten

● Modus1(Auto) Einschalten





1. Nehmen Sie den Kopfhörer aus der Ladebox, der Kopfhörer schaltet sich automatisch ein (blaues Licht blinkt).
2. Wenn sich der Kopfhörer nicht in der Ladebox befindet oder wenn die Ladebox keinen Strom mehr hat, drücken Sie die MFB-Touchtaste 2S lange, der Kopfhörer schaltet sich ein (blaues Licht blinkt).

Paarung

Weißes und blaues Licht von rechter Kopfhörer blinkt abwechselnd.

