




Smartphone Vlogging Kit




Model # 36020825_EN_092225

Model Description


PARTS

Part	Description	Qty
1	Wireless Microphone	1
2	USB-C Receiver	1
3	LED Light	1
4	Smartphone Clamp	1
5	Tripod Grip	1
6	USB Charging Cables	2
7	Shutter Remote Control	1

Parts Diagram



Convert Grip to Tripod




1. SET GRIP ON FLAT SURFACE

Swing left and right rear legs out from grip's center

2. PRESS AND HOLD RED BUTTONS

Adjust pivot head for best photo/video angle


Attach Accessories



3. SCREW CLAMP ONTO PIVOT HEAD

Tighten lower knob, then slide LED light into clamp's top slot (cold shoe) and turn knob to lock in place

Microphone and Receiver Use



4. TURN ON WIRELESS MIC

When LED blinks green, clip to shirt and plug in USB-C receiver - works on phone or select as source on PC/Mac


HAVING TROUBLE? WE CAN HELP

1-888-516-2630

7 DAYS/WEEK 7:00am - 9:00pm CST


Distributed by
Walmart Inc.,
Bentonville, AR 72716
FCC ID: 2AYFN-RMT
FCC ID: 2AYFN-MIC
Manufactured in China

Charging While Using the Mic




1. CONNECT USB-C END TO RECEIVER
Connect other end to a charger or portable battery to charge while using the microphone/receiver

LED Light Controls




1. COOL/NEUTRAL/WARM LED LIGHT
Control tone and brightness of solid light or tone and speed of strobing LED light

USB Charging



1. CONNECT USB-C END TO DEVICE
Connect other end to a USB charger (not included)

Shutter Remote Pair/Controls



1. PRESS 3 SECONDS FOR PAIRING
In Bluetooth® settings select "onnRemote" — hold button for on/off or quick press to take photo

Warranty

1 YEAR LIMITED WARRANTY COVERING DEFECTIVE PARTS
Contact Manufacturer for Additional Information
• This warranty is non-transferable and does not cover failure due to misuse or improper installation or maintenance.

Troubleshooting

Problem	Cause	Solution/Prevention
No mic audio when recording on phone	Mic/receiver not paired or powered on	Charge mic until red LED is off, then power on. Plug receiver into phone — mic green LED glows steady when paired.
No mic audio when recording on PC/Mac	Mic/receiver not paired, selected, or powered on	See above for charging and pairing. On PC/Mac, open audio settings and select USB-C receiver as input.
Distorted or static mic audio	Receiver too far, loose connection, interference	Bring mic and receiver closer, unplug/replug USB-C receiver, and stay clear of WiFi routers, microwaves, and other devices.
Shutter remote control not working	Too far, bad Bluetooth® connection, low battery	Charge remote and ensure Bluetooth® is on/paired to "onnRemote". Stay clear of WiFi routers, microwaves, and other devices.
LED light will not respond	Low battery or hard reset needed	Charge LED light for at least 2 hours. Hold power button for 10 seconds to reset.
Smartphone clamp not holding securely	Clamp misaligned or pivot head loose	Ensure Smartphone Clamp is screwed onto pivot head with lower knob firmly tightened. Adjust pivot head as needed.
Unstable Tripod	Legs not extended or uneven surface	See "Convert Grip to Tripod" page. Rotate rear legs out fully and place tripod on flat surface

Safety Precautions

Warning
To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Statement
This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in the portable exposure condition without restriction.

CAUTION

Lithium-ion Battery

- Lithium-ion batteries, if used improperly, can be dangerous to users. Exercise caution when handling them, especially in adverse environments.

Power Input
Remote..... 5V/120mA
LED Light..... 5V/2A
Wireless Microphone 5V/1A
USB-C Microphone Receiver 5V/1A

Pass-Through Charging (Input and Output)
USB-C Microphone Receiver 3.7V/20mA