CALCINI™

SweatPro 3

# User Manual

True Wireless Earbuds

- 1 -

## FIND YOUR FIT

Choose your comfortable size




- 2 -

## PAIRING

1.Open the lip of the charging case first
(Blue flash and enter the pairing mode)

2.Turn on the pairing function via BT on your device

- 3 -

3. From the list of available devices and select "Calcini SweatPro 3"

- 4 -

## Music




Double click the left or right earbud

- 5 -




Long press the left earbud for 2s

Long press the right earbud for 2s

- 6 -

## Calls




Long press left or right earbud for 4s can activate siri or other voice assistant

Double click left or right earbud can cancel call

- 7 -




**Answer calls**
Click the left or right earbud
**Hang up or Reject**
Double click the left or right earbud

- 8 -




Click the left earbud

Click the right earbud

- 9 -

68mm

96mm

## Game Mode




Triple click left or right earbud
(Double click again switch to music mode)

- 10 -

## WaterProof (IPX8)

The earbuds will NOT RECEIVE the BT signal in the following situations:
1.Diving with earbuds
2.Earbuds are submerged in water while swimming
(You can take shower with earbuds)

Signal Reception Explanation Picture:

- 11 -

## Reset the earbuds

**You need reset your earbuds in following case :**
1.Bad signal, slow connection
2.Your earbuds are connected with other device

**Starting with the earbuds**
1.Take both earbuds out of the case
2.Touch and hold on the touch-control pannels on both earbuds for 6s to power off until red flashing
3.Touch and hold on the touch-control pannels on both earbuds for 10s. ( Bule flashing indicate it is power on and red flashing 3 times indicate it be reset sucessfully)
4.Put both earbuds into the charging case and colse the lid
5.Open the lid again, and both earbuds will turn on then enter the pairing mode.(Please refer the page 3-5)

- 12 -

## Package Contents

- A Pairs of Earbuds with charging case
- USB-C Cable
- S/M/L Ear Tips
- S/M/L Ear Wings
- User Manual
- Thank Card

## Product Diagram




- 13 -

## Getting Started
## Charging

Fully charge the charging case before the first use. To charge, connect the charging case to a USB charger or charging port with the included USB-C cable.



- 14 -

## Controls & LED Indicators
## Streaming Audio

Once paired, you can wirelessly stream audio on your device via earbuds. Music will automatically get paused when you receive an incoming phone call and will be resumed once the call ends

| | |
|---|---|
| Play or pause music | Double click the left or right earbud |
| Skip to previous track | Long press the left earbud for 2s |
| Skip to next track | Long press the right earbud for 2s |
| Answer call | Click the left or right earbud |
| Hang up or Reject | Double click the left or right earbud |
| Cancel call | Double click left or right earbud |
| Volume + | Click the right earbud |
| Volume - | Click the left earbud |
| Game low latency | Triple click left or right earbud |
| Switch to music mode | Double click left or right earbud |

Earbuds

| | |
|---|---|
| LED Status Indicator | Status |
| Blue flashing | Pairing |
| Red and blue flashing alternately | TWS pairing |
| Red flashing 3 times | Reset |

Charging Case

| | |
|---|---|
| LED Status Indicator | Status |
| Bule flashing 10S | Earbuds charging |
| Blue always flashing | Charging case charging |
| Blue turn off | Charging case fully charged |

- 15 -

## Specifications

Earbuds

| | |
|---|---|
| Model | EA07 |
| Technology | A2DP, AVRCP, HFP, HSP, AAC |
| Speaker Sensitivity | 95dB±3dB@1KHz |
| Frequency Range | 20Hz ~ 20KHz |
| Impedance | 16Ω |
| Charging Time | 1.5H |
| Battery Life | >5H |
| Battery Type | Li-polymer (2 x 50mAh) |
| Operating Range | 10m/33ft |
| Weight | 5g*2 |

Charging Case

| | |
|---|---|
| Charging Input | 5V |
| Charging Time | 1.5H |
| Battery Type | Li-polymer 500mAh |
| Number of Earbuds Recharges | 4 times |
| Weight | 38g |

Turning On/Off

| | |
|---|---|
| Turn On | Open the lid of the charging case or touch and hold on the touch-control pannels on one of the earbuds that you want to turn on for 6s |
| Turn Off | Return the earbuds to the charging case and close the lid or touch and hold on the touch-control pannels on one of the earbuds that you want to turn off for 6s |

- 16 -

## Pairing

Starting with the earbuds in the case:
1.Open the lid of charging case, both earbuds will be turned on.
2.Take the earbuds out of the charging case and then enter pairing mode.
3.Turn on the pairing function via BT on the device you want to pair with the earbuds.
4.From the list of available devices and select "Calcini SweatPro 3"

## Regular Use After Pairing

Once the earbuds are successfully paired with your device, they can be switched on and off as follows:
1.Open the lid of the charging case,then both earbuds will turn on and connect with each other automatically
2.To turn off, put the earbuds back in the charging case and close the lid. They will begin charging

## Product Care & Use

1.Keep away from liquids and extreme heat
2.Don't use the earbuds at high volume for extended periods, as this may cause permanent hearing damage or loss

- 17 -

## FCC Warning Statement:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device,pursuant to Part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates uses and can radiate radio frequency energy. If not installed and used in accordance with the instructionmay cause harmful interference to radio communica- tions.However, there is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try tocorrect the interference by one or more of the following.

- 18 -

## Measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that
to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC Rules.Operation is
subject to the following two conditions:
(1) This device may not cause harmful interference
(2) This device must accept any interference received,including
interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure
requirement.

## Contact us :

Join member

Official Website: www.calcini.com
Support Service: support@calcini.com
B2B Distributor: distributors@calcini.com

- 19 -

| 尺 寸 公 差 | | | 要求 | | 品名 | SweatPro 3 说明书 (线上) | | 比例 | 1 : 1 | 日 期 DATE | 2021.12.29 |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 位 数 | 尺 寸 | 角 度 | | | 料号 | | 设 计 DESIGNED | HOY | | 审 核 CHECKED | |
| X / X . X | ±1mm | ±0.5° | | | 版 本 FORMAT | A | 制 图 DRAWN | | | 批 准 APPROVED | |
| X . XX | ±0.5mm | ±0.5° | | | 深圳市溦沃科技有限公司 SHENZHEN WEWO TECH CO., LTD | | | | | | |
| 记 事 | | 变更NO. | 年/月/日 | | | | | | | | |