

User Manual

OXS Thunder DUO Gaming Speaker

MANUEL D' UTILISATION · MANUAL DEL USUARIO
РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ · MANUALE D' USO
用戶手冊 · 用戶手冊 · ユーザーマニュアル · 사용자 설명서
INSTRUKCJA OBSŁUGI · GEBRUIKER HANDLEIDING

Model No. : S031

Thank you for purchasing this OXS product.

To receive more complete service, please follow us at www.oxsaudio.com

ABOUT THIS MANUAL

The user manual has two parts: this simple paper USER MANUAL and a detailed FULL MANUAL you can download.

① USER MANUAL

See this manual for product installation, components and connections.

② FULL MANUAL


You can access the FULL MANUAL or download it in document format from OXS's website. (<http://www.oxsaudio.com/support>)

Design and specifications are subject to change without prior notice.

CONTENTS

WHAT'S INSIDE	ENG - 03
•Device Layout	ENG - 04
•Remote	ENG - 06
•Toggle Control	ENG - 07
HOW TO USE	ENG - 08
CONNECTING TO AN AUDIO SOURCE	ENG - 09
•Connecting via HDMI eARC/ARC	ENG - 09
•Connecting via HDMI IN	ENG - 10
•Connecting via the USB-C cable	ENG - 11
•Connecting via the analog cable	ENG - 12
•Connecting via Bluetooth	ENG - 13
•Setting the speaker as the default device	ENG - 14
ENABLING DOLBY ATMOS	ENG - 15


WHAT'S INSIDE



Active and Passive Speaker




OXS Cable×1




Power Adapter×1




Power Cable×1



HDMI Cable×1



OPT Cable×1




USB C to C Cable×1




Remote Control

DEVICE LAYOUT



1		Sky Channel Driver	7		HDMI IN
2		Tweeter Driver	8		Speaker Output
3		Woofer Driver	9		Optical Input
4		Dongle Hub	10		Power Input
5		USB-C Input	11		Speaker Input
6		HDMI eARC	12		Bass Port


REMOTE



1	MUTE
2	VOLUME UP
3	POWER
4	LAST TRACK
5	PLAY PAUSE
6	NEXT TRACK
7	EQ MODS
8	VOLUME DOWN
9	INPUT SWITCH
10	RGB MOTION
11	RGB MODS
12	RGB COLOR
13	BASS UP
14	BASS DOWN
15	TREBLE UP
16	TREBLE DOWN
17	SKY UP
18	SKY DOWN

HOW TO USE

Setting it up




1 Positioning

Position the soundbar on a flat and stable surface as required in your setup.


2 Adjusting height

The extra pair of detachable feet lets you change the soundbar height to ensure that sound is delivered with the least amount of obstruction.




3 Connect Power

After connecting the power, the device enters standby mode.




4 Power on

Power on the soundbar by press and hold the button.




CONNECTING TO AN AUDIO SOURCE


Connecting via HDMI eARC/ARC




- 1 Connect the soundbar to any of the HDMI(eARC/ARC) ports on your TV using the included HDMI cable.




- 2 Switch the audio input to TV.



Connecting via HDMI IN




- 1 Connect any of the HDMI ports on your TV or monitor to the soundbar's HDMI OUT port.



- 2 Connect any of the HDMI ports on your PC or gaming console to the soundbar's HDMI IN port.


Method A



- 3 Switch the audio input to HDMI.


ENG-10

Connecting via the USB-C cable



- 1 Connect the soundbar to any of the USB-A ports on your PC using the included USB-C to USB-A cable.


Method A



Method B




- 2 Switch the audio input to the PC.




ENG-11

Connecting via OPTICAL




Connect to Optical device (Xbox One)


Method A



Method B




② Switch the audio input to OPTICAL



Connecting via Bluetooth


Method A




Method B



① Switch the audio input to Bluetooth.




② Select "OXS Thunder" on the device screen.




③ Once the connection is successful, the "BT" indicator on the soundbar will remain steady.

SETTING THE SPEAKER AS THE DEFAULT DEVICE

If you are using the soundbar for the first time, you may be required to set up the device as your system's default playback device.



1 For Windows PC users




2 For MAC users

ENABLING DOLBY ATMOS

Please be noted, Dolby Atmos is only available via HDMI output. If you are using the soundbar for the first time, you may need to enable Dolby Atmos on your gaming console or PC. For more instructions, please go to below sites:

<https://games.dolby.com/atmos/documentation/#Platforms>


1 WHAT'S INSIDE





2 BUTTONS



3 LEDS




4 CONNECTION



5 The display screen on the soundbar will show **LINKED**, while there will be solid white on the LINK button of the Satellite Neck Speaker indicating the solid connection.


5 ADJUSTING THE VOLUME

You can adjust the volume on the OXS Satellite Neck Speaker in the menu of the OXS Thunder Bar.




6 CHARGE

Charge your OXS Satellite Neck Speaker quickly and easily with the included USB-C to C cable. For fastest charging, use a Quick Charge compatible adapter.



7 AUTO-STANDBY


The satellite neck speaker automatically turns off with the soundbar (when plugged in) and powers back on when the soundbar does.



Notes:

Wired Operations: This feature requires the neck speaker to be plugged into an adapter.

Wireless Power Saving: The neck speaker turns off after 15 minutes of inactivity on battery power.



FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC and ISED Radiation Exposure Statement

This equipment complies with FCC and ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement est conforme aux limites d'exposition au rayonnement FCC et ISED établies pour un environnement non contrôlé, cet équipement devrait être installé et exploité avec une distance minimale de 20cm entre le radiateur et. Votre corps.

ISED STATEMENT:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux normes RSS exemptées de licence d'innovation, sciences et développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Thank you for purchasing this OXS product.

To receive more complete service, please follow us at www.oxsaudio.com

制造商:深圳雷戈创新科技有限公司

地址:深圳市龙岗区园山街道荷坳社区龙岗大道8288号大运软件小镇17栋105

製造商:深圳雷戈创新科技有限公司


地址:深圳市龍崗區園山街道荷坳社區龍崗大道8288號大運軟體小鎮17棟105

Manufacturer: ShenZhen Rango Innovation Technology Co., Ltd


Address: Room 105, Building 17th, Dayun Software Town,

No. 8288 Longgang Avenue, Longgang District, Shenzhen, China 518115


内容物



音箱主机




OXS 定制线




电源适配器×1




电源线×1



HDMI 线×1



光纤线×1




USB C to C 线×1




遥控器

产品图解



1		天空声道单元	7		HDMI 输入
2		高音单元	8		副音箱输出
3		低音单元	9		Optical 输入
4		发射器插座	10		电源输入
5		USB-C 输入	11		副音箱输入
6		HDMI eARC	12		低音倒相孔


遥控器图解



1	静音
2	增加音量
3	电源
4	上一曲
5	播放暂停
6	下一曲
7	音效切换
8	音量减少
9	输入切换
10	灯光动作
11	灯光模式
12	灯光颜色
13	增加低音
14	减少低音
15	增加高音
16	减少高音
17	增加天空音
18	减少天空音

使用指引

摆放建议




摆放


通常情况下，确保摆放位置水平，确保摆放区稳定无松动
如增加支架高位摆放，建议调节摆放平面为前倾8°
左右音箱间距在1米-2米为宜，如更大间距，需要购买专用线材

2


正面请勿遮挡，顶部请勿遮挡，音箱背后
距离墙壁请保持15CM以上，请勿靠近墙角摆放
平整的天花板可获得更好的天空反射效果



3 连接电源




4 上电自动开机




ENG-08

连接说明


连接 HDMI eARC/ARC



1 使用HDMI线连接电视机eARC口




2 切换到eARC模式，输入键白色灯




ENG-09

连接 HDMI IN




① 连接游戏主机或PC的HDMI输出



② 连接游戏主机或PC的HDMI输出


Method A




③ 切换到HDMI输入，按键绿色

ENG-10


通过 USB-C 线连接



① 大部分数码设备均可使用USB连接




切换到USB输入，灯光紫色



ENG-11


通过光纤OPTICAL连接




可以连接各种数字输出的光纤设备 (例如Xbox One)

Method A

Method B




② 切换到光纤模式，灯光黄色



使用蓝牙 Bluetooth连接


Method A

Method B



BT

① 切换到蓝牙输入，灯光蓝色




使用手机搜索连接


连接过后会自动回连已有设备

如何设置设备音频输出

Windows设备请在右下角选择设备名字
your system' s default playback device.



1 Windows 用户参考



2 MAC 用户参考

如何启动杜比全景声 DOLBY ATMOS

请保证您的播放内容为正版杜比影片，音乐或游戏
更多信息请访问杜比官方网站by Atmos on your gaming console
or PC. For more instructions, please go to below sites:

<https://games.dolby.com/atmos/documentation/#Platforms>

1 内容物




2 按键




3 指示灯




4 连接




1. 在主机背面插入发射器




2. 打开卫星颈枕电源



3. 长按连接键
Speaker.





4. 触发主机连接
Thunder Bar.



5.

5 控制音量



2.



3. 请用OXS APP调节颈枕音量

⑥ 充电

使用普通C口充电，支持QC快充协议
with the included USB-C to C cable. For fastest charging, use
a Quick Charge compatible adapter.

⑦

