


AGE 14+

GPS DRONE USER MANUAL



Thank you for purchasing our GPS Drone. Please read all instructions and warnings carefully before operating. Please also keep this instruction manual for future reference and maintenance.

IMPORTANT

- This product is not a toy. It is a precision device, integrating machinery and electronics with air mechanics and high frequency transmission. It requires correct assembly and debugging to avoid any accident. The user should operate and control the product in a safe manner. In case of incorrect operation, it may cause serious injury or property damage. It can also be lost due to incorrect operation.
- This product is suitable for those who are experiencing operating UAV and age no less than 14 years old.
- In the event of a problem during using, operating, or maintenance, please contact the local sales agent or retailer or keep in touch with the responsible staff of our company.
- Small parts are included with this product. Please place it beyond the reach of the children to avoid a CHOKING HAZARD or parts being mistakenly swallowed.

INTRODUCTION SAFETY PRECAUTIONS

This RC flying model can be dangerous when in use. Please make sure you keep it far away from any person or spectators when flying. In correct installation, poor conditions, poor operation or familiar with operation may cause damage to the air area and injure people or may cause an unexpected accident. Please pay close attention to flying safety and learn to recognize more dangerous conditions which may cause an accident due to your own negligence.

This RC aircraft may vary slightly in speed or sensitivity while flying and can cause potential danger. Therefore, please keep it far away from crowds, buildings, trees, structures, high voltage wire, etc. Please also avoid flying in adverse weather conditions such as rain, electrical storms, and high winds to ensure safety of the user, any spectators, and surrounding property.

Keep it away from any moist environment.

The inside of the aircraft is composed of many precision electronic and mechanical parts. Therefore, please try to avoid any moisture or water content from entering the aircraft, any spectators, and surrounding property.

Only operate with included parts for intended use.

Please use the original parts for any re-assembling or maintenance to ensure flying safety. Please operate and use only under the scope of the product function permitted. Using unapproved parts may cause a breakdown of the mechanical and electronic parts and thus cause an accident.

Avoid controlling it independently.

New users may have certain difficulties during the early stages of learning to operate this aircraft. Please try to avoid operating the aircraft alone. When available, always operate this aircraft under the guidance of a more experienced user.

Do not operate under the influence of drugs or alcohol.

Please operate this RC aircraft according to your own state and flying skills. Any fatigue, bad mental state, or incorrect operation may increase the probability of an accident risk.

Please keep a safe distance from aircraft when using top speed.

When the drone is flying, please keep the drone far from the operator and any surrounding persons or objects to avoid any risk of damage or injury.

Store it in a cool dry place.

The RC aircraft is composed of material such as metal, fiber, plastic, electronics, etc. Therefore, please keep it away from any heat source and avoid prolonged exposure to direct sunlight. Excessive heat exposure can cause distortion and damage.

Please read this manual carefully before operation and keep it properly for future reference.

AGE 14+

GPS无人机 飞控说明书



根据中国民用航空局相关规定，无人机所有者需到民航局的无人机进行实名登记，登记后可获得国家有关部门颁发的飞行执照。飞行安全飞行，登记网址 <https://uac.caa.gov.cn> 欢迎选购本产品，为了您能更好地使用本产品，请仔细阅读本说明书，以便正确使用本产品，同时请妥善保管好说明书，作为以后维护及维修的参考。

重要提示

- 本产品不是玩具，而是集机械、电子、空气力学、高级编程等专业知识于一体的精密设备，需正确组装和调试才可能避免事故发生。该产品持有人必须使用安全的方式来控制操作；操作不当，可能导致严重的人身伤害或财产损失。
- 本产品属于手持飞行模型，使用时请务必保持清醒头脑，切勿在酒后、疲劳、情绪不佳、注意力不集中、或身体不适的情况下使用。
- 如使用、操作、维修等问题，请与当地经销商或本公司相关人员联系。
- 产品含有小零件，请将其置于小孩不能触及的地方，以免发生误食或窒息危险。

安全注意事项

遥控飞行器属于最高危险性产品，飞行时必须远离人群，人为失误可能造成财产损失、人员伤亡、财产损失、以及财产损失。请务必按照飞行说明书中的安全警告和注意事项，谨慎操作。飞行安全飞行，请务必按照飞行说明书中的安全警告和注意事项，谨慎操作。飞行安全飞行，请务必按照飞行说明书中的安全警告和注意事项，谨慎操作。

重要提示：

- 起飞无人机时，确保操作者离飞机3米之外，飞行时必须远离人群及财物；
- 请操作飞行器务必按照说明书的要求操作，注意飞行安全，必需了解自身技能，勿造成意外责任；
- 起飞前请确保GPS校准已成功且卫星数量大于10颗；
- 本产品提供室内模式和室外GPS两种飞行模式，两种模式手动切换，起飞前请根据飞行环境选择相应的飞行模式。

请在飞行前仔细阅读说明书并妥善保管以便日后参考。

KNOW YOUR DRONE

