kaiboaudio

【产品使用手册】


Buds Plus

真无线骨传导耳机

TWS BC EARBUDS

@kaiboaudio

配件清单



- 耳机：1对




- 充电盒：1个
- 鲨鱼鳍：1对
- 充电线：1条
- 布袋：1个

注：本说明书中的图片均为示意图，可能与实物有偏差，请以实物为准

设置你的 Buds Plus

1.充电

- 耳机充电：
  当听到"Battery low"提示音时，提示耳机需要进行充电。将耳机放入充电盒中，合上盖子即可充电。耳机充电时红灯常亮，耳机充满电后红灯灭。
- 充电盒充电：
  通过Type C充电线给充电盒充电，充电时充电盒红灯闪烁，充满后熄灭。



注意：必须选择正规厂家生产且经过国家CCC认证的充电器

2.配对

打开充电盒上盖，取出耳机，双耳红绿交替快闪进入自动配对模式，即可进入蓝牙搜索。



3.链接手机

打开手机或其他设备蓝牙设置，搜索蓝牙名称"Buds Plus"，点击耳机连接蓝牙，听到语音提示"connected"，这时耳机连接成功，指示灯灭。若超过3分钟没有连接到蓝牙，耳机将会自动关机左右耳机均可以分开单独连接其他蓝牙设备使用。



耳机触摸功能说明

模式	功能	操作
音乐模式	播放 / 暂停	双击左耳机或右耳机
	上一曲	长按左耳机2秒
	下一曲	长按右耳机2秒
	音量 +	单击右耳机
	音量 -	单击左耳机
电话模式	接听/ 结束电话	双击左耳机或右耳机
	拒接电话	长按左耳机或右耳机2秒
语音助手模式	唤醒语音助手	三击左耳机或右耳机/语音直接唤醒
开关机与移除模式	开机	同时长按两只耳机7秒
	关机	同时长按两只耳机7秒
	清除配对信息	关机状态下同时长按两只耳机10秒

注意：音量调节功能（音量+/-）可同时使用手机端操作或是采用手机上的语音助手来驱动。



LED指示灯说明

充电状态

充电盒	红灯闪烁	充电中
	红灯灭	充满电
耳机	红灯常亮	耳机在充电盒充电中
	红灯灭	耳机在充电盒充满电

电量状态

耳机低电位状态	耳机自带语音提示 / 红灯每十秒闪一次
充电盒低电位状态	充电盒关盖时红灯闪烁3次
充电盒高电位状态	充电盒开关盖时绿灯长亮10秒后熄灭
注意：拔下电源插头后，LED灯会熄灭	

蓝牙连接状态

红绿灯交替闪烁	耳机待连接配对状态
灯灭	耳机配对成功
红绿灯交替闪烁	耳机配对断开



请注意：充电盒不支持快速充电，当耳机放入充电盒便开始充电。

规格

型号 ： Buds Plus		扬声器 ：	骨传导扬声器
频段 ：20Hz~20KHz		蓝牙连接距离 ：	无线传输范围10米
蓝牙版本 ： V5.2 立体声			
蓝牙协议：支持HSP、HFP、A2DP、AVRCP			
耳机电池容量 ：	70mAH	充电盒电池容量 ：	500mAH
耳机充饱时间 ：	约90分钟	充电盒充饱时间 ：	约60分钟
耳机播放时间 ：音乐播放时间约7小时，通话时间约7小时。（充电盒给耳机充电大约可充3~4次）			
麦克风灵敏度 ：-40dB ± 2dB		防水等级 ：	IP55
耳机重量 ： 15.5g		充电盒重量 ：	51g

储存和维护

- 该耳机是防水跳的，但并不完全防水。请不要将耳机浸入水中。
- 过高音量下听音乐可能会损伤您的听力。
- 存储很长一段时间后，请在使用前再次充电。充电之前保持充电口干燥会降低耳机损坏的风险。
- 注意置放环境在过冷、过热或过度潮湿环境可能会缩短电池的寿命。充电之前保持充电口干燥会降低耳机损坏的风险。
- 充电盒充电电压/电流5V/1A。

注意：首次使用本产品请充满电给您更好的体验如长时间内不使用，请每月至少充电一次以延长电池寿命。

kaiboaudio

【產品使用手冊】


Buds Plus

真無線骨傳導耳機


TWS BC EARBUDS

@kaiboaudio

配件清單



- 耳機：1對




- 充電盒：1個
- 鯊魚鰭：1對
- 充電線：1條
- 布袋：1個

注：本說明書中的圖片均為示意圖，可能與實物有偏差，請已實物為準

設置你的Buds Plus

1.充電

- 耳機充電：
  當聽到"Battery low"提示音時，提示耳機需要進行充電。將耳機放入充電盒中，合上蓋子即可充電。耳機充電時紅燈常亮，耳機充滿電後熄滅。
- 充電盒充電：
  通過Type C充電線給充電盒充電，充電時充電盒紅燈閃爍，充滿後紅燈滅。



注意：必須選擇正規廠家生產且經過國家NCC認證的充電器

2.配對

打開充電盒上蓋，雙耳紅綠交替快閃進入自動配對模式，即可進入藍牙搜索。



3.鏈接手機

打開手機或其他設備藍牙設置，搜索藍牙名稱"Buds Plus"連接藍牙，聽到語音提醒"connected"連時耳機連接成功，指示燈滅。若超過3分鐘沒連接到藍牙，耳機將會自動關機。
左右耳機均可分開單獨連接其它藍牙設備使用。



耳機觸摸功能說明

模式	功能	操作
音樂模式	播放 / 暫停	雙擊左耳機或右耳機
	上一曲	長按左耳機2秒
	下一曲	長按右耳機2秒
	音量 +	單擊右耳機
	音量 -	單擊左耳機
電話模式	接聽 / 結束電話	雙擊左耳機或右耳機
	拒接電話	長按左耳機或右耳機2秒
語音助手模式	喚醒語音助手	三擊左耳機或右耳機/語音直接喚醒
開關機與移除模式	開機	同時長按兩只耳機7秒
	關機	同時長按兩只耳機7秒
	清除配對信息	關機狀態下同時按住兩個耳機10秒

注意：音量調節功能（音量+/-）可同時使用手機端操作或採用手機上的語音助手來驅動



LED指示燈說明

充電狀態


充電盒	紅燈閃爍	充電中
	紅燈滅	充滿電
耳機	紅燈常亮	耳機在充電盒充電中
	紅燈滅	耳機在充電盒充滿電

電量狀態

耳機低電位狀態	耳機自帶語音提示 / 紅燈每十秒閃一次
充電盒低電位狀態	充電盒關蓋時紅燈閃爍3次
充電盒高電位狀態	充電盒開關蓋時綠燈長亮10秒後熄滅
注意：拔下電源插頭後，LED燈會熄滅	

藍牙連接狀態

紅綠燈交替閃爍	耳機待連接配對狀態
燈滅	耳機配對成功
紅綠燈交替閃爍	耳機配對斷開



請注意：充電盒不支持快速充電，充電盒合蓋時，耳機在充電。

規格

型號 ： Buds Plus		揚聲器 ：	骨傳導揚聲器
頻段 ： 20Hz~20KHz		藍牙連接距離 ：	無線傳輸範圍10米
藍牙版本 ： V5.2 立體聲			
藍牙協議：支持HSP、HFP、A2DP、AVRCP			
耳機電池容量 ：	70mAH	充電盒電池容量 ：	500mAH
耳機充飽時間 ：	約90分鐘	充電盒充飽時間 ：	約60分鐘
耳機播放時間 ：音樂播放時間約7小時，通話時間約7小時。（充電盒給耳機充電大約可充3~4次）			
麥克風靈敏度 ：-40dB ± 2dB		防水等級 ：	IP55
耳機重量 ： 15.5g		充電盒重量 ：	51g

儲存和維護

- 該耳機是防水跳的，但並不完全防水。請不要將耳機浸入水中。
- 過高音量下聽音樂可能會損傷您的聽力。
- 存儲很長一段時間後，請在使用前再次充電。充電之前保持充電口乾燥會降低耳機損壞的風險。
- 注意置放環境在過冷、過熱或過度潮濕環境可能會縮短電池的壽命。充電之前保持充電口乾燥會降低耳機損壞的風險。
- 充電盒充電電壓/電流5V/1A。

注意：首次使用本產品請充滿電給您更好的體驗如長時間內不使用，請每月至少充電一次以以延長電池壽命。

NCC警語、保固說明及注意事項

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自 變更頻率、加大功率或變更原設計之特性及功能。低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

kaiboaudio

【User Manual】

Buds Plus

TWS BC EARBUDS

Thank you for purchasing a pair of Kaibo Buds!
To give us feedback, find out more about upcoming product releases, and join our growing community, please connect with us on social media!

@kaiboaudio

What's in the box

1 pair earbuds

charging case: 1 piece	removable ear fins:1 pair	USB Type-C charging cable: 1 piece	carrying pouch: 1 piece

Note: The pictures in this manual are all schematic diagrams, which may deviate from the actual product; please refer to the actual product.

Quickly Set Up Your Buds Plus

- Charging :
  - Earphones charging:
    When you hear "Battery low",the headset needs to be charged.Place earphones in the charging case and close the cover to charge them. When earphones is charging, the red light keeps on. After earphones are fully charged, the indicator is off.
  - Case charging:
    Charge the case through the Type-C charging cable. When charging, the red light of the case blinks, and the red light is off after it is full.

- Pairing :
  When opening the cover of the case, red and green lights of the two earphones alternately blink to enter the automatic pairing mode, then you can enter the Bluetooth search state.

- Connect :
  Activate the Bluetooth settings of your phone or other device, search for the bluetooth name"Buds Plus", click the phone to connect to bluetooth, hear the voice prompt "connect", it means that the bluetooth connection is successful, then light is off. If earphones are not connected to bluetooth for more than 3 minutes, earphones will automatically shut down. The left and right earphones can be separately connected to other Bluetooth devices.

Smart Touch Guide

Mode	Punction	Punction
Music	Play/Pause Music	Double TAP on left or right bud
	Play Previous	PRESS left bud for 2 seconds
	Play Next	PRESS right bud for 2 seconds
	Volume +	PRESS right bud for 1 second
	Volume -	PRESS left bud for 1 second
Calls	Answer/End Call	Double TAP on left or right bud
	Decline Incoming Call	PRESS left or right bud for 2 seconds
Voice Assistance	Arouse Voice Assistance	Triple TAP on left or right bud or Voice direct arouse
Set-Up	Turn On	PRESS each bud for 7 seconds (left and right buds need to be turned on separately)
	Turn Off	PRESS left or right bud for 7 seconds
	Remove Existing Bluetooth Connections	Press both earbuds for 10 seconds at the same time in the off state

Note:The volume adjustment function(Volume +/-)can be simultaneously operated by the phone or driven by the Voice Assistance.

LED Indicator Guide

Charging Level

Case	Blinking Red	Charging
	None	Fully charged
Earbuds	Red	Charging
	None	Fully charged

Battery Level

Earbuds low battery	Earbuds built-in voice prompt or Red blinks every 10 seconds
Case low battery	Red blinks 3 times when case closed
Case full battery	Green stays on for 10 seconds and goes out when case opend or closed
Note:After unplugging the power plug, the LED will go out	

Bluetooth Pairing

Blinking Red and Green	Ready to pair
Lights Go Out	Pairing sucessful
Blinking Red and Green	Pairing disconnected

Note:Case does not support fast charging. When the charging case is covered, buds are charging.

Product Specification

Model: Buds Plus		Speaker: Bone conduction transducer	
Frequency:20Hz~20kHz		Bluetooth connection distance: > 10m	
Bluetooth version:V5.2 Stereo			
Bluetooth communication protocol:	HSP HFP A2DP AVRCP		
Headset battery capacity:70mA		Charging case battery capacity:500mA	
Headset charging time: about 1.5 hours		Charging case charging time: about 1 hour	
Headset usage time: Music plays for about 7 hours(average measured data at 70% volume); The call lasted about 7 hours. (Charging case can charge headset for about 3 to 4 times)			
Microphone sensitivity:-40dB±2dB		Headset waterproof rating: IP55	
Headset weight:15.5g		charging case weight:51g	

Storage and Maintenance

- The earphones can resist water and sweat, but not completely waterproof. Do not immerse the earphones into water.
- Listening to music at too high volume mayy damage your hearing
- After a long time of storage, please charge it again before use. Keep the charging port dry before charging. This will reduce the risk of damage to earphones.
- Be careful not to place earphones in excessively cold, hot, or humid environments. Otherwise, the battery life will be shortened
- The charging case's voltage/electric current is 5V/1A

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Non-modification Statement:
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
FCC Radiation Exposure Statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Still have questions?
We're here to help!

Check out our online FAQs at www.kaiboaudio.com

For the first time use this product, please fully charge it to give you a better experience. If you do not use it for a long time, please charge it at least once a month to extend the battery life.

kaiboaudio

【製品の取扱説明書】


Buds Plus

完全ワイヤレス骨伝導イヤホン

TWS BC EARBUDS

@kaiboaudio

パッケージ内容



- イヤホン本体：1ペア




- 充電ケース：1個
- マカセ：1ペア
- 充電ケーブル：1本
- 収納バッグ

注意：製品の取扱説明書写真はすべて概略図であり、実際の製品とは異なる場合があります。実際の製品を参照してください。

Buds Plusを設定します

1.充電

- イヤホンの充電：
  「Battery low」のビープ音が聞こえたら、ヘッドセットを充電する必要があることを示しています。イヤホンを充電ケースに入れ、蓋を閉めて充電します。ヘッドセットの充電中は常に赤色のライトが点灯し、ヘッドセットが完全に充電されると赤色のライトは消灯します。
- 充電ケースの充電：
  タイプCの充電ケーブルで充電ケースを充電します。充電中は充電ケースの赤色のライトが点滅し、完全に充電されると赤色のライトが消灯します。



注意：正規のメーカーによって製造され、国のPSEによって認定された充電器を使用してください。

2. ペアリング

充電ケースを開くと、二つのイヤホンの赤と緑が交互にすばやく点滅して自動ペアリングモードになり、片方のイヤホンの赤と緑のライトがゆっくり点滅したらペアリングが成功したことを示します。Bluetoothで検索できます。



3. 設備と接続

スマートフォンまたはその他のデバイスのBluetooth設定を開き、Bluetooth名 Buds Plus を検索し、クリックして Bluetooth に接続し、"connected)という音声リマインダーを聞くと、ペアリング完了です。イヤホンを充電ケースに入れます。イヤホンがBluetoothに3分間以上接続されていない場合、イヤホンは自 動的にシャットダウンします。
左右のイヤホンは他のBluetooth デ バイスに個別に接続できます。



イヤホンのタッチ機能説明

モード	機能	操作
音楽モード	再生/一時停止	左/右イヤホンをダブルクリック
	前の曲	左イヤホンを2秒間長押しする
	次の曲	右イヤホンを2秒間長押しする
	音量＋	右イヤホンを1秒間長押しする
	音量－	左イヤホンを1秒間長押しする
通話モード	電話を受ける / 電話を切る	左/右イヤホンをダブルクリック
	着信拒否	左/右イヤホンを2秒間長押しする
音声アシストモード	音声アシストを起動	左のイヤホンまたは右のイヤホンをトリプルクリックします/音声起動
電源オン/オフと解除モード	電源オン	両方のイヤホンを同時に 7 秒間押し続けます
	電源オフ	両方のイヤホンを同時に 7 秒間押し続けます
	ペアリングモードをクリアする	電源がオフのときに、両方のイヤホンを同時に 10 秒間押し続けます。

注意：音量調整機能（音量+/-）は、携帯電話の操作または携帯電話の音声アシスタントによって同時に駆動できます



LEDライト説明

充電状態

充電ケース	赤く点滅	充電中
	赤信号オフ	充電完了
イヤホン	赤いライトが点灯	イヤホンが充電ケースの中で充電中
	消灯	イヤホンが充電ケースの中で 充電完了

電池残量

イヤホンの低電力状態	イヤホンに音声提示（赤いライトが10秒間ごとに点滅する
充電ケースの低電力状態	充電ケースを開じる時に赤いライトが3回点滅します
充電ケースの高電力状態	充電ケースを閉じる時に緑ライトが 10秒間点灯した後消灯します
注意：電源コードを外した後、LEDライトは消灯します	

Bluetoothの接続状態

赤緑ライトが交互に点滅	イヤホンはペアリング待ちの状態
緑ライトが5秒ごとに点滅する	イヤホンのペアリングが成功した
緑ライトがすばやく点滅した後、赤緑ライトが交互に点滅する状態に戻る	イヤホンのペアリングが切れた



ご注意：充電ケースは急速充電ができません。充電ケースの蓋が閉じる時、イヤホンは充電中です。

製品スペック

型番： Buds Plus		スピーカー：骨伝導スピーカー	
周波数：20Hz~20KHz		Bluetooth接続範囲：10メートル	
Bluetoothバージョン：5.2			
Bluetoothプロトコル：HFP、HSP、A2DP、AVRCP			
イヤホンバッテリー容量：70mAH		充電ケース/バッテリー容量：500mAH	
イヤホン充電時間：約90分		充電ケース充電時間：約60分	
イヤホンの再生時間：音楽再生時間は約 7 時間、通話時間は約 7 時間（充電ケースはイヤホンに約3-4回分充電可能）			
マイクの感度：-40dB ±2dB		防水レベル：IP55	
イヤホンの重量：15.5 g		充電ケースの重量：51g	

保存とメンテナス

- このイヤホンは水しぶきは防げますが、完全に防水してありません。水の中にイヤホンを浸さないでください。
- 大音量で音楽を聞くと、聴力が低下し、音が歪む場合があります。
- 長期間保管した後は、使用する前に再充電してください。充電する前に充電ポートを乾いた状態に保つと、イヤホンが損傷するリスクが軽減されます。
- 低温、高温、多湿の環境に置くと、バッテリーの寿命が短くなる場合がありますのでご注意ください。充電する前に充電ポートを乾いた状態に保つと、イヤホンが損傷するリスクが軽減されます。
- 充電ケースを充電する際には電圧/電流5V / 1Aの充電器を使用してください。

For the first time use this product, please fully charge it to give you a better experience. If you do not use it for a long time, please charge it at least once a month to extend the battery life.