



Gateway®

Quick Start Guide
Desktop

Warning:

When connecting keyboards, mice, monitors, and other devices to the host, make sure that your monitor and host are powered off and do not operate with power on.


1 Connect keyboard and mouse

Insert the wireless receiver into any of the USB ports or other device USB ports (No driver setup is necessary)

Notice: There is only one wireless receiver for this combo. The wireless receiver is located inside the mouse battery compartment. Users must open the bottom cover underneath the mouse to access the wireless receiver.


2 Connect to the computer host

Please connect the monitor to the computer host using the included monitor cable as shown in the diagram, and connect the monitor to a power outlet using the included power cord.



Caution: The AC adapter included with your PC was specifically designed and approved for your model. Utilization of an after-market adapter may damage either the notebook or other devices connected to it. If damage is determined to have been caused by utilization of an unauthorized power supply, it will not be protected under warranty. For our FAQ, please visit www.gatewayusa.com, click on the Support Tab, click on General. Gateway and the Gateway logo are the registered trademarks of Acer Inc. and are used under license from Acer America Corporation.

www.gatewayusa.com | Customer Service: support@gatewayusa.com



What's in the box

- | | |
|------------------------|---------------------|
| 1 Desktop | 3 Quick Start Guide |
| 2 Keyboard & Mouse Set | 4 AC wire |

FCC regulatory conformance :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a **Class B** digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user ' s authority to operate the equipment.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

RF Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.