

尺寸: 100*100mm_157G铜版纸，黑白印刷，5折页

Xnjun

LX1

Quick
Start
Guide

► For TV Box

Packing list




BOX 1pcs



Remote 1pcs



Quick Start Guide 1pcs



HDMI Cable 1pcs



Electric source 1pcs




Batteries 2pcs

Remote




1. **POWER** - Switch on or switch off receiver.
2. **MUTE** - Switch on or switch off receiver's sound.
3. **FIND** - Search channel, program or application.
4. **0-9** - Numerical key.
5. **Subtitle** - Display Subtitle information of channel.
6. **FAV** - A shortcut to the favorite channel list.
7. **Group** - A shortcut to channel group list.
8. **▲/▼** - Page up/down.
9. **🔊** - Adjust receiver's volume.
10. **EPG** - Display Electronic program Guide information.
11. **INFO** - Display detailed information of channel, program or application.
12. **◀/▶** - Moving the highlight to left/right.
13. **▲/▼** - Moving the highlight to up/down.
14. **OK** - Confirm the selection.
15. **MENU** - The entry of application's functions.
16. **BACK** - Back to the previous menu.
17. **COLORIZED KEYS** - Entries of application's key functions.
18. **RECORD** - Record program to local storage such as USB stick.
19. **PLAY** - Start to play media.
20. **PAUSE** - Pause the playing of media.
21. **STOP** - Exit the playing of media.
22. **Live** - Shortcut to live channel.
23. **VOD** - Shortcut to VOD.
24. **Series** - Shortcut to SERIES.
25. **Radio** - Shortcut to Radio.


Front Panel



Rear Panel




Side Panel



Preparation

1. **Connecting Internet cable**
Connect Ethernet cable to the 'Ethernet' Port of the rear panel of the box.
2. **Connecting the TV**
Connecting TV via HDMI cable.
3. **Power ON/OFF**
There are several ways to turn the box ON or OFF.
 - **Complete Power Shutdown**
Remove the power supply, it takes a longer time to boot the system if you turned it off by this way.
 - **Standby Mode**
Press the **POWER** button to turn the box on or off.
The box includes a standby mode for lower power consumption which locates at **[Setting >System Options>Real standby]**.
If **Real standby** set to **OFF**, the system is not completely shutdown and thus it takes a few seconds to restart.




First Time installation

When you switch the box on for the first time, the easy installation starts automatically with the language selection.


1. Language Selection

Use **▲/▼** button to scroll up and down to select the desired language and confirm with **OK** button.




2. Press ► button to go to next region setting.

Use **▲/▼** button to scroll up and down to select the desired time zone and confirm with **OK** button.




3. Press ► button to go to next search setting.

Use **▲/▼** button to scroll up and down to setup the portal URL etc



4. Full Settings Menu.

After installation guider, you can enter the Settings menu through Main menu and set everything what you may need.



Specifications

Main Processor	Quad Core A53 CPU
Flash Memory	EMMC : 8GByte
DDR SDRAM	2GByte
Input Voltage	DC 12V/1A
Power Consumption	MAX: 12W Standby:<0.5W
Network	LAN: 100Mb
USB	Two USB 2.0 host
HDMI	VER1.4b
Operation Temperature	0°C~+45°C
Storage Temperature	-10°C~+70°C

Trouble shooting

Before you contact your local service center, please read the following tips carefully.

1. **No video on TV**
 - Check first if the product is powered on and in operational mode.
 - Check if the video cable is properly connected between TV and the box.
 - Check if the internet cable is properly connected between Router and the box.
2. **Problem with audio quality**
 - Check if your audio cable is connected correctly.
 - Check the volume level of your TV and the box.
 - Check if the box or TV is on mute.
 - Check the audio option if it is correctly selected for the program that you are currently watching.
3. **Poor audio and video quality**
 - Check if the internet cable is properly connected between Router and the box and the internet bandwidth is enough.
4. **Remote control problem**
 - Check if the battery is low power.
 - Point the remote control directly toward the box.
 - Make sure that nothing blocks the front panel display.
5. **Recording problem**
 - Check if the HDD has a sufficient space for recording.
 - Check if there is a conflict between recordings.

NOTICE

- Specifications are subject to change without further notice.
- The manufacturer does not assume any responsibility regarding any errors or mistakes in printing.
- Please note that a new software may change the features of the receiver.
- The manufacturer holds the rights of changes without any further notice.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.