


 + LEYU SMART - F300

To connect the device, follow step 1.



~5 cm

1

Connecting devices
Install F300 in the headset box, open the headset box, then go to Bluetooth settings and select F300.



● ▶ ||

Click play pause.

● ● ||||


Press the left ear twice to decrease the volume, Press the right ear twice to increase the volume.

● ● ● ◀▶


Press the left ear three times to jump to the next song, Press the right ear three times to jump to the previous song.

🎤

Long press for 2 seconds to enter the voice assistant.



Headset charging.
F300 needs to be charged in the headphone box, which uses the type-C connector to charge.



Replace the earplug.
Pull the earplug down. To fit the earplug, push it in.

FCC Statement
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


LEYU SMART

F300 instructions

70.00 mm

70.00 mm