




Electric Three-wheel Scooter Instructions for Use

MODEL:YD350DH-C



Tips: Before using this product, you must carefully read all contents of this instruction manual. Please keep it properly after reading. Do not use the electric scooter until you understand its characteristics.

Dear User,
Thank you for your trust in Yadea Electric Vehicles!

These instructions contain important safety precautions to help you improve your driving safety. The more you know, the more safely you will drive. This manual is a part of the whole vehicle. When selling or lending this vehicle, please transfer this manual to the new users.

Please purchase Yadea electric scooters (hereinafter referred to as scooters) through regular channels, and properly keep the invoice as the warranty certificate. Accessories that are not approved by the manufacturer shall not be used. Therefore, it is recommended to use the "Yadea Spare Parts for Yadea Products".

Please follow the instructions in this manual to complete the maintenance work on schedule. If you find problems during the use of the product, please contact the authorized service station or the company, and we will provide you with high-quality service.

The copyright of this manual belongs to Yadea Technology Group Co., Ltd. (hereinafter referred to as "Yadea Group" or "The Company"). Reprinting is not permitted without the written consent of the Company.

Please enjoy the fun of riding a Yadea electric scooter!

Directory

1 Safety Precautions	01
2 Product Accessories	02
3 Spare Parts Description	02
4 Control Panel Display and Operation	03
5 Scooter Assembly	03
6 Battery Charging	03
7 Proper Driving	04
8 Security Warning	04
9 Folding and Carrying	05
10 Table of Technical Parameters	05
11 Trouble-Shooting	05
12 Repair and Maintenance	06
13 Trademark and Legal Statement	06
14 Safety statement	07


1. Safety Precautions

- 1) A scooter is an entertainment product. Before you master your driving skills, please follow the instructions to practice. Yadea Group will not be held liable for any loss or injury caused by your lack of driving experience or failure to follow the instructions.
- 2) When driving this scooter, follow the instructions and warnings in this manual to reduce the risk, although it is not possible to eliminate it completely, because there will always be a risk of losing control, colliding or falling. When you enter a public place, you must comply with local laws and regulations. When driving a scooter-like any other vehicle-, the faster it goes, the longer the braking distance is. Emergency braking on slippery ground may cause wheels to slip or fall.
- 3) Always exercise caution and keep a safe distance from pedestrians or vehicles while driving. Be alert and slow down when driving into unfamiliar areas or complex terrain. When driving at night, it is recommended to wear reflective clothing, keep alert, and go at low speed.
- 4) You must wear protective equipment for head, elbows, hands/wrists and knees when driving.
- 5) When driving, please respect pedestrians' right of way. When walking in the same direction, the scooter should ride on the left. When facing to pedestrians, ride on the right. Reduce the speed to avoid scaring pedestrians. In other cases, please comply with local traffic laws and regulations.
- 6) When driving, the scooter shall drive in lanes for non-motorized vehicles. In case of only motorized lanes, drive on the right side of the lanes.
- 7) In areas where there are no scooter-related laws and regulations, please observe the safety requirements for drivers in this manual. Yadea Group shall not be held liable for any loss of property, accident, personal injury or legal dispute resulting from non-compliance.
- 8) Do not lend your scooter to someone who has not read this manual. If the product is lent out, you shall help novices to use the product until they learn its basic operation. Ensure that novices wear helmets and other protective equipment during learning and use.
- 9) Before each drive, check for loose fasteners and damaged parts. Check the whole vehicle's electric circuit, and the front and rear lights. Check the brake condition. If the scooter makes an abnormal noise or alarm, stop driving immediately and contact the authorized service station in the area or the Company.
- 10) Do not drive in bad weather such as: storm, rainstorm, fog, ice or snow.
- 11) This product is only for human driving. You must always wear shoes when driving; no slippers are allowed. It is recommended that the maximum weight is 100Kg and the maximum height is 200cm.
- 12) Do not charge the scooter when the power charger or power outlet are wet. Please read the instructions before charging.
- 13) When charging, use only the matching power charger provided by Yadea. Do not use any other power charger.
- 14) Use only spare parts approved by Yadea. Do not modify your scooter; modifications to the scooter may result in serious damage or injury, invalidating the warranty.
- 15) This product must be stationed on a floor with flat surface to prevent it from tipping over.
- 16) In order to reduce the risk, please read and observe all "Cautions" and "Warnings" in this manual. Do not drive on roads for motorized vehicles under any circumstances. The product is advised to use by persons in between 15 and 50 years old.

4. Control Panel Display and Operation

Display:

1. Headlamp On Display: When the headlights are on, the icons are illuminated.
2. Power Display: Real-time display of the remaining battery power.
3. Speed Display: Shows real-time speed and malfunction code.
4. Mileage: ODO shows total mileage; TRIP shows single mileage; short-press to switch display.
5. Up-shift/Headlight Button: Short-press to raise gear; long-press to turn on the headlights.
6. Down-Shift/Push-Vehicle: Short-press to lower the gear; long-press to switch to push mode in order to move the vehicle by using human force.
7. Key: key on/off.
8. Gear-Shift Mode: ECO for push-vehicle and low-speed mode; SPORT for medium-speed and sport mode; POWER for high-speed and power mode.
9. NFC Indicator: The display will illuminate after turning on the vehicle by swiping an NFC card.
10. Push Mode Display: It will illuminate after switching to push-vehicle mode.



Operation:

1. Power On: Short-press the button to power on, then swipe the NFC card.
2. Power Off: Long-press the button to power off.
3. Switch lights: Long-press the Up-Shift/Headlight Button to turn on and off the lights.
4. Shift gears: Short-press the Up-Shift/Headlight Button in the ECO-gear position and the Down-Shift/Push-Vehicle button in the POWER-gear position to increase and decrease the gear.
5. Boost: Press the down-shift/push-vehicle button under the ECO gear to bring the vehicle into boost mode.
6. Coupling the vehicle with an additional card (or a mobile phone): Short-press the Button to power the vehicle on; then long-press the Down-Shift/Push-Vehicle Button; the panel with the mother card shall display as "F3-F8"; then place the new card; if the display is empty (black screen), then the new card has been coupled with vehicle system.



Speed	Gear position	CE
	P	25km/h
	S	18km/h
	E	6km/h

Light	Gear position	Explanation for light indicators
	P	The rear taillight is blinking
	S	The rear taillight is steady on
	E	The rear taillight is blinking

(Press the and to switch to the British system, Notes: 1. Mobile phone coupling: The phone must provide an NFC function, which must be enabled for the vehicle to be coupled with the phone; the process to couple the mobile phone will be the same as coupling an additional card.


5 Scooter Assembly

1. Unfold the riser to its limit position, press down the fast-folding handle until you hear a "click" sound, and open the single support.




6. Battery Charging

1. Open the lid.



2. Connection of the charger: connect the battery to the charger before connecting the charger to the power outlet.
environmental conditions:
outdoor charging



Warning



* A steady red light indicates that the power charger is charging; a steady green light indicates that the charging is complete. After the battery is fully charged, interrupt the power supply in time. Please use the original power charger; otherwise, the battery will be damaged or in risk of fire.

2. Product Accessories

User data




attachment



When unpacking the scooter, check whether the accessories are complete. If missing or damaged, contact your authorized service station in the area. Once you're sure all the accessories are in order, you can assemble your scooter.
Please save the packaging materials for future shipment of your scooter.

3. Component Description




7 Proper Driving

Wear safety helmets and other protective equipment to minimize any possible damage.




1. Check the battery level. If the battery level is low, charge it in time. Place one foot on the foot-board, while the other foot is stepping back on the ground, to help the start of sliding to the front.




Note: For your safety, the scooter will not start until it reaches a speed of 1.86 mile/h (3 km/h).
For riding, please lift the locking handle; for parking, please clip the locking handle downward.

2. Place the ground-stepping foot on the foot-board, and keep a stable position. After achieving balance, press down the speeder to accelerate.



Warning
You may suffer serious injury from falling and losing traction when you brake suddenly. Maintain proper speed and be aware of potential hazards.

3. Deceleration is performed by loosening the speeder; hold the brake handle tightly to brake.



Instructions for operating parking : After power off, the handlebars and the center of the car, lower the limit handle, lock the brake parking button

8 Safety warning

1. Please do not ride on one foot.



Warning
Serious injury may result if one does not follow the rules.

2. Do not leave the handlebars with one or both hands while riding.

Warning
Please grip the handlebars with both

3. Do not press the governor when walking.

4. Do not drive onto motorway or highway.





5. Avoid obstacles when riding. Do not ride through puddles or any other obstacles. In this case, slow down and go around the obstacle.

6. Slow down when driving on speed bumps, thresholds, bumpy roads or other uneven surfaces.

7. When turning or turning, tilt your weight slightly toward the direction of steering and turn the car slowly. Please do not make sharp turns.

8. Large rotation of handlebars is prohibited at high speeds.





9. Do not ride in the rain.

10. Please pay attention to high obstacles to avoid collision.

11. Do not place heavy objects on the handlebars.

12. Scooters are for single riders only. No pairs riding. No carrying or carrying children.



13. Do not ride scooters, down steps or jump obstacles.

14. Please control the speed when going downhill and don't put your foot on the rear fender.

15. Do not look at your phone or wear headphones while riding.

16. Do not touch the wheel motor after riding, in case of burns.

