

VIVITAR®

CREATOR SERIES

Power Grip Charger

Power to Charge, Capture, and Create



Bluetooth®
Shutter Button



Powers
Devices



Built-In
Battery



Rubber
Grip

User's Manual

Item: VIRL5000KIT



Safety Precautions

Before setting up and using your Power Grip Charger, basic safety precautions should always be followed including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR CHARGER.
2. This product is not a toy, do not allow children to play with it. Adult supervision is advised.
3. This product should not be exposed to extreme heat or fire. Do not store in a location with temperatures above 104°F.
4. Do not expose this product to any water, liquids, or excessive humidity.
5. Do not crush, throw or subject this product to extreme physical force.
6. Do not use this product if it appears to be cracked or damaged.
7. Do not use in wet or humid environments. Do not place on wet surfaces.
8. Please recycle or dispose of the product properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of the product for further information.
9. To prevent damage to the product, always place it on a flat, even surface.
10. In order to avoid the risk of electric shock, never attempt to open your charger or repair it without the assistance of certified professionals.



CAUTION

BATTERY WARNING:

- The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
- Do not dispose of in fire or expose to excessive heat.
- Do not crush, puncture, incinerate, or short circuit external contacts.
- Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

Introduction

Thank you for purchasing the Vivitar Power Grip Charger, item VIRL5000KIT. Use the included supplies to assemble an all-in-one tripod, phone mount, phone charger and more. Please read this manual carefully before using.

Package Contents

- 1 Power Grip
- 1 Ball Head Mount
- 1 Smartphone Mount
- 1 Table Top Tripod
- 1 USB-A to USB-C Charging Cable
- 1 USB-C to USB-C Charging Cable
- 1 Micro-USB Cable
- 1 3/8" to 1/4" Adapter
- User's Manual with Warranty Information

Specifications


Power Grip Size: 12" x 1"
Cable Type: USB-C, USB-A
USB-C Charging Port: 5V 2A
USB-A Charging Port: 5V 1A

Battery: 5000mAh Lithium Polymer
Bluetooth Version: 5.0
Thread Holes: 3/8" & 1/4"

Charging

Connect the USB-C cable end (rounded connector) into the power grip's USB-C charging port. Connect the other USB cable end (rectangular connector) to a standard USB port or wall adapter.

Charging indicator lights will illuminate to show the charging status. Unplug once charging is complete.



Tripod Stand and Phone Mounting

The tripod stand and smartphone mount are included with your power grip.

To assemble the tripod stand and smartphone mount, screw on the tripod stand to the bottom of the power grip, then attach the smartphone mount to the top of the power grip.

Note: Attach your phone to the smartphone mount before assembly.



Bluetooth Connection

Wirelessly connect your power grip to your smartphone to capture photos and videos using the capture button on your power grip. Press and hold the capture button to activate Bluetooth. Open the Bluetooth settings menu on your smartphone to turn on Bluetooth, then connect the device listed as "IRL 5000". Press and hold the Capture button again to turn off Bluetooth.



Phone Charging

You can charge your phone while it is attached to the smartphone mount. Use one of the included charging cables to connect your phone to the power grip's USB-A port.

Notes: -Use your smartphone's original charging cable if the charging cables included with the power grip are not compatible. -The USB-A port can be used as a miscellaneous power port.



Ball Head Installation

For 360° swivel motion, attach the ball head mount. Screw on the ball head mount (2) to the top of the power grip (1). Then, attach the smartphone mount (3) to the top of the ball head mount. Loosen the side screw when adjusting the ball head mount and tighten to keep stable.



External Attachments

There are three threaded accessory mounts at the back of your power grip. If a male adapter is needed, use the included adapter to attach external devices such as lights, microphones, etc. Below is an illustrated example of how a video light attaches to the power grip.

On the top of the phone mounting accessory is a cold shoe where you can mount a ring lights, flashes or accessories with similar mounting attachments.



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 or visit our website at www.vivtar.com.

To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaid.

VIVITAR®

©2023 Sakar International
195 Carter Drive
Edison, NJ 08817
Support: 800 592 9541
www.vivitar.com