

F21

User Manual

WIRELESS SPEAKER

LENRUE Portable Speaker
Light Up Your Music and Life

Packing List

Specification

Version	Play Time	Battery Capacity
5.0	3-24H	2000mAh
Charging Time	Input	Wireless Range
3-4H	DC-5V/1A	33ft

Wireless Connection

1.Turn on the F21 Speaker 2.Pair the speaker with your devices

Diagram

English

Buttons

Button	Function	Detailed Operation
	Turn on/off Switch Play Mode TWS Connection/ Disconnect	Long press Short press Double Click
	Disconnection Devices Play/Pause Music Call Back	Long press Short press Double Click
	Volume up Next track	Short press Long press
	Volume down Previous track	Short press Long press
	RGB Light on/off Change Light Mode	Long press Short press

- Plug the USB-C charging cable on your speaker, the battery indicator glows red.
- When fully charged, the indicator goes out.

TWS Wireless Pairing

- Turn on two F21 speakers.
- Disconnect all devices with F21 speakers.
- Double click the power button " on the one of speaker into TWS pairing mode.

English

- TWS pairing will be finished after prompt.
- Click the device name "F21" to pair on.(Refer to page 2 "Wireless connection")

Alexa Connection

- Disconnect wireless speaker with all devices.
- Put your wireless device in pairing mode.
- Open the Alexa app, click the "Settings".
- Click Echo Dot device name.
- Click the "Wireless".
- Click the speaker name "F21" to pair the wireless speaker with Alexa.

Warm Note:

Thank you for choosing us!

Every order will enjoy following after-sale policy:
We hope you are satisfied with our products, more questions and problems, feel free contact us for help.
Each of your suggestions and ideas is very important to us. Welcome to share design suggestions to our via your order of shopping plat. and become an important promoter of our brand.

- 30 Days refund,
- 180 Days worry-free warranty,
- Lifetime technical support.

Use Tips:

- Full charge for first use
- Disconnect all device for Alexa Pairing

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.