

蓝悦F9(亚马逊 六人行) 说明书第二版  
材质:128g双铜+风琴折 四色印刷  
展开尺寸:260x86mm 折后尺寸:65x86mm  
料号: Y.047.0997

LENRUE


User Manual

F9  
WIRELESS  
SPEAKER




support@lenrue.com

►► Packing list



1 Speaker 2 Sucker 3 Safety Hook  
4 User Manual 5 Customer Service Card 6 Charging Cable

►► Play



Insert the power cable and the red light is on,  
○ When it is full of electricity, the light goes out.


►► Specifications

|                       |                    |
|-----------------------|--------------------|
| Device Name           | F9                 |
| Wireless Version      | V5.1               |
| Wireless Range        | 30ft               |
| TWS Range             | 10ft               |
| TF-Card Max Capacity  | 32GB               |
| True Wireless Pairing | Yes                |
| Charging Voltage      | DC-5V/1A           |
| Compatible Protocol   | A2DP/AVRCP/HFP/HSP |

►► Wireless Connection

Beep rings and the blue light turns into RGB light, success to connect.

1. Turn on/off 2. Pair with your device




►► Alexa Connection

1. Disconnect wireless speaker with all device.
2. Put your wireless device in pairing mode.
3. Open the Alexa app, click the 'Settings'.
4. Click the 'xx's Echo Dot.
5. Click the 'Wireless'.
6. Click the 'F9' to pair the speaker.

►► TWS Wireless Pairing

1. Turn on two F9 speakers.
2. Disconnect all devices with F9.
3. Short press the TWS button "TWS" on the one of speakers into TWS pairing mode.
4. TWS pairing will auto finish after "beep".
5. Click the device name "F9" to pair on.



PS:

- After using TWS for the first time, TWS wireless pairing will be automatically connected after the two speakers are turned on.
- After TWS wireless pairing, two speakers will mutual wireless synchronization.
- When one of the speakers is playing, the other speaker will also TWS automatically when it is turned on.

►► Warm Note:

Thank you for choosing us!  
Every order will enjoy following after-sale policy:

30 Days refund,  
180 Days worry-free warranty,  
Lifetime technical support.

Share advise for product and design, you will get  
365 Days Extended Warranty, contact us to collect it.

Use Tips:

- Full charge for first use
- Disconnect all devices for Alexa Pairing

Maintenance: After contacting the water source, please wipe / shake off the water stains in time to prolong the service life of the speaker.

►► FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.