

WARNING!
APPROPRIATE MAINTENANCE AND TAKING-CARE COULD EXTEND THE USAGE OF PRODUCT. PLEASE READ THE SECURITY DESCRIPTION BEFORE USING THIS PRODUCT.

1. FOLLOW THE STEPS BELOW BEFORE USING THE PRODUCT:

- CLEAN AND DISINFECTION ARE NECESSARY BEFORE USE, USE ANTIBACTERIAL SOAP OR CLEANING LIQUIDS WITH WARM WATER, DRY IT WITH TOWEL OR SOFT CLOTH.

2. DURING USING

- MASSAGE OIL OR HAND CREAM IS FORBIDDEN TO USE WITH THE PRODUCT.
- SILICONE SUBSTRATE LUBRICANT IS FORBIDDEN TO USE WITH THE PRODUCT, IT WILL HURT SILICONE SURFACE.

SECURITY INFO!

- THIS PRODUCT MAY HAVE SMALL COMPONENTS THAT HARM CHILDREN'S HEALTH, PLEASE KEEP IT AWAY FROM CHILDREN, SWALLOW BAG OR SMALL COMPONENTS CONTAINED MAY CAUSE CHOKE.
- USERS CAN'T CHANGE OR MAINTAIN ANY COMPONENTS, EXCEPT AUTHORIZED DISTRIBUTOR OR MAINTENANCE CENTER, IF ANY COMPONENTS OF YOUR PRODUCT NEED TO CHANGE IN ANY REASON, INCLUDE NORMAL ABRASION OR BREAKAGE, PLEASE CONTACT WITH YOUR LOCAL DISTRIBUTOR.
- DON'T USE IT IN ANY AREA (SUCH AS HOSPITAL & PLANE) THAT NEED TO SHUT DOWN ELECTRONIC EQUIPMENT OR RADIO FREQUENCY REMOTE PRODUCTS.

REMEMBER: DON'T CLEAN IT WITH DETERGENT CONTAINED ALCOHOL, GAS OR ACETONE, AVOID DIRECT SUN OR EXPOSING HIGH TEMPRATURE ENVIRONMENT, THIS PRODUCT SHOULD BE KEPT IN CLEAN AND DRY PLACE, AND DO NOT PUT TOGETHER WITH OTHER PLASTIC PRODUCTS.

BUILT-IN BATTERY MAINTENANCE

- BUILT-IN BATTERY MAINTENANCE: THE BATTERY INSIDE IS RECHARGEABLE AND IT CAN GET AGING AFTER RECHARGED FOR HUNDREDS OF TIMES PLEASE TAKE OUT THE CHARGER AFTER FULLY CHARGED OVER CHARGED MAY REDUCE THE USAGE LIFE OF THE BATTERY.
- FULL CHARGED BATTERY WILL LOSE POWER SLOWLY EVEN YOU DON'T USE IT.
- TOO HOT OR COLD ENVIRONMENT CAN REDUCE THE VOLTAGE OF BATTERY AND ALSO THE USAGE, IF THE BATTERY IS TOO HOT OR TOO COLD, THE USAGE TIME WILL DECREASE EVEN IF FULLY CHARGED.

BATTERY WARNING



- CAUTION-ANY WRONG OPERATION CASES WITH BATTERY MAY HAVE RISKS OF CAUSING FIRE OR CHEMICAL BURN, DAMAGED BATTERY HAVE RISK OF EXPLODING.
- PLEASE HANDLE THE BATTERY APPLY TO LOCAL LAWS, IF POSSIBLE PLEASE USE RECYCLE. USERS CAN'T TAKE OUT OR CHANGE BATTERY BY THEMSELVES, SUCH KINDS OF BEHAVIOR MAY CAUSE HAZARD AND BREAK THE PRODUCT.

IMPORTANT:



PLEASE CHECK USER GUIDE TO CHECK LIGHTS INDICATORS, SOME VIBRATORS CAN'T USE DURING CHARGE.

QUICK START GUIDE

NOTICE: CHARGE AND CLEAN IT BEFORE USING. ORIGINAL ADAPTOR FOR CHARGING SUGGESTED ONLY.



ITEM NAME: BS1004
SIZE: 89*44,5*32MM
74*35*94,5MM
MATERIAL: ABS + SILICONE
BATTERY CAPACITY: 240mAh
USAGE TIME: 2H
NOISE: <50dB
WATERPROOF: IPX7
RECHARGE TIME: 2H



1.VIBRATION MODE (8)

- NORMAL 1-3
- ENTHUSIASM MODE
- SHAKING MODE
- PLEASURE MODE
- PASSION MODE
- CLIMAX MODE



POWER (VIBRATOR)



VIBE PATTERN SWITCH: UP



VIBE PATTERN SWITCH: DOWN



POWER (REMOTE CONTROL)

2. BUTTONS FUNCTION

- ON&OFF THE VIBRATOR ----- LONG PRESS "⏻"
- ON&OFF THE CONTROL ----- CLICK "⏻"
- M1 UPWARD/CONVERSION TO EIGHT VIBRATION MODES ----- CLICK "⏻"
- M2 DOWN CONVERSION TO EIGHT VIBRATION MODES ----- CLICK "⏻"

3. LIGHTS INDICATOR

- POWER ON ----- LIGHT ON
- WORKING ----- LIGHT ON CONTINUOUSLY
- POWER OFF ----- LIGHT OFF
- CHARGING ----- LIGHT BLINK
- FULLY CHARGED ----- LIGHT ON ALL TIME

USAGE SCENARIO



1.NIPPLE CLAMP



2.CLITORIS STIMULATOR



3.SEX-ON-THE-GO VIBRATOR

CLEANING AND MAINTENANCE



1.WASH IT THOROUGHLY WITH DETERGENT AND CLEAN WATER



2.DRY IT WITH A CLEAN TOWEL



3.STORE IT IN COOL, DRY AND AIRPROOF

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction