




P1

REMOTE CONTROL FUNCTIONS


Power/Standby
INPUT: Switch between input modes: USB/SD/FM/
AUX/DVD/OPT/COAX/TV ARC/BT
MUTE: Mute all output
5.1/2.1: Channel mode select
SLEEP +/-: Setting the sleep time
SAVE: Save stations to unit memory
TUNE +/-: Manually tune FM stations
▶|: Play/Pause in USB/SD/BT modes
◀|: Previous FM station/previous track(USB/SD)
CH +/-: Next FM station/next track(USB/SD)
FL +/-: Front left speaker volume control
FR +/-: Front right speaker volume control
SW +/-: Subwoofer volume control
CEN +/-: Center speaker volume control
VOL +/-: Master volume control
SL +/-: Rear satellite left speaker volume control
SR +/-: Rear satellite right speaker volume control
0-9: Number pad used to direct select tracks when
in USB/SD mode
REPEAT: Repeat one song/repeat all songs/shuffle
RESET: Reset volume level
MIC +/- (EQ +/-): when a pair of microphone are connected,
these buttons will control the mic volume. In USB/SD mode,
they will allow you to navigate the 5 preset EQ curves. Please
note: connecting mics will override the EQ +/- function.
ECHO +/- (DISP +/-): when a pair of microphone are connected, these buttons
will control the echo effect. If there are no mics connected,
they will control the display brightness. Please note:
connecting mics will override the DISP +/- function.

P9

COMPONENT CONNECTIONS

Verify that your device can be used to input sound from audio/video for
other external sound source devices, and ensure your device have an
available jack to match the appropriate port on the subwoofer,
e.g: TV ARC, Optical, Coaxial, RCAs...


B89 Home theater system is suitable for many TVs, projector, digital set-top
boxes, game consoles, DVD players, Blu-ray players, CD players, etc.



Connecting a device by wireless BT

1. Make sure the wired center speaker and FL & FR, SL & SR speaker have
plugged into the match Audio Output Socket of the subwoofer, and the
power is "ON" status.
2. Press "INPUT" button by remote or in the subwoofer, switch mode to
"BT" showing in the LED display of the subwoofer.
3. Make sure the units are plugged in and power "ON" status.
4. On your smartphone or tablet or other wireless BT device, search for the
BT named "Bobtot B89" and tap to connect. Now you can enjoy the music.

Note: If your device requires the password, please enter "0000".



P10

Table of Contents

What's In the Box.....	4
Important Safety Instructions.....	4
Best Placement for 5.1 Home Theater System.....	5
Set Up Center & Front & Rear Speakers.....	6
Front Panel of Subwoofer.....	7
Back Panel of Subwoofer.....	8
Remote Control Function.....	9
Composite Connection(Getting Started).....	10
-Connect a device by wireless BT.....	10
-Connect a device with a TV ARC cable.....	11
-Connect a device with Optical cable.....	11
-Connect a device with Coaxial cable.....	11
-Connect a device with 2RCA M/M Stereo Audio cable.....	12
-Connect a device with 3RCA Video Audio cable.....	12
-Connect with Antenna for FM radio.....	13
-Playing with USB/SD.....	13
-Connect microphone.....	13
Product Specifications.....	14
Need Help.....	14
Certification.....	15

P2

Introduction

Thank you for purchasing the Bobtot 5.1 Channel Home Theater System .
We encourage you to read this instruction guide before using and retain
this for future reference. Also, please inspect the package contents and
ensure there are no missing or damaged parts.

What's In the Box

- 1) Subwoofer with Built-In Receiver
- 2) Center Channel Speaker
- 2 * Front Channel Speakers
- 4) 2 * Rear Channel Speakers
- 3 * RCA Video Audio Cable
- 1 * Full Function Remote
- 7) TV ARC Cable
- 8) Optical Stereo Cable
- 9) Coaxial Cable
- 10) 3.5mm to 2-Male RCA Audio Stereo Cable
- 11) FM Antenna Cable
- 12) Quick Setup Guide

IMPORTANT SAFETY INSTRUCTIONS



TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE AMPLIFIER
PLATE. NO USER SERVICEABLE PARTS INSIDE. WE RECOMMEND TAKING THE
UNIT TO A QUALIFIED SERVICE TECHNICIAN FOR ANY REPAIRS.

Read the following safety instructions before operating your home
theater system.
• Do not place these speakers on an unstable surface. The speaker may
fall over, causing serious injury to a child or adult and serious damage
to the unit.
• The speakers should be situated away from heat sources such as radiators,
heat registers, stoves, or other devices that produce heat.
• Please use under specified voltage(120V/60Hz). Any other voltage than the
specified voltage may cause fire or electric shock.
• To reduce the risk of electric shock or component damage, unplugged the
power before moving your speakers or connecting other components to
your device.
• Clean only with a soft dry cloth. Unplug the main unit from the wall outlet
before cleaning.

CAUTION: Always use a power outlet that is properly grounded.

P3

Connecting a device with a TV ARC cable

1. Verify that your device has ARC/eARC output.
2. Connect the TV ARC cable to the subwoofer and your device.
3. Make sure the units are plugged in and power "ON" status.
4. Press the "INPUT" button by remote or in the subwoofer, switch mode
into "ARC" which is showing in the LED display of the subwoofer.
5. Some TVs could automatically recognize the audio output as ARC audio
output after connecting ARC cable, you can enjoy it now. If your device
couldn't, please manually enter into the audio sound out setting to choose
"ARC Audio Output."

NOTE: B89 ARC output only supports LPCM 2.0 audio format.




Connecting a device with Optical cable

1. Verify that your device has an "Optical" output.
2. Connect the optical cable to your device and subwoofer.
3. Make sure the units are plugged in and power "ON" status.
4. Press the "INPUT" button by remote or in the subwoofer, switch mode
into "OPT" which is showing in the LED display of the subwoofer.
5. Choose "PCM" not "Automatic" from the Digital output audio format of
the audio setting of your device. You can enjoy it now.



Connecting a device with Coaxial cable

1. Verify that your device has an "Coaxial" output.
2. Connect the coaxial cable to your device and subwoofer.
3. Make sure the units are plugged in and power "ON" status.
4. Press the "INPUT" button by remote or in the subwoofer, switch mode
into "COA" which is showing in the LED display of the subwoofer.
5. Choose "PCM" not "Automatic" from the Digital output audio format of
the audio setting of your device. You can enjoy it now.



P11


Connecting a device with 2RCA M/M Stereo Audio cable

1. Verify that your device has RCA L/R output.
2. Connect the RCA L/R cable to your device and subwoofer.
3. Make sure the units are plugged in and power "ON" status.
4. Press the "INPUT" button by remote or in the subwoofer, switch mode into
"FM" which is showing in the LED display of the subwoofer.
5. Long press the "AUTO" button about 3 seconds, it will be automatically
searching for radio stations.
6. Manually save stations:
-press the "TUNE+/TUNE-" button to search for a station you like.
-press the "SAVE" button, it will display some radio channel on the screen,
press the "CH/CH+" buttons to choose the broadcast channel you like.
-press the "SAVE" button again, it will save the radio channel & the message
"good" will be displayed.
7. Press the "CH/CH+" button to search through saved stations or press the
"TUNE+/TUNE-" buttons to manually find a station what you like.




Connecting a device with 3.5mm to 2-Male RCA Audio Stereo cable

1. Verify that your device have a 3.5mm AUX jack output.
2. Connect the RCA L/R cable to the subwoofer and 3.5mm AUX plug into your
device.
3. Make sure the units are plugged in and power "ON" status.
4. Press the "INPUT" button by remote or in the subwoofer, switch mode into
"AUX" which is showing in the LED display of the subwoofer.
5. Now you can enjoy it.



Connecting a device with 3RCA Video Audio cable


1. Verify that your device have 3RCA output.
2. Connect the 3RCA cables to your device and subwoofer.
3. Make sure the units are plugged in and power "ON" status.
4. Press the "INPUT" button by remote or in the subwoofer, switch mode into
"AUX" which is showing in the LED display of the subwoofer.
5. Choose "PCM" not "Automatic" from the Digital output audio format of
the audio setting of your device. You can enjoy it now.



P12

BEST PLACEMENT FOR 5.1 Home Theater System


1. Most people place the subwoofer in the front of the room, near the sound input source,
for ease of connection. But since bass frequencies are non-directional the subwoofer can
be placed anywhere. Try placing it near a wall or a corner for increased bass.
2. The center channel speaker should be place directly in front of the listening position,
above or below the sound input source. If possible, tilt it as necessary to direct the sound
to ear level.
3. Mount the front speakers on the wall, directly to the left and right of the center channel
speaker. Angle them towards the listening position. Preferably, the tweeters should be at
ear level.
4. Mount the satellite speakers on the wall, slightly behind the listening position, about
1 to 2 feet above ear level. If side placement isn't possible place them to the rear of the
listening position and angle them forward.



P5


SET UP CENTER & FRONT & REAR SPEAKERS

Place speakers in the ideal position, using the built-in electric cable
to connect the center & front & rear satellite speakers to the "CEN &
FL & FR & SL & SR" of the Audio Output RCA socket on the
subwoofer unit.




P6

FRONT PANEL OF SUBWOOFER



P7

BACK PANEL OF SUBWOOFER



P8

Connecting by Antenna for FM radio

1. Put the white Antenna cable plug into "FM ANT" jack on the back of
subwoofer.
2. Make sure the units are plugged in and power "ON" status.
3. Press the "INPUT" button by remote or in the subwoofer, switch mode into
"FM" which is showing in the LED display of the subwoofer.
4. Long press the "AUTO" button about 3 seconds, it will be automatically
searching for radio stations.
5. Manually save stations:
-press the "TUNE+/TUNE-" button to search for a station you like.
-press the "SAVE" button, it will display some radio channel on the screen,
press the "CH/CH+" buttons to choose the broadcast channel you like.
-press the "SAVE" button again, it will save the radio channel & the message
"good" will be displayed.
6. Press the "CH/CH+" button to search through saved stations or press the
"TUNE+/TUNE-" buttons to manually find a station what you like.

Playing USB

1. Make sure the units are plugged in and power "ON" status.
2. Plug your USB drive into USB jack of the subwoofer.
3. Press the "INPUT" button by remote or in the subwoofer, switch mode into
"USB" which is showing in the LED display of the subwoofer.
4. Now you can enjoy the music.

Playing SD

1. Make sure the units are plugged in and power "ON" status.
2. Plug your SD drive into SD jack of the subwoofer.
3. Press the "INPUT" button by remote or in the subwoofer, switch mode into
"SD" which is showing in the LED display of the subwoofer.
4. Now you can enjoy the music.

MIC INPUT

B89 home theater system can connect wireless and wired microphone,
you can use one of mic jack or 2 mics jack together.

1. Wireless microphone: plug the receiver to the mic 1 or 2 jack in the front of
the subwoofer.
2. Wired microphone: plug in, play it.
3. Control the mic volume: press "MIC-" or "MIC +" button by remote
4. Control the mic echo effect: press "ECHO-" or "ECHO+" button by remote

P13

Product Specifications

- 5.1 Channel Home Theater System
- 1400 Watts Peak Power
- 600 Watts Program Power
- 250 Watts Continuous RMS Power
- BT Version: 5.0+EDR
- Input Voltage: AC 120V/60Hz
- System Impedance: 12" : 80mm 4" driver: 4 Ohm /1" driver: 4 Ohm
- Frequency Response: 20Hz - 20KHz
- Amplifier: Class AB, very efficient amplifier with top components
- Signal to Noise Ratio: >70dB (Maximum output with THD <1%
Center Speaker: 157.48inch;
Rear L/R Speaker: 472.44inch;
Subwoofer Size: (W*D*H) 10.62" x 18.89" x 17.32"
Center Satellite Speaker Size: (W*D*H) 5.90" x 6.88" x 10.31"
Front L/R Satellite Speaker Size: (W*D*H) 5.90" x 6.88" x 10.31"
Rear L/R Satellite Speaker Size: (W*D*H) 5.90" x 6.88" x 10.31"

Need Help ?

Customer Care Guide
At our company, we strive to provide exceptional customer care to every
one of our clients. We believe that building strong relationships with our
customers is essential to the success of our business. To help us achieve
this goal, we have put together the following customer care guide.

Time
We understand that our customers' time is valuable, so we will respond to
any inquiries within 24 hours.

Feedback
We know that our customers are the heart of our business so we value your
feedback. We encourage you to share your thoughts and ideas with us.

Solutions
If our customers encounter any issues, we will try our best to find a quick
and efficient solution that meets your needs.
Here at Bobtot, we take customer care very seriously. Our customers are
our first priority, and we are committed to providing the highest quality
services. If you have any questions or concerns, please don't hesitate to
reach out to us. We will be happy to assist you:
Call or Message: +1 (888) 572-1718
Email: service@bobot.net

P14

Certification

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to
the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received,
including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party
responsible for compliance could void the user's authority to operate the
equipment.
Note: This equipment has been tested and found to comply with the limits
for a Class B digital device, pursuant to part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against
harmful interference in a residential installation.
This equipment generates uses and can radiate radio frequency energy
and, if not installed and used in accordance with the
instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a
particular installation. If this equipment does cause harmful interference
to radio or television reception, which can be determined by turning the
equipment off and on, the user is encouraged to try to correct the
interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to
which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for
uncontrolled environment.
This equipment should be installed and operated with minimum
distance 20cm between the radiator & your body.

bobot.net

©2023 BOBTOT // Features and specifications are subject to change and or improvement without notice.

P15

说明：尺寸：140x215mm
材质：128G铜版纸 四色双面印刷 8张装订本

说明：尺寸：140x215mm
材质：128G铜版纸 四色双面印刷 8张装订本

说明：尺寸：140x215mm
材质：128G铜版纸 四色双面印刷 8张装订本

说明：尺寸：140x215mm
材质：128G铜版纸 四色双面印刷 8张装订本