正面


Bobtot
Sound of Nature



Outdoor Portable Speaker
ET100
Quick Start Guide


What's in the Box

Check to make sure you have everything bellow.



A: 1*Portable Wireless Speaker
B: 1*USB Charging Cable (Type-C)
C: 1*Quick Start Guide

Device Overview



① Power on/off
② Volume Down/Previous Button
③ Play/Pause/BT Disconnection /Reconnection/Hands-free Call
④ Volume Up/Next Button
⑤ Lamp Effect Mode/TWS
⑥ USB Type-C Charging Port

Buttons and Ports

Power on/off
Long press to turn the speaker on/off.

Volume Up/Next Button
Short press to turn up the volume.
Long press to go to next song.

Volume Down/Previous Button
Short press to turn down the volume.
Long press to go to previous song.

Play/Pause/BT Disconnection/Reconnection
Hands-free Call
Short press to pause/play music.
BT mode: long press for fast pairing (disconnect/connect back BT device).
Hands-free call: when answering call, short press to accept an incoming call/hang up, long press to reject an incoming call.


Lamp Effect Mode/TWS
Short press cycle to select light effect mode.
Long press to TWS pair/disconnect.

Charging Your Device


Plug the included USB type-C cable into the speaker's charging port,and connect the other end of the cable to a power adapter (sold separatedly).Allow approximately 4 hours to full charge the battery.

When the battery is low and the red light blinks, please charge it.
The indicate light is red color when it's charging.
After full charge, the indicator disappears.

Note:
We recommend using a USB wall adapter with a DC5V output.




Initial Setup



1. Once your speaker is fully charged, long press the "⏻" Power button until you hear a voice prompt indicating the device has entered BT paring mode.
2. On your smartphone or tablet, search for the BT device named " **Bobtot ET100** " and tap to connect.
3. A prompt will play once pairing is successful.

Note:
1. When you turn on the speaker but no connection, it will automatically shut down after 10 minutes.
2. When you connected the speaker but no playback, it will automatically shut down after 20 minutes.

TWS Sync Mode (Two Speakers Together)



This device features TWS (True Wireless Stereo) technology,which allows to play music on two of these speakers simultaneously,creating a surround sound experience.
1. Long press the "⏻" on both speakers to turn them on, and the blue light flashes.
2. Long press the "☼" on any one speaker, a prompt sound "pair" indicates the speakers enter into pairing mode, the indicator light of one speaker status indicator purple.
3. On your smartphone or tablet, search for the BT device named " **Bobtot ET100** " and connect it, you could hear the sound "connected" again, which means connect successfully, you can enjoy the music with two speakers together.

Note:
* In TWS mode, turn off one of the speakers, both of them are off.
* Long press the "☼" button will be TWS disconnected.

Bobtot
Sound of Nature


反面

Hands-Free Calling


Volume Up
Short press once to increase volume

Volume Down
Short press once to decrease volume

Answer Button
Short press to accept an incoming call/hang up.
Long press to reject an incoming call.



Light Status



Red	Charging(The light goes out when fully charged)
Blue	BT pairing
Purple	TWS pairing
Red Flashing	Low battery

Resetting Your Device

If your speaker is not operating properly, you may reset it.to do so, long press the "⏻" power button for approximately 8s until the speaker powers off, and then power it on again as usual.

Specifications

Model: Bobtot ET100
Output Power: 15W
Input Power: 5V ⎓ 2A
Battery Capacity: 7.4V 2000mAh
Frequency Response: 130Hz-18KHz
Singal to Noise Ratio: ≥ 78dB
Operating Range: 33ft(10m)
Up to 18 hours of playtime (Vol 50%)
BT/Hands-free Call/TWS
IPX6 Water-resistant

FCC Warning

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection

FCC Warning

against harmful interference in a residential installation.
This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

FCC Warning

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Need help?

Customer Care Guide
At our company, we strive to provide exceptional customer care to every one of our clients. We believe that building strong relationships with our customers is essential to the success of our business. To help us achieve this goal, we have put together the following customer care guide.

Time
We understand that our customers' time is valuable, so we will respond to any inquiries within 24 hours.

Feedback
We know that our customers are the heart of our business so we value your feedback. We encourage you to share your thoughts and ideas with us.

Solutions
If our customers encounter any issues, we will try our best to find a quick and efficient solution that meets your needs.

Need help?

Here at Bobtot, we take customer care very seriously. Our customers are our first priority, and we are committed to providing the highest quality service.
If you have any questions or concerns, please don't hesitate to reach out to us.
We will be happy to assist you:
Call or Message: +1 888 572 1718
Email: service@bobtot.net

bobtot.net

©2024 BOBTOT // Features and specifications are subject to change and or improvement without notice.

技术要求：

1. 成品尺寸90*90mm　展开尺寸：720*90mm
2. 128g铜版纸
3. 风琴折，红色虚线为压线无需印刷出来。
4. 单黑色双面印刷

深圳市恩科电子有限公司　SHENZHEN CITY ENKOR ELECTRONICS LTD

设计绘图	测试员	品质	业务	产品	审核	客户品牌	内部型号	零件名称	材 料	单 位	版本
						bobtot	ET100	说明书		MM	1.0

料　号	部　门	研发部	PMC	采购部	品管部	木箱部	生产部
BZ0-ET100SMSB01		✓		✓	✓		✓