



Check to make sure you have everything below.

A

B

C


D

Bobot

Portable Wireless Speaker
Quick Start Guide
©2016 HFI

A: 1* Sound Air1 Portable Speaker
B: 1* Type-C USB Charging Cable
C: 1* 3.5mm AUX Audio Cable
D: 1* Quick Start Guide

1. Power On/Off
2. Previous Button
3. Play/Pause
4. TWS/Mode
5. Indicator light
6. Next Button
7. Volume +
8. Volume -
9. AUX jack
10. USB port
11. Type-C charging port
12. Indicator light
13. TF card jack




1. **Power On/Off**
Long press and hold to turn the speaker on/off.
2. **Previous Button**
Short Press to go to previous song.
3. **Play/Pause/Answer Button**
Short press to pause/play the music.
Short press to answer an incoming call. (BT mode)
Double click to talk back. (BT mode)
Long press to reject an incoming call. (BT mode)
Long press to disconnect/reback BT.
4. **TWS/Mode**
Double click to TWS ,connect with two speakers.
Long Press TWS, to disconnect both speakers.
5. **Indicator light**
Blue light flash will in BT pairing or TWS pairing status
6. **Next Button**
Short Press : to go to next song.
7. **Volume +**
Press to turn up the volume.
8. **Volume -**
Press to turn down the volume

Plug the included USB type-C cable into the speaker's charging port and connect another end of the cable to a power adapter (not included). Allow approximately 4.5 hours to full charge the battery.

When the battery is low and the red light blinks, please charge it.

The indicate light is red color when it's charging
The red light will be off when it's full charged.

Note: We recommend using a USB wall adapter with a **DC 5V** output.



The diagram illustrates the connection between the battery pack and the smartphone. On the left is a battery pack with two terminals labeled 'V+' and 'V-'. A dashed line with double arrowheads at both ends connects the battery pack to a smartphone on the right. The smartphone screen displays a 'BT device' selection menu with 'On' and 'Off' toggle switches, and a list of available devices including 'Roblox Sound Art'.

1. Once your speaker is fully charged, press and hold the  **Power button** until you hear a voice prompt indicating the device has entered BT pairing mode.
2. On your smartphone or tablet, search for the BT device named **"Bobtot SoundAir1"** and tap to connect.
3. A prompt will play once pairing is successful.

Note:

1. When you turn on the speaker but no connection, it will automatically shut down after 10 minutes.
2. When you connected the speaker but no playback, it will automatically shut down after 20 minutes.

1. Long press the "O" about 2s on both speakers to turn them on, and the blue light flashes.
2. Quickly double-click the "O" on any one speaker, a prompt sound "connected" indicates the speakers enter into pairing mode, the indicator light of one speaker turned solid blue.
3. On your smartphone or tablet, search for the BT device named "Bobot SoundAir" and connect it, you could hear the sound "connected" again, which means connect successfully. You can enjoy the music with two speakers together.

Notes:

- *Double-click the "O" button will be disconnected.

Mode Indicator light

Power supply Indicator light

•	Blue light flash: in BT pairing or TWS pairing status
•	Blue light slow flash: Low battery
◦	Stay red light: Charging
◦	Red light off: Full charge

Play/Pause/Answer Button
 Short press to pause/play the music.
 Short press to accept an incoming call. (BT mode)
 Double click to call back. (BT mode)
 Long press to reject an incoming call. (BT mode)
 Long press to disconnect/reback BT.

- V+ Volume Up**
Press to turn up the volume.
- V- Volume Down**
Press to turn down the volume.

If your speaker is not operating properly, you may reset it. To do so, press and hold the **○ power button** for approximately 8s until the speaker powers off, and then power it on again as usual.

- Model Name: SoundAir1
- Outdoor Portable Wireless Speaker
- Input Power: DC 5V
- Impedance: 3Ω
- Signal to Noise Ratio: $\geq 78\text{dB}$ (TBC)
- IPX6 water-resistant, sprayproof
- Built-in rechargeable battery
- Built-in Mic
- Range 33ft(10m)
- Frequency Response: 180Hz- 18KHz (TBC)
- TWS Sync Mode(Pair 2 of these speakers together)
- Up to 25 hours of playtime (battery life is measured as number of playtime with volume set at 50%)

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection

against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Customer Care Guide
At our company, we strive to provide exceptional customer care to every one of our clients. We believe that building strong relationships with our customers is essential to the success of our business. To help us achieve this goal, we have put together the following customer care guide.

Time
We understand that our customers' time is valuable, so we will respond to any inquiries within 24 hours.

Feedback

We know that our customers are the heart of our business so we value your feedback. We encourage you to share your thoughts and ideas with us.

Solutions

If our customers encounter any issues, we will try our best to find a quick and efficient solution that meets your needs.

Here at Bobbot, we take customer care very seriously. Our customers are our first priority, and we are committed to providing the highest quality service.

If you have any questions or concerns, please don't hesitate to reach out to us.

We will be happy to assist you:

Call or Message: +1 888 572 1718

Email: service@bobbot.net

bobtot.net

©2023 BOBOTOT // Features and specifications are subject to change and or improvement without notice.

技术要求:

1. 成品尺寸90*90mm 展开尺寸： 720*90mm

2. 128g铜版纸

3. 风琴折，红色虚线为压线无需印刷出来。

4. 单黑色双面印刷