


F



Shenzhen JWEI Electronic Technology Co., Ltd. (dissemination and diffusion are prohibited without written authorization)

F

“A”不具备实际含义，只要完整码除员工代码之外的编码有变动，镭射箭码将相应变化，推移规则为A~Z，用完1位字母的序列后，将增加一位字码“AA、AB、AC~ZZ”，依此类推。

"A" does not have the actual meaning. As long as the code of the complete code except the employee code changes, the laser short code will change accordingly. The change rule is AA, AB, AC~ZZ, and so on.

“01”代表包棉员工编号，推移规则为01~∞，2位数字用完，可以使用3位数字，依此类推。

"01" stands for employee number, the transition rule is $01 \sim \infty$, Run out of 2 digits, 3 digits can be used, and so on.

“J”字母代表深圳聚维工厂。

"J" represents shenzhen JWEI Factory.

“B” 字母代表第二代烟弹M926-B。

“B” represents shenzhen Second-generation smoke grenade M926-B.

F