



Thank you for purchasing an original
**Nautica True Wireless Stereo Earbuds With
Charging Case - UCCWS07**

You are getting a high-quality product that's built to combine
technology and design for your everyday use.

Please read the below info carefully to get the most out of
your new product.




WHAT'S IN THE BOX



TRUE WIRELESS
STEREO EARBUDS



CHARGING CASE



TYPE-C TO USB-A
CHARGING CABLE



USER'S MANUAL

Your product comes with four pairs of eartips (S, M and L). Try all sizes to find
the size that fits best. Your device comes with size M eartips on.

3



HOW TO USE ?

*Multi-function Button

***MFB (LEFT)**

- Press and hold for 5
secs to POWER
ON or OFF
- Double press:
Previous track
- Press once: Answer
call
- Press once: End
call
- Double press:
Reject call



***MFB (RIGHT)**


- Press and hold for
5 secs to POWER
ON or OFF
- Double press:
Next track
- Press once: Answer
call
- Press once: End
call
- Double press:
Reject call

*Multi-function Button

4

BLUETOOTH PAIRING

1. Press each MFB button for 5 seconds, to turn on both earbuds.



- No need to hold MFB button after power is on.
- The Left & Right will automatically connect, one of the two earbud LEDs
flashes white and green alternately.

2. Find “UCCWS07” to connect with your phone.

5

CHARGING EARBUDS

- Charging: White LED light turns on
- Fully charged: White LED turns green for 30
seconds and then Green LED turns off



CHARGING CASE

- Plug the small end of the USB cable into
the Type-C USB port of the charging case.
- Plug the other end into a USB wall charger
or computer (DC 5V) that is powered on.



6



TECHNICAL SPECIFICATIONS

Bluetooth Version	v5.3
Play Time	Up to 7 hours
Earbuds Charging Time	Up to 2 hours
Charging Case Charging Time	Up to 1 hours
Standby Time	40 hours
Battery Capacity (Each earbud)	25x2mAh
Battery Capacity(charging case)	180mAh
Speaker Drivers	0.50in/ 13mm
Wireless Range	Up to 33ft/ 10m

7

Impedance	32Ω
Frequency Response	20Hz-25kHz
Sensitivity	-38±3db
Rated Input Voltage	5V
Earbud Dimensions	1.41x1.02x1.24in / 35.8x26x31.6 mm
Charging Case Dimensions	2.28x2.28x0.87 in / 58x58x22 mm
Weight (Each Earbud)	0.11 oz / 3.1 g
Weight (Charging Case)	1.16 oz / 32.8g
Charging Port	Type-C
Speaker Drivers Type	Composite film

8



SAFETY AND MAINTENANCE

Before you use the device, read the following precautions carefully to
ensure optimal product performance.

The use of earbuds will impair your ability to hear other sounds. Use
caution while using your earbuds during any activity that requires your full
attention.

This package contains small parts that may be hazardous to children and
should be kept out of reach of children. This product is not a
toy – never allow children to play with this product.

Please do not overuse the earbuds or put them under heavy pressure.
Keep away from wet and heat. Exposing the product to extreme hot or
cold, such as in a closed car in the summer and winter conditions, will
reduce the capacity and lifetime of the product. Earbuds listening at high
volume levels – especially over extended periods of time – may damage
your hearing.

9

Keep away from router or other high-frequency transmitting equipment
to prevent interruption of signal receiving.

Please use the earbuds under working range (up to 33 ft / 10 m). The
effective range may vary depending on multiple conditions.

Power time may differ depending on personal use habits.

Do not dismantle the product. If any parts of your product require
replacement for any reason, including normal wear and tear or breakage,
please contact us. Unauthorized parties may damage the product.

Do not drop, strongly vibrate, or strike the product with hard objects to
avoid damaging the internal circuit.

Do not use drastic chemicals or cleaner to clean the product. Do not use
sharp objects to scratch the product surface.

10



WARRANTY INFORMATION

We do our best to make sure that this product is free from defects in
materials and workmanship for a period of 1 year.

The following conditions must be met for your warranty claim to be
approved:

You must have purchased the product from a Nautica or Technofashion
authorized dealer.

You must provide proof as to the date of purchase from the Nautica or
Technofashion authorized dealer.

You must have used the product only as intended and in accordance with
the product's care instructions.

11

Within 12 months after the purchase, in case the product is determined to
be defective (at the date of original purchase) due to improper
materials or workmanship, you are entitled to free repair or exchange of
goods.

The product should be returned to Technofashion.

The warranty does not cover defects caused by third-party modifications,
repairs or replacement parts.

Punctures, scratches, normal wear and tear and the natural breakdown of
colors and materials over extended time and use are not warranted.
Warranty applies to the USA only.

We will make every effort to replace limited edition or discontinued
products but cannot guarantee availability for replacement.

12

Any limited edition or discontinued product still under its applicable
warranty that cannot be replaced with an identical product will be
replaced with the equivalent model based on availability.

We may make changes to products and designs in the time you
purchased your product and submitted a warranty claim.

Products repaired or replaced under this warranty may or may not
incorporate these changes.

13



SUPPORT

For any questions, email us at
support@technofashion.com

FCC ID: 2AZBO-N00026

This device complies with Part 15 of the FCC Rules. Operation is subject to
the following two conditions: (1) this device may not cause harmful
interference, and (2) this device must accept any interference received,
including interference that may cause undesired operation.

This device has been tested and found complying with the limits for a Class
B digital device, pursuant to Part 15 of the FCC Rules. These limits are
designed to provide reasonable protection against harmful interference in a
residential installation. This device generates, uses, and can radiate radio
frequency energy and, if not installed and used in accordance with the
instructions, may cause harmful interference to radio communications.

14

However, there is no guarantee that interference will not occur in a particular
installation. If this device does cause harmful interference to radio or
television reception, which can be determined by turning the device off and
on, the user is encouraged to try to correct the interference by one or more
of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which
the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Changes
or modifications not expressly approved by the party responsible for
compliance could void the user's authority to operate the equipment.

15

NAUTICA

designed, manufactured, distributed by
TECHNOFASHION

© Technofashion, Inc.
All Rights Reserved.
Designed in USA. Made in China.



8