



Wireless Keyboard Case with adjustable stand for Alexa Tablet 11

Model: CEL0001

User Manual



Pairing Steps

- Step 1. Switch On/Off to On to turn your keyboard on.
- Step 2. Press the “Fn + ” keys together to enter pairing mode.
- Step 3. Verify your device’s Bluetooth® settings are on.
Select Settings > Bluetooth > On.
- Step 4. Select “Pair new device”.
- Step 5. Select “Fintie” from your device’s list of available devices to complete pairing.
- Step 6. The Bluetooth pairing indicator will turn off after your device has paired successfully.

Sleep Mode

The keyboard will enter sleep mode after being idle for 30 minutes. Press any key to wake the keyboard up. Wait up to 2 seconds for the keyboard to reconnect with the tablet before starting to type.

Charging Your Keyboard

1. Plug the Type-C end of the charging cable into the keyboard and the other USB end into your preferred USB charger. (USB charger is not included.)
2. When charging, the power indicator will turn red. Generally, it takes approximately 4 hours for a full charge. (Output: DC 5 V/500 mA.)

Package Contents

- 1 x Keyboard Case
- 1 x USB-C Charging Cable
- 1 x User Manual

Specifications

Bluetooth Version	Ble 5.1
Operating Range	10 metres
Working Voltage	3.0-4.2 V
Working Current	0.5 mA
Working Current with Touchpad	8 mA
Charging Current	310 mA
Sleeping Current	0.02 mA
Re-connect Time	Apx. 2 seconds
Stand-by Time	365 days
Charge Time	≤ 2 hours
Uninterrupted Work Time	71 days
Lithium Battery Capacity	500 mAh
Frequency Band	2400 to 2483.5 MHz

Product Overview



- ① Power indicator:

Turns blue for 3 seconds.
- Bluetooth indicator:

Flashes blue when pressing “Fn + ”.
- Caps Lock indicator:

Blue light is on.
- ② Charging indicator:

Red while charging.

Green when fully charged.
- Low battery indicator:

Flashes red when charging is required.
- ③ Charging port:

Only used for charging.

Keys and Function

	Home (Press and Hold for Alexa)		Back		Search for
	Brightness -		Brightness +		Previous track
	Play/Pause		Next track		Volume -
	Volume +		Lock screen		Writing Assistant
	Meta key		AI	Fn+Tab	Touchpad on/off

Touchpad Function

Gesture	Finger action picture	Android
1-finger tap		Left-click
1-finger slide		Move cursor
2-fingers vertical/ horizontal movement		Scroll / Pan
3-fingers slide to the left		Back
3-fingers slide to the right		Back
3-fingers slide up		Light swipe: Go Home Three-finger swipe up and hold: Show recent apps
3-fingers slide down		Show notifications

Troubleshooting

If your device does not respond to the keyboard, try the following.

1. On your Alexa Tablet 11, navigate to “Settings > Connected Devices > Previously connected devices” and delete any entries for unused Bluetooth devices including “Fintie”.
2. Restart your device.
3. Turn your keyboard off and back on.
4. Re-pair your keyboard.
5. If your keyboard does not establish or maintain a Bluetooth connection, reset the Bluetooth module by charging your keyboard.
6. If your keyboard does not operate correctly after charging it, please contact your authorised retailer.

Safety Tips

- Do not place heavy objects on the keyboard.
- Do not disassemble the product.
- Keep the product away from oils, chemicals and organic liquids.

- Use only a damp, soft cloth, like microfibre, to wipe the keyboard.
- Dispose of the battery according to local laws.
- Keep the product away from sharp objects.

******* For UK customers only *******

Recycling Your Old Electricals Is Easy!

Recycle your electrical and electronic devices for free at your local recycling centre. To find your nearest centre, visit www.recycle-more.co.uk and type in your postcode.

Why Recycle?

Unwanted electrical equipment is the UK's fastest growing type of waste. Many electrical items can be repaired or recycled, saving natural resources and the environment. If you do not recycle, electrical equipment will end up in landfill where hazardous substances will leak out and cause soil and water contamination—harming wildlife and also human health.

We're proud to support your local authority in providing local recycling facilities for electrical equipment.

To remind you that old electrical equipment can be recycled, it is now marked with the crossed-out wheeled bin symbol. Please do not throw any electrical equipment (including those marked with this symbol) in your bin.



What is WEEE?

The Waste Electrical or Electronic Equipment (WEEE) Directive requires countries to maximise separate collection and environmentally friendly processing of these items.

How Are We Helping?

In the UK, distributors including retailers must provide a system which allows all customers buying new electrical equipment the opportunity to recycle their old items free of charge. As a responsible retailer, we have met the requirements placed on us by financially supporting the national network of WEEE recycling centres established by local authorities. This is achieved through membership of the national Distributor Take-back Scheme (DTS).

To find more information on WEEE recycling and to locate your nearest recycling centre, please visit www.recycle-more.co.uk.

Contact Us

Website: www.fintie.com
E-mail: support@fintie.com

North America
Tel: 1-888-249-8201
(Monday-Friday: 9:00 AM – 5:00 PM EST)

Europe
Tel: +49 69 95094777
(Monday-Friday: 9:00 AM – 5:00 PM CET)

©2026 Amazon.com, Inc. or its affiliates. Amazon, Alexa, and all related trademarks are trademarks of Amazon.com, Inc. or its affiliates.

operating temperature:0℃-+40℃

Hereby, (Fintie LLC) declares that the radio equipment type Wireless Keyboard Case is compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: xxx.xxxyyy.com



Hereby, (Fintie LLC) declare that the radio equipment type Wireless Keyboard Case with adjustable stand for Alexa Tablet 11 is compliance with requirements: Radio Equipment Regulations 2017 (S.I. 2017/1206).

The full text of the UK declaration of conformity is available at the following internet address: www.xxxyyy.com



Frequency Range: 2402MHz-2480MHz
Maximum output power: 0.40dBm

This product can be used across all EU member states.



FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment can be used in portable exposure conditions.

ISED Statement

Déclaration d'ISDE

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED Radio Frequency Exposure Statement:

This equipment complies with ISED exposure limits set forth for an uncontrolled environment. This equipment can be used in portable exposure conditions.

Déclaration d'ISDE sur l'exposition aux radiofréquences :

Cet équipement est conforme aux limites d'exposition d'ISDE établies pour un environnement non contrôlé. Cet équipement peut être utilisé dans des conditions d'exposition portables.