128克双铜纸 双色 K + PANTONE 2297 C 双面印刷 骑马钉 尺寸：73*80mm

封面



感谢您购买兰士顿AirWave Pro2开放式运动耳机，以下说明将指导您轻松使用它。

佩戴

将耳机挂在外耳上，把AirWave Pro2开放式运动耳机的出音孔对准耳道，调整佩戴舒适度。



配件



耳机图示



手动开关机



1.在关机状态下，长按多功能键约2秒，耳机开机。
2.在开机状态下，长按多功能键约3秒，耳机关机。

蓝牙配对




1.首次配对时，将蓝牙耳机和手机的距离控制在1米的范围内，长按多功能键约2秒，指示灯红蓝闪烁，耳机进入配对状态。
2.在智能设备蓝牙列表，选择 "Langsdom AirWave Pro2" 耳机，进行蓝牙耳机与手机连接配对即可。

重置蓝牙配对



1.耳机关机状态下，长按10秒先开机，经过语音提示后，耳机清除配对信息并关机。
2.重新将耳机开机进入配对状态。

一拖二功能



1.耳机成功连接设备A后断开设备A蓝牙。
2.打开设备B蓝牙,在设备B的蓝牙列表搜索 "Langsdom AirWave Pro2" 并点击连接。
3.耳机与设备B成功连接后,在设备A的蓝牙列表点 "Langsdom AirWave Pro2" 进行连接即可实现一拖二的功能。

操作说明



耳机充电



*充电时，耳机为关机状态。

传输文件



电脑传输步骤：
1.使用包装盒中的充电数据线将AirWave Pro2连接到您的电脑。
2.电脑上会出现一个名为"Langsdom"的磁盘,在电脑上打开"Langsdom"磁盘。
3.将音频文件(歌曲、有声读物或文件夹)导入到"Langsdom"磁盘中。
4.文件传输完成后，从计算机中移除"Langsdom"磁盘。

手机传输提示：
1.支持手机传输,适配IOS/Android等主流系统。
2.由于手机系统多样,传输步骤有所不同,请查阅官方公众号或咨询客服获得操作指南。

※建议先考虑电脑传输，请勿在文件传输过程中强行中断，这可能会导致产品损坏。

*以下音乐文件格式目前由AirWave Pro2支持：

格式	比特率	取样率	备注
MP3	8 - 320Kbps	8 - 48kHz	量化bit 数:16bit 支持CBR/VBR
WMA	5 - 384kbps	8 - 48kHz	量化bit 数: 16bit 支持WMA Ver 9/10 不支持WMA Lossless /Pro/Voice
FLAC	700 - 1100kbps	8 - 48kHz	量化bit 数: 8,16,24bit
APE	750 - 850kbps	8 - 48kHz	量化bit 数: 8,16,24bit 压缩设置: High(3000) Li(Fi)
WAV	32 - 1411kbps	8 - 48kHz	量化bit 数: 8,16bit 支持 PCM /ADPCM

警告

1.请勿长时间高音量听，防止听力受损。
2.该耳机只能用5V电压的充电器充电，切勿使用超过5V的快速充电器或大于1.5A的充电器充电，可能或造成过热或起火。
3.切勿将耳机暴露在温度过高的地方或长时间受阳光直接照射。
4.产品的储存温度为10℃至30℃。
5.产品使用环境温度为-20℃至60℃。
6.耳机在长时间未使用的情况下需充满电再使用，建议每3个月充电一次。

※ 建议新机在使用前先充满电

真诚为您服务

1.产品使用过程中，有任何问题可随时与我们联系，我们竭诚为您提供专业的售后服务。
2.保修期内，凡属产品本身原因引起的故障问题，我们将为您提供免费保修服务。
3.联系我们时，请提供产品保修卡及相应订单编号，以便于我们更好的为您解决问题。

产品规格

型号:	BE28
蓝牙版本:	V6.0
充电电压:	DC5V
电池容量:	180mAh
BT频率:	2.402-2.480GHz
音频频率:	20Hz-20KHz
扬声器尺寸:	Φ18mm*11mm
总播放时长:	约13.5小时
耳机充电时间:	约1小时

有害物质的名称及含量

部件名称	产品所有物质的名称及含量					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr6+)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
电子元器件	○	○	○	○	○	○
电线	○	○	○	○	○	○
五金件	○	○	○	○	○	○
塑料件	○	○	○	○	○	○
其他部件	○	○	○	○	○	○

○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572-2011规定的限量要求以下。
×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572-2011规定的限量要求。

产品合格证

产品型号 _____
产品名称 _____
执行标准 Q/LSD 001-2021
检验日期 _____
检员员 _____
检验结果 _____

Q.C passed 01 质 检 合 格

姓名:	地址:
购买日期:	联系电话:
产品型号:	产品编号:
保修内容:	保修日期:
故障及处理方法:	

保修服务

保修政策
1年质保服务，凡属产品本身质量引起的故障原因，本公司将进行免费维修。

非保修条款
1. 超过三包有效期限。
2. 无订单凭证、无发票或订单信息不符。
3. 人为原因造成的外观和内在损坏。
4. 不可抗拒因素造成的损坏。
5. 未按(说明书)的要求使用、保养及调整造成的任何损坏。
6. 超出正常使用条件,擅行使用本产品造成的故障或损伤。
7. 未经兰士顿授权的人员私自拆动或修理。
8. 质量损坏和属改说明书保修部分内容,产品信息。
9. 非产品本身设计,制造,质量等问题而导致的故障和损坏。

*兰士顿享有对该保修条款的最终解释权。

手机下载歌曲到耳机操作

*如何使用耳机数据线连接从手机下载歌曲到耳机,请扫描二维码查看详细操作及下载步骤。

We appreciate you for purchasing the Langsdom AirWave Pro2 Open-ear sports headphones, the ollowing instructions will guide you to use it easily.

Wearing

Hang the headphone on the auricle, align the sound holes with the ear canal and adjust to wearing comfort angle.



Accessories



Headphone Diagram



Power On/Off



1.When the headphone is off, long press the multifunction button about 2 seconds to power on.
2.When the headphone is on, long press the multifunction button about 3 seconds to power off.

Bluetooth Pairing




1.When pairing Bluetooth for the first time long press the multifunction button about 2 seconds, the headphone will automatically turn on the Bluetooth function after the red and blue light flash alternately.
2.Then search for Bluetooth devices,select the" Langsdom AirWave Pro2" to pair.

Reset The Pairing




1.When the headphone is off, press and hold for 10 seconds to power on. After the voice prompt, the headphone clears the pairing information and power up.
2.Then, the headphone is powered on again and enters the pairing state again.

Extended Link



1.Disconnect the headphone from device A after it connected.
2.Turn on the Bluetooth of device B, search for "Langsdom AirWave Pro2" and select to connect.
3.Turn on the Bluetooth of device A and select "Langsdom AirWave Pro2" to connect.

Button Operation



Charging



※The headphone is off while charging.

Transferring Files



Computer Transfer Steps:
1.Connect your AirWave Pro2 to your computer using the USB charging cable included in the package.
2.A drive named "Langsdom" will appear on your computer. Open the "Langsdom" drive on your computer.
3.Copy audio files (songs, audiobooks, or folders) into the "Langsdom" drive.
4.Once the file transfer is complete, safely eject the "Langsdom" drive from your computer.

Mobile Transfer Notes:
1.Mobile transfer is supported and compatible with iOS, Android, and other major systems.
2.Transfer steps may vary depending on the operating system. Please refer to the official account guide or contact customer support for assistance.

※It is recommended to use a computer for file transfer whenever possible. Do not forcibly disconnect the device during the transfer, as this may cause damage to the product.

*The following music file formats are currently supported by AirWave Pro2:

Format	Bit rate	Sampling rate	Remarks
MP3	8 - 320Kbps	8 - 48kHz	Quantization bit depth is 16bit. Supports CBR/VBR
WMA	5 - 384kbps	8 - 48kHz	Quantization bit depth is 16bit. Supports WMA Ver 9/10 Does not support WMA Lossless/Pro/Voice
FLAC	700 - 1100kbps	8 - 48kHz	Quantization bit depth is 8bit, 16bit, 24bit.
APE	750 - 850kbps	8 - 48kHz	Quantization bit depth is 8bit, 16bit, 24bit. Compression setting: High (3000) or less.
WAV	32 - 1411kbps	8 - 48kHz	Quantization bit depth is 8bit, 16bit. Supports PCM/ADPCM.

Warning

1. Do not listen for a long time at a high volume level, preventing injury to hearing.
2. The headphone only can be charged with a 5V charger. Using a fast charger with more than 5V or a charger with more than 1.5A may cause overheating or fire.
3. Do not expose the headphone to high temperature or sunlight for a long time.
4. The ambient operating temperature of the headphones is between -20°C (-4°F) and 60°C (140°F).
5. Please fully charge the headphone after long-term placement, and ensure to charge every 3 months.

※ It is recommended that new headphone be fully charged before use.

Service

1. Please contact us if any problems, we will provide you a professional service.
2. Warranty is only covered by the first year of purchase. Free repair service if the failure is caused by product quality.
3. Please provide the product warranty card and the corresponding order number so that we can better solve the problem for you.

Product Parameters

Model:	BE28
BT Version:	V6.0
Charging Voltage:	DC5V
Battery Capacity:	180mAh
BT Frequency Range:	2.402-2.480GHz
Audio Frequency:	20Hz-20KHz
Speakers Size:	Φ18mm*11mm
Total Play Time:	About 13.5 hours
Headphones Charging Time:	About 1 hour

RohS Testing

Parts	Hazardous Substance					
	(Pb)	(Hg)	(Cd)	(Cr+6)	(PBB)	(PBDE)
Speaker	○	○	○	○	○	○
Battery	○	○	○	○	○	○
Plastic	○	○	○	○	○	○
PCB	○	○	○	○	○	○
Others	○	○	○	○	○	○

○: Hazardous substance contained in all homogeneous materials of this part is below the limit requirement.
×: Hazardous substance contained in homogeneous materials of this part is above the limit requirement.

Certificate Of Quality

Product Model _____
Product Type _____
Executive Standard Q/LSD 001-2021
Inspection Date _____
Inspector _____
Test _____

Q.C passed 01 质 检 合 格

Name:	Address:
Purchase Date:	Telephone:
Product Model:	Product Number:
Warranty Content:	Warranty Date:
Faults&Treatment Methods:	

Warranty Service

Warranty Policy

One-year warranty service. Provide free repair service if the failure is caused by quality issues related to the product.

Non-Warranty Situations

1. The warranty date has expired.
2. No valid warranty card or mismatched country.
3. Damage caused by human factors (appearance and internal damage).
4. Breakdown caused by force majeure.
5. Breakdown caused by not following the instructions.
6. Failure or damage caused by use of the product beyond normal operation.
7. Damage caused by movement or mishandling by a non-authorized party.
8. Malicious damage, theft, or loss of parts of the manual or product information.
9. Breakdown caused by issues such as design, manufacturing, or other factors not related to product quality.

Langsdom has reserved the right of final explanation of the warranty terms.

How to Download Songs

How to use the headphone data cable to connect from the mobile phone to download songs to the headphone, please scan the QR code for detailed operation and download steps.

FCC

FCC ID: 2AZDD-BE28

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However,there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the users us encouraged to try to correct the interference by one or more of the following measures.
-Reorient or separation the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Any changer or modifications not expressly approved by the party responsible for compliance could void the user 's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and
(2)This device must accept any interference received, including interference that may cause undesired operation.
This device has been evaluated to meet general RF exposure requirement.The device can be used in portable exposure condition without restriction.

LANGSDOM 兰士顿	日 期	2026-3-17	设计部		产品部		市场部	B2B事业部		B2C事业部		董事长审批
	项 目	BE28说明书										