

PJ-33 instruction (whole machine operation flow)

Important safety instructions

- 1. Read this instruction.**
- 2. Follow these instructions.**
- 3. Pay attention to all warnings.**
- 4. Follow all instructions.**
- 5. Don't use this instrument near the water.**
- 6. Clean with dry cloth only.**
- 7. Do not block any ventilation openings. Install according to the manufacturer's instructions.**
- 8. Do not install near any heat source, such as radiator, heat register, furnace or other products (including amplifier).**
- 9. Protect the power cord from being trampled or squeezed, especially on the plug and socket, and where they leave the equipment. .**
- 10. Only use the accessories/fittings specified by the manufacturer.**
- 1. Unplug this device during thunderstorm or when it has not been used for a long time.**
- 12. Give all maintenance work to qualified maintenance personnel. When the instrument is damaged in any way, such as the power cord or plug is damaged, liquid overflows or objects fall into the instrument, the instrument is exposed to rain or moisture, can't function properly or is thrown away, it must be repaired. .**
- 13. Only use carts, stands, tripods, brackets or tables designated by the manufacturer or sold with the equipment. When using the cart, be careful when moving the cart/instrument combination,**
To avoid injury caused by rollover. .

Other warnings and precautions

- 1. Don't look directly at the light of the projector.**
- 2. Do not touch the projection lens.**
- 3. The power adapter is used as a disconnecting device and should be easy to operate during its expected use. To completely disconnect the device from the power supply,**
The power plug should be completely disconnected from the power socket.
- 4. Note: The use of control or adjustment or execution of steps other than the specified procedures may lead to dangerous radiation exposure. .**
- 5. Warning: without the explicit approval of the compliance responsible party, the user may lose the operation of this device by changing or modifying this device.**
The right to prepare.
- 6. Warning: The use of this machine near fluorescent lighting may interfere with the use of remote control. If the machine shows no**
Stable behavior should be kept away from any fluorescent lighting, as it may be the cause.
- 7. Warning: Danger of electric shock-do not open it.**

8. Warning and marking information is located at the back or bottom of the instrument.
9. Warning: To reduce the risk of fire or electric shock, do not expose this equipment to rain, humidity, dripping or splashing.
10. Objects filled with liquid, such as vases, must not be placed on the equipment.

handling instruction

Open the cartoon box, take out the projector, place the projector on the desktop or tripod, remove the lens cover, plug one end of the adapter into the socket and the other end into the projector, turn on the projector switch, and the Power indicator on the panel turns red. Press on.

1.USB Play: Press the Power key to turn the indicator light from red to green to enter the boot state, press the remote control to turn off, the Power indicator light on the panel turns red, and

press on.  Key, select DMP to enter the DMP page, and select Movie, Music ,Photo to play videos, music and pictures in USB.

1. Android: Press the remote control  Key, enter the Android interface and select the Settings page to connect to WIFI. After successful networking, you can play online videos. Note: If you need to read USB files in Android, the USB must be plugged into USB2.Bluetooth

speakerMode: Press the remote control  Key, enterBluetooth speakermodel, Turn on the Bluetooth of your mobile phone to find PJ-33S device pairing. After successful pairing, you can play audio files.

2. AV mode, the content can be played by sending the video signal to the AV jack.

3. HDMI mode, send high-frequency signal to HDMI jack to play content.

Panelintroduction



1. 1. the 1.MIC knob adjusts the microphone sound volume.
2. 2. The volume knob adjusts the main volume.



3. direction key



4. Bluetooth pairing light, which shows Bluetooth after successful pairing.



5. The battery lamp is green when charging, and red when fully charged.



6. The Power light is red when it is in standby and green when it is turned on.



7. return key



8. Turn off the projection light key




9. Standby key



10. source key



11. menu



12. Press short to pause playback and long to disconnect Bluetooth.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.