



Set up your frame

Scan the code or visit
auraframes.com/ink-setup



Table of Contents

Setting up your Aura frame	1
Gift setup	3
Features and settings	3
Photo access and privacy	4
Device requirements	5
Operating requirements	5
Frequently asked questions	5
Safety information, warnings, and compliance	6





Setting up your Aura Ink frame

01 Frame set up

Visit auraframes.com/ink-setup to set up your frame.

02 Plug your frame in

Plug your frame into a power outlet using the included cord to start set up.

03 Download the Aura Frames app

Search for “Aura Frames” in your phone’s App Store (iOS or Android), or head to auraframes.com/app to download it directly.

04 Create an account

Be sure your phone is connected to WiFi and Bluetooth is turned on. Open the app and follow the prompts to create an account. Don’t forget to check the box to agree to the Privacy Policy and Terms of Service.

05 Complete frame setup

Follow the in-app instructions to connect your frame and start adding photos. Already have the Aura app? Tap the hamburger menu in the top left corner, then tap “Add Frame” to get started.

06 Continue to charge your frame

Your frame’s status light pulses green while your frame is charging, and turns solid green when the frame is fully charged. Your frame may take up to eight hours to charge, and can still be used during this time.

Once setup is complete, you can decide how you’d like to display your frame—portrait or landscape mode. Use the stand to place it on a surface or mount it on a wall using the included mounting kit (see instructions).

Giving it as a gift? See Gift Setup below, or visit auraframes.com/gift-setup.

Adding photos to your frame

From the app’s home screen, tap “Add Photos” to upload photos to your frame.

All photos added are securely uploaded to Aura’s cloud and linked to your Aura account. If your frame ever goes offline, it will update automatically once it’s back on WiFi.

For more information, visit auraframes.com/add-photos.

Adding contributors to your frame

Invite family and friends to add photos to your frame too! Use the app to send invites—each person will need to download the Aura app and create their own account.

Anyone you invite can see the photos you’ve added, adjust settings, invite others, and use all features like “Show Now.” To edit or change the WiFi settings, a member of the frame must be present with the frame.

For more information, visit auraframes.com/invite.






Wall-hanging instructions

Mark the spot where you want to hang your frame.
The wall hook will sit about three inches below the top of the frame when mounted.

Align the hook on the wall, insert the included nail into the top holes, and use a level to ensure it's straight.


Hammer the nail into place.

Slot the hook into the channel on the back.




Tabletop instructions

Choose portrait or landscape orientation.



Place the hook into the small opening, and rotate the stand until it clicks.





Gift setup

With Aura's gift feature, you can preload a frame with photos before it's unwrapped. Once the recipient connects the frame to WiFi, the photos you've added will automatically appear on the frame and in the Activity tab of the Aura Frames app.

Using the app to set up your gift

If you've purchased an Aura frame as a gift, you do not need to open the box to set it up. Instead, use one of these two methods to get started:

- Scan the gift setup QR code: Use the Aura Frames app to scan the QR code on the box. The app will guide you through preloading photos and a personalized gift message onto the frame.
- Generate a virtual code: In the app, create a virtual setup code. When you give the frame to the recipient, simply provide them with this code to enter during their setup.

For more information, visit our FAQ at auraframes.com/gift-setup.

Features and settings

Adaptive brightness

Ambient light sensors automatically adjust the frame's front light based on the room's light level, so photos always look their best. Automatic shut-off ensures your frame is never illuminated in the dark.

Control the slideshow

By default, your Ink frame displays a new photo each day. To change this setting, open the Aura Frames app and tap the settings icon in the top right corner. You can choose to update photos as often as six times per day (note: frequent changes will reduce battery life). You can also set the photo order to shuffle or display chronologically.

Rechargeable battery

When set to change images once per day, you can expect the battery of a fully charged Ink frame to last up to six months when the front light is off. You'll receive a message on your frame and in the Aura app (as well as an email from us) when it's time to charge your frame.

Using the buttons

Your Ink frame automatically cycles through photos, but you can also choose the next or previous photo using the "Next" or "Previous" buttons located on the top or side of the frame.



When either of these buttons is pressed, the status light pulses blue, indicating that the imprinting process has begun.

The picture light is controlled by an ambient light sensor. Pressing it temporarily disables the front light, which automatically reactivates at the next display refresh.

Screen orientation

Ink displays photos in either portrait or landscape, depending on how you position the frame. To update the photo's orientation, press the next button—it will refresh to match the frame's placement.

Status light

The status light shows what your frame is doing:

- Pulsing blue: The frame is booting up or refreshing a photo
- Pulsing green: Charging at an optimal rate
- Pulsing red: Not charging—remove and reinsert charger
- Solid green: Fully charged

Update the Aura app

Regularly update the Aura Frames app to enjoy the latest features and the best possible experience.

Photo access and privacy

The Aura Frames app needs access to the photos you wish to send to your frame. Your photos are stored securely on your device, on Aura's cloud servers, and on your Aura frame. They are never shared with third parties without your permission or with others who are not invited to your frame.

Security and privacy

Aura securely uploads and stores your selected photos in a cloud database powered by Amazon Web Services (AWS). We use AES-256 encryption, the industry standard for data security.

Other frame members connected to your frame will see only the photos you've shared with that frame and never those you haven't. Your frame requires an active internet connection to function properly.

For more information, visit auraframes.com/privacy and auraframes.com/data-collection.



Device requirements

For the most up-to-date information, visit auraframes.com/requirements.

iOS: The free Aura Frames app is available for iOS and iPadOS and requires the latest version of either operating system.

Android: The Aura Frames app requires the latest version of Android. Please ensure your operating system is up to date.

Operating requirements

The Aura Ink frame must remain connected to WiFi at all times to imprint new photos.

Setup requirements

- Free Aura Frames app and Aura account required.
- Your phone or tablet must have both Bluetooth and WiFi turned on.

Frequently asked questions

What's different about the Aura Ink display?

Aura Ink replaces a traditional LCD with advanced E Ink Spectra 6™ technology, giving your photos a soft, natural tone that looks more like a printed photo than a screen.

What should I expect when my frame transitions to a new photo?

When the frame transitions to a new image, each pigment capsule repositions to form the updated photo—a process known as imprinting. This gradual transition takes time as the image fully renders.

My frame is not working. Should I try to reset it?

Do not attempt to manually reset your frame or remove it from the Aura Frames app, as you may lose your photos. Instead, contact Aura Customer Care at auraframes.com/help.

Where can I find warranty information?

Visit auraframes.com/warranty.

Can I upload photos from a computer?

Yes, visit app.auraframes.com from your computer browser.

For more FAQs and to learn about new features for your Aura Ink frame and the Aura Frames app, visit auraframes.com/help.



Safety information, warnings, and compliance

WARNING: Before using your Aura frame, read all instructions and safety information carefully. Failure to follow these instructions could result in injury or damage to property.

Electrical safety

Do not disassemble: Do not attempt to open, disassemble, or repair your Aura frame, even when unplugged, as this may cause personal injury and property damage.

Use only the supplied adapter:

- Only use the provided charger model AURA30-001 for the United States.
- Do not use the charger with other devices.
- If the charger or cable appears damaged, stop use immediately and contact Aura customer support at auraframes.com/help.

Power source requirements:

- Confirm that the electrical outlet matches the voltage and frequency specified
INPUT: 100-240VAC 50/60Hz
OUTPUT: 9.0VDC 3.0A

- Avoid non-standard power sources, such as generators or inverters.
- For questions about your power source, consult a qualified electrician.

Keep cables and adapters out of reach of children.
Always unplug your Aura frame before moving it.

Battery:

- Only use the provided battery model: GSP30103123HV-1S4P for the United States.
- Battery type: Rechargeable Li-polymer Battery
- Nominal capacity: 25200mAh
- Nominal Voltage: 3.87V
- Rated energy: 97.524Wh

Medical conditions

WARNING: If you have a medical condition, such as seizures, blackouts, or eye strain, that could be affected by visual stimuli, consult your doctor before using the Aura frame. Discontinue use and consult a doctor if symptoms arise during use.

Interference with medical devices:

WARNING: Aura Frames contain magnets and emit radio frequencies that may interfere with medical devices like pacemakers, hearing aids, or defibrillators. Consult your doctor or device manufacturer before using your Aura frame.



The Aura frame may cause interference with other electronic equipment. Follow the instructions to avoid interference and ensure compatibility.

Avoid Third-Party Accessories: Using non-approved accessories or equipment may impact performance and may void the warranty.

Proper handling and usage

The Aura frame is intended for indoor use only and should be positioned on a stable, flat surface or securely hung on a wall. Ensure that the frame is positioned securely to avoid tipping, which could lead to personal injury or property damage.

Keep your Aura frame away from:

- Water, other liquids, and areas prone to moisture, such as sinks, showers, and pools.
- Heat sources, including space heaters, heater vents, radiators, stoves, or any devices that produce heat.

It is normal for your Aura frame to feel warm during use. Place it in a well-ventilated area where the temperature remains between 60°F and 85°F (19°C to 30°C), with up to 90% relative humidity.

Cables, connectors, and ports

When charging your Aura frame, do not pull on the cable to unplug it; instead, gently remove it by grasping the plug.

Avoid plugging multiple devices into the same wall outlet as the Aura frame, as this may overload the socket and increase the risk of overheating or fire.

Refrain from using extension cords with the Aura frame to prevent socket overload.

To minimize trip or entanglement hazards, arrange any cords and cables so that they are not in high-traffic areas. Ensure they are positioned securely to prevent people or pets from tripping over or accidentally pulling on them.

Care and cleaning your Aura frame

Only clean the exterior of the Aura frame. Do not attempt to open the frame, as this could lead to electric shock or injury.

Use a soft, dry cloth to clean your Aura frame. Avoid using abrasives, harsh chemicals, or compressed air, as these may damage the frame.

Do not use external heat sources, such as a microwave oven or hairdryer, to dry your Aura frame.



Repairing your device

If your Aura frame stops working or requires servicing, please contact the Aura Customer Care team. Visit auraframes.com/help for more information.

Do not attempt to repair, disassemble, or modify your Aura frame yourself. Doing so may damage the device and could result in personal injury or property damage.

Improper or unauthorized repairs will void your limited warranty and may lead to personal injury or property damage.

Compliance mark information

Use of the Made for iPhone | iPad badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. iPad, iPad Air, iPad Pro, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries.

Compliance statement and warnings

How to view E-label information:

Press and hold the Next and Picture Light buttons for 2–3 seconds to display the e-label.

To return to the slideshow, press either the Next or Previous button.

USA

FCC compliance statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device should be installed and operated with a minimum distance 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

For additional FCC information, please visit auraframes.com/fcc.



Canada

ISED Canada compliance statement

This device contains license-exempt transmitters and receivers that comply with the Innovation, Science, and Economic Development Canada license-exempt RSS standards.

Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This device complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device should be installed and operated with a minimum distance 20 cm between the radiator and your body.

The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

Model Name: AF130

Made in China

© 2025 Aura Home, Inc.

