

Appendix A: Test Result Conducted Test


Duty cycle

Condition	Mode	Frequency (MHz)	Duty Cycle (%)	Correction Factor (dB)
NVNT	a	5180	98	0
NVNT	a	5200	98	0
NVNT	a	5240	98	0
NVNT	n20	5180	98.40	0
NVNT	n20	5200	98.40	0
NVNT	n20	5240	98	0
NVNT	n40	5190	96	0
NVNT	n40	5230	96	0
NVNT	ac20	5180	98	0
NVNT	ac20	5200	98.40	0
NVNT	ac20	5240	98	0
NVNT	ac40	5190	96	0
NVNT	ac40	5230	96	0
NVNT	ax20	5180	86.60	1
NVNT	ax20	5200	87	1
NVNT	ax20	5240	87	1
NVNT	ax40	5190	87	1
NVNT	ax40	5230	87	1
NVNT	a	5260	98	0
NVNT	a	5300	98	0
NVNT	a	5320	98	0
NVNT	n20	5260	98.40	0
NVNT	n20	5300	98	0
NVNT	n20	5320	98	0
NVNT	n40	5270	96	0
NVNT	n40	5310	96	0
NVNT	ac20	5260	98	0
NVNT	ac20	5300	98.40	0
NVNT	ac20	5320	98.40	0
NVNT	ac40	5270	96	0
NVNT	ac40	5310	96	0
NVNT	ax20	5260	87	1
NVNT	ax20	5300	87	1
NVNT	ax20	5320	87	1
NVNT	ax40	5270	87	1
NVNT	ax40	5310	87	1
NVNT	a	5500	98	0
NVNT	a	5600	98	0
NVNT	a	5700	98	0
NVNT	n20	5500	98	0
NVNT	n20	5600	98.40	0
NVNT	n20	5700	98.40	0
NVNT	n40	5510	96	0


Condition	Mode	Frequency (MHz)	Duty Cycle (%)	Correction Factor (dB)
NVNT	n40	5590	96.20	0
NVNT	n40	5670	96	0
NVNT	ac20	5500	98.40	0
NVNT	ac20	5600	98.40	0
NVNT	ac20	5700	98.40	0
NVNT	ac40	5510	96	0
NVNT	ac40	5590	96	0
NVNT	ac40	5670	96	0
NVNT	ax20	5500	87	1
NVNT	ax20	5600	87	1
NVNT	ax20	5700	87	1
NVNT	ax40	5510	87	1
NVNT	ax40	5590	87	1
NVNT	ax40	5670	87	1

Test Graphs


Duty Cycle NVNT a 5180MHz




Duty Cycle NVNT a 5200MHz




Duty Cycle NVNT a 5240MHz




Duty Cycle NVNT n20 5180MHz




Duty Cycle NVNT n20 5200MHz




Duty Cycle NVNT n20 5240MHz




Duty Cycle NVNT n40 5190MHz




Duty Cycle NVNT n40 5230MHz




Duty Cycle NVNT ac20 5180MHz




Duty Cycle NVNT ac20 5200MHz




Duty Cycle NVNT ac20 5240MHz




Duty Cycle NVNT ac40 5190MHz




Duty Cycle NVNT ac40 5230MHz




Duty Cycle NVNT ax20 5180MHz




Duty Cycle NVNT ax20 5200MHz




Duty Cycle NVNT ax20 5240MHz



Duty Cycle NVNT ax40 5190MHz




Duty Cycle NVNT ax40 5230MHz




Test Graphs


Duty Cycle NVNT a 5260MHz




Duty Cycle NVNT a 5300MHz




Duty Cycle NVNT a 5320MHz




Duty Cycle NVNT n20 5260MHz




Duty Cycle NVNT n20 5300MHz




Duty Cycle NVNT n20 5320MHz




Duty Cycle NVNT n40 5270MHz




Duty Cycle NVNT n40 5310MHz




Duty Cycle NVNT ac20 5260MHz




Duty Cycle NVNT ac20 5300MHz




Duty Cycle NVNT ac20 5320MHz




Duty Cycle NVNT ac40 5270MHz




Duty Cycle NVNT ac40 5310MHz




Duty Cycle NVNT ax20 5260MHz




Duty Cycle NVNT ax20 5300MHz




Duty Cycle NVNT ax20 5320MHz



Duty Cycle NVNT ax40 5270MHz




Duty Cycle NVNT ax40 5310MHz




Test Graphs


Duty Cycle NVNT a 5500MHz




Duty Cycle NVNT a 5600MHz




Duty Cycle NVNT a 5700MHz




Duty Cycle NVNT n20 5500MHz




Duty Cycle NVNT n20 5600MHz




Duty Cycle NVNT n20 5700MHz




Duty Cycle NVNT n40 5510MHz




Duty Cycle NVNT n40 5590MHz




Duty Cycle NVNT n40 5670MHz




Duty Cycle NVNT ac20 5500MHz




Duty Cycle NVNT ac20 5600MHz




Duty Cycle NVNT ac20 5700MHz




Duty Cycle NVNT ac40 5510MHz




Duty Cycle NVNT ac40 5590MHz




Duty Cycle NVNT ac40 5670MHz




Duty Cycle NVNT ax20 5500MHz




Duty Cycle NVNT ax20 5600MHz



Duty Cycle NVNT ax20 5700MHz



Duty Cycle NVNT ax40 5510MHz



Duty Cycle NVNT ax40 5590MHz

