


2.Specification:


- A.Configuration: 1 American power, USB A charging port, USB C charging port, 1 wireless charger. See above pic.
- B.Rated voltage and current: AC 125V 15A
- C.Rated power: 1875W
- D.USB charging ports power:
 - USB A : DC5V3A/9V2A/12V1.5A 18W Max.
 - USB C : DC5V3A/9V2.2A/12V1.67A 20W Max.
 - USB A and USB C Used together: 38W Max.
- E.Max wireless charging power: 10W

3.Installation size: (unit: mm)




4.How to install (with bracket):

- A.Fit this product into the tabletop and fix it with screws. Ref pic 1




- B.Press the button, the middle cover will pop up. Finally, plug your appliance to use. Ref pic 2.




5.How to install (without bracket):

- A.Discharge the screws to fit the bottom box into the tabletop, fix it with screws. Ref pic 1



- B.Neaten cables inside the box in order to make sure they are not twisted. Fix panel with 2 screws. Finally, press and fix the power cable on the bottom box. Ref pic 2



K207 MULTIFUNCTIONAL OUTLETS ASSEMBLY

USER MANUAL

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical furnishing, basic precautions should always be followed, including the following:

Read all instructions before using (this furnishing).

DANGER – To reduce the risk of electric shock:

1. Always unplug this furnishing from the electrical outlet before cleaning.

WARNING – To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Unplug from outlet before putting on or taking off parts.
2. Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.
3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
4. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
5. Keep the cord away from heated surfaces.
6. Never operate the furnishing with the air openings blocked. Keep the air openings free of lint, hair, and the like.
7. Never drop or insert any object into any opening.
8. Do not use outdoors.
9. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
10. To disconnect, turn all controls to the off position, then remove plug from outlet.
11. **²WARNING: Risk of Injury – Keep children away from extended foot support (or other similar parts).**²
12. Each surface intended to support a load shall have a corresponding statement in the use instructions specifying the maximum intended load for that surface in pounds (kilograms),

SAVE THESE INSTRUCTIONS

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

1.Item code: K207-25

