




Head Massager


Thank you for purchasing our Head Massager. Before using, please read this manual for correct methods of usage. This manual should be kept available for future reference.

CONTENTS


Product Components	2
Preparation	3
Function configuration	4
Operation Guide	5
Precautions	6
Trouble shooting and technical parameters	7
Storage transportation and maintenance	8

Product Components

Master Unit



Accessories



USB cable

Preparation


Preparation before using

- To make sure whether the product has power, it can't turn on without power. Please use it after charging, and the product doesn't support working while charging. Please make sure to unplug the power if you don't use it for a long time. Please not be long-time charging, which will affect the life span of the product.


Charging

1. Insert charge adapt USB socket into the machine's USB interface.
2. In charging status the red LED lamp will flashing, and after charge finished, the LED lamp will still be light.
3. In charging status, the product is not supported to work. (in charging status, the machine will stop working automatically)
4. The machine is with lithium battery supply, charging time is 3-4 hours.

Charging status



Function Configuration



1.Power/Mode button

Long press 2s on/off function, short press 1s is mode choice, it's with 4 different modes.

2. Bluetooth/Music button

Short click “*” play music/stop music;
Double click “*” play next music;
Long click “*” 2 seconds, connect/disconnect;
Short click “*” when answer call /end call;
Double click “*” reject call.

3. Bluetooth Connect

Use your Bluetooth device to search “Massager” and connect it. The Bluetooth sign on the display of massager will stop blink after connecting successfully.

Operation Guide


Default boot:

Relax mode:

Pressure+ Heat

One key can control the mode revolving:

Notice: Every operation, voice warning tone will prompt the current mode. In operation, music will be stop 2seconds, and then restart automatic play.



Precautions

Please do read this Usher's Manual carefully for correct and safe use of this massagr.

1. Do not use the massager when walking in wild and driving.
2. Do not use the massager in high temperature, damp place.
3. Please remove the hairpin, hair accessories and contact lenses before using the massager.
4. Do not use the massager when head injuries or after head surgeries.
5. Do not use the massager when getting sick, or using under supervision.
6. Do not use the massager when getting drunk.
7. This product has heating fonction, please use it carefully if you are not sensitive to temperature.
8. Please turn on the massager after wearing on your head in order to avoid air bag damage of overpressure.
9. This product is personal care products, not a substitute for drugs and medical devices.
10. If you felt uncomfortable or painful when using this product, please stop using and ask doctors.
11. This product is personal care products, please do not use it for diagnoses and treatment.
12. Please clean the massager by medicinal alcohol, do not put it into the alcohol.
13. Do not remove the product by yourself.
14. Please use the original power adapter.
15. Please take out the battery when stopping using for long and recycle waste batteries correctly.

Trouble shooting and technical parameters

If there is any problem when you use the device, Please follow the instructions below to check, if the problem still exists or the device can't work normally, please turn off the power supply and contact the after-sales service center.

Do not disassemble or repair the device yourself

Basic problem	Possible Cause	Solution
Can't turn on the power	The Li battery is low	Use it after charging
The keys are not sensitive	The Li battery is weak	Use it after charging
Air pressure feels weak	The Li battery is weak	Use it after charging

Product name: head massager

Rated voltage: 5V ===

Rated power: 5W

Items in the Box

1 x Head Massager

1 x USB Cable

1 x User Manual

storage transportation and maintenance

Power checking

Check the power supply, if the voltage exceeds the specified range , please do not charge.

Maintenance

If it requires cleaning , wipe it with cotton soaked in alcohol .

Put the device in safe place after using . Do not put heavy objects on the device .

Switch off the device before cleaning the manual controller .

Take measures to prevent moisture , rats and pollution .

Contact qualified technician if there is any fault . Do not disassemble the device yourself .

Transportation and storage

Ideal environment temperature : 5℃-40℃

relative humidity: ≤80% Keep good ventilation condition and away from direct sunshine and corrosive gases .

Atmospheric pressure : 860hpa-1060hpa

Transportation : The product has simple shockproof design and can be transported by air , railway , highway or ship ; avoid rain , snow , impact and always keep the right side up .

In case the storage periods 6 months , please check it and power it on for half an hour .

Do not store close to floor , wall or roof .

Keep good ventilation condition and away from direct sunshine and corrosive gases .

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.