

RAYCON MAGIC POWER BANK 5-IN-1


QUICK START GUIDE

GUIDE DE DÉMARRAGE RAPIDE

GUÍA DE INICIO RÁPIDO



PRODUCT DETAIL PART



AC PLUG



USB-C CABLE
iOS DEVICE CABLE



LCD DISPLAY
POWER BUTTON
USB-A OUTPUT
USB-C INPUT/OUTPUT

PRODUCT SPECIFICATIONS

Model : RAPBAN700 Battery: 10000mAh@3.7V 37Wh

Power Bank Mode:

USB-C Input: DC 5V/2.5A, 9V/2A, 12V/1.5A PD 18W Max

USB-C Output: DC 5V/3A, 9V/2.22A, 12V/1.67A PD 20W Max

iOS Device Wire Output: DC 5V/2.4A Max

USB-C Wire Output: DC 5V/3A Max

USB-A Output: DC 5V/4.5A, 9V/2A, 12V/1.5A 22.5W Max

Wireless Output: 15W Max Sharing output: 5V/3A

Adaptor Mode: AC Input: 100-240V 50Hz/60Hz 0.3A (Max)

USB-C Output: DC 5V/2A USB-A Output: DC 5V/2A

USB-C Wire Output: DC 5V/2A Wireless Output: 5W Max

iOS Device Wire Output: DC 5V/2A Adaptor Mode Output: 10W

Size: 86mm X 86mm X 35.5mm

ATTENTION

- ENGLISH:

- The power bank is NOT a toy and should be kept away from children.
- Please do NOT use the power bank in direct sunlight or extreme heat for extended periods of time.
- Please do NOT submerge the power bank in water.
- Please do NOT leave the power bank near the fire.
- Please do NOT subject the power bank to harsh chemicals.
- Please do NOT use the power bank if it has been damaged and/or modified.
- Please do NOT insert any foreign objects into the openings or port of the power bank.
- Please do NOT attempt to disassemble, repair, or open the power bank in any way.

- FRENCH:

- La banque d'alimentation n'est PAS un jouet et doit être tenue hors de portée des enfants.
- Veuillez NE PAS utiliser la batterie externe à la lumière directe du soleil ou à une chaleur extrême pendant de longues périodes.
- Veuillez NE PAS immerger la banque d'alimentation dans l'eau.
- Veuillez NE PAS laisser la banque d'alimentation près du feu.
- Veuillez NE PAS soumettre la batterie externe à des produits chimiques agressifs.
- Veuillez NE PAS utiliser la batterie externe si elle a été endommagée et/ou modifiée.
- Veuillez ne PAS insérer d'objets étrangers dans les ouvertures ou le port de la banque d'alimentation.
- Veuillez NE PAS tenter de démonter, réparer ou ouvrir la batterie externe de quelque manière que ce soit.

ATTENTION

- ESPAÑOL:

- El banco de energía NO es un juguete y debe mantenerse fuera del alcance de los niños.
- NO utilice el banco de energía bajo la luz solar directa o calor extremo durante períodos prolongados.
- NO sumerja el banco de energía en agua.
- NO deje el banco de energía cerca del fuego.
- NO exponga el banco de energía a productos químicos agresivos.
- NO utilice el banco de energía si ha sido dañado y/o modificado.
- NO inserte ningún objeto extraño en las aberturas o el puerto del banco de energía.
- NO intente desmontar, reparar ni abrir el banco de energía de ninguna manera.

ATTENTION

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

ATTENTION

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC Caution:

Radio Standards Specification RSS-Gen, issue 5

- English:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ATTENTION

- French:

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

Cet appareil ne doit pas causer d'interférences.

Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.