

FRONT COVER



TABLE OF CONTENTS

1. INTRODUCTION	2
2. PACKAGE CONTENTS	3
3. UNIT AT A GLANCE	4
4. FEATURES AT A GLANCE	5
5. CHARGING YOUR DEVICE	6
6. QUICK START GUIDE	7
7. FUNCTIONS	8
8. MULTIFUNCTION MODES	9
9. SUPPORT	10
10. LIMITED WARRANTY	11
11. SPECIFICATIONS	12

INTRODUCTION

Thank you for purchasing the JBL Power Speaker. This portable speaker is designed to provide high-quality sound for your mobile devices. Please read the instructions carefully to ensure proper use and to maximize the performance of your speaker.

Important Safety Information:

- Do not use the speaker near water or other liquids.
- Do not use the speaker near fire or other heat sources.
- Do not use the speaker near children or pets.
- Do not use the speaker near electrical equipment.

UNIT AT A GLANCE



FEATURES AT A GLANCE

- 1. Power Button:** Press and hold for 5 seconds to power on the speaker.
- 2. Volume Up/Down Buttons:** Press to increase or decrease the volume.
- 3. Play/Pause Button:** Press to play or pause music.
- 4. USB-C Port:** Connect your mobile device to the speaker.
- 5. Charging Port:** Connect the charging cable to the speaker.
- 6. Speaker Grilles:** The speaker grilles are located on the front and back of the speaker.








CHARGING YOUR DEVICE

1. Connect the charging cable to the speaker.
2. Connect the other end of the cable to a power source.
3. The speaker will begin charging.
4. The charging time is approximately 2 hours.
5. The speaker will be fully charged when the charging indicator light turns off.

QUICK START GUIDE

1. Charge the speaker fully before use.
2. Press and hold the Power Button for 5 seconds to power on the speaker.
3. Press the Play/Pause Button to play music.
4. Press the Volume Up/Down Buttons to adjust the volume.
5. Connect your mobile device to the speaker using the USB-C Port.

FUNCTIONS



BACK COVER